



Attachments and Spare Parts for
Multi-Spindle Machines

machine

Brown & Sharpe

catalog

**Brown & Sharp Parts List
2018-2019**

Call us today **(704) 849-9209**
or visit us online @ **turningconcepts.com**



brown & sharpe™

PART #	DESCRIPTION
1-432-10	RING, FIBRE
1-432-11	RING, FIBRE
1-432-15	RING, FIBRE
1-432-22	RING, FIBRE
1-432-1300-1	RING, FIBRE
1-432-1301-1	RING, FIBRE
1-432-1302-1	RING, FIBRE
1-432-1304-1	RING, FIBRE
2-432-11	PIN, OUTER RACE
2-432-15	SCREW, RETAINING
2-432-22	SCREW, RETAINING
2-432-1301-1	PIN, OUTER RACE
2BS-1.000-M42	CIRCULAR FORM TOOL BLANK#2, 1"
2BS-1.375-M42	CIRCULAR FORM TOOL #2, 3/8" W
2BS-1.500-M42	CIRCULAR FORM TOOL, #2, 1-1/2W
2BS-125-M42	DOVETAIL BLANK #2, 1-1/4"WIDE
2BS-125-T15	DOVETAIL BLANK #2, 1-1/4"WIDE
2BS-150-M42	DOVETAIL BLANK #2, 1-1/2" WIDE
2BS-150-REX	DOVETAIL BLANK #2 1-1/2" WIDE
2BS-150-T15	DOVETAIL BLANK #2, 1-1/2"WIDE
2BS-200-M42	DOVETAIL BLANK #2, 2" WIDE
2BS-200-REX	DOVETAIL BLANK #2 2" WIDE
3-432-11	SCREW, RETAINING
3-432-15	PIN, OUTER RACE
4S-8080-15A	SCREW MACHINE RELATED ITEM
4S-8111/15A	SCREW MACHINE RELATED ITEM
4S-8112/15A	SCREW MACHINE RELATED ITEM
4S-8123/15A	SCREW MACHINE RELATED ITEM
23-2586-1	GRINDER PART
23-4881	GRINDER PART
40-24-99	CR SLIDE WORM GEAR
40-26-ZZ	RACK, CROSS SLIDE
40-75-99	CLAMP BOLT, TURRET SLIDE
40-109-99	FULCRUM
40-115-99	WRENCH
40-125-99	SPINDLE CLUTCH LEVER
40-129-99	CLAMP NUT

PART #	DESCRIPTION
40-155-99	TURRET CLAMP LEVER
40-267-99	IDLER ADJUST ROD
41-399-1-99	GEAR, TURRET STOP SHAFT
41-478-99	TURRET RATCHET DOG
41-547-99	TURRET LOCKING PIN LEVER
41-548	TURRET RATCHET
41-552-99	TUR LOCK PIN SHELL
41-587-99	TURRET LOCKING PIN
41-626	LOCKING PIN
41-627-99	BUSHING, LOCKING PIN
41-787-99	GIB, TURRET SLIDE
41-863-99	CHUCK NUT
41-876-99	GIB, TURRET SLIDE
41-1480	TURRET CLAMP BUSHINGSHIN
41-1480-A	TURRET TOOL CL. BUSHING PLAIN
41-1480-B	TURRET TOOL CL BUSH-THRD
41-1900-99	TURRET DOG RATCHET STUD
41-1967-99	CHUCK NUT
41-1969-99	CHUCK FORK RINGS
41-2045-99	TURRET LOCKING PIN LEVER
41-2064-99	PAWL, SLIDE & FEED STOP
41-2093	CROSS SLIDE STOP SCREW, BACK
41-2188-99	TURRET RATCHET DOG STUD
41-2229	GIB CLAMP SCREW
41-2569-99	PIN, CLUTCH LEVER BRACKET
41-2579-99	CLUTCH SLEEVE RING
41-2679-99	TURRET TONGUE
41-2713-1-99	TURRET STOP DISK
41-2735-1	STOP SHFT GR BSHNG
41-2736-99	COUPLING
41-2742-99	PLUNGER
41-2766-99	CHUCK LEVER
41-2827-99	TURRET STUD
41-2828-99	TURRET STUD NUT
41-2842-99	PLUG, TURRET STUD NUT
41-2950-99	CHUCK FORK SLEEVE
41-2954	BRAKE LINER

PART #	DESCRIPTION
41-2998-1-99	BRAKE SHOE
41-3090-99	LINER, FRONT BOX
41-3091-1-99	LINER, FRONT BOX
41-3093-1	LINER, FRONT BOX
41-3302-99	CLUTCH FORK SLEEVE
41-3627	BUSHING COMPLETE, TURRET CLAMP
42-58-99	CHUCK FORK RING
42-61-99	CLUTCH SHOE
42-62-99	CLUTCH LEVER
42-78	LEVER
42-81-99	CLUTCH LEVER
42-82	CLUTCH SHOE
42-107-1	CONNECTING ROD
42-107-99	ROD,CONNECTING
42-108-99	FEED LATCH
42-109	PIN
42-142-99	SCREW HOLDER
42-169	TOOL ADJ. BLOCK
42-179	TURRET LOCKING PIN
42-180-99	TURRET LOCKING PIN
42-181-99	TURRET LOCKING PIN
42-231-99	CHUCK FORK RING
42-268-99	DOG, TRIP, WITH T-BOLT
42-268-NF	DOG, TRIP, NO T-BOLT
42-270-99	DOG,SPEED & REV LEVER
42-588-1	DISK, CAM DRIVING
42-589	CAM HOLDER, RAPID PULLOUT ATT.
42-589-1	HOLDER, CAM
42-590-99	INDEX CAM HOLDER
42-594-99	ROTATING CAM HOLDER
42-597	DISK,CAM DRIVING
42-644-99	DOG, TRIP LEVER
42-644-NF	DOG, TRIP LEVER (NO TOE)
42-656-99	CAM HOLDER,CROSS SLIDE FR
42-782-99	CHUCK LEVER FULCRUM SHOE
42-797-99	CLUTCH LEVER
42-798-99	CLUTCH SHOE

PART #	DESCRIPTION
42-1089-99	GIB,CROSS SLIDE BACK
42-1103-99	GIB,TURRET SLIDE
42-1105-99	GIB,TURRET SLIDE
42-1122-99	BUSHING,CLUTCH&DRIVE GEAR
42-1122-A	BUSHING, FINISHED ID
42-1124-3	DISK,TURRET CHANGE ROLL
42-1125	TURRET DISC
42-1125-1	TURRET DISC
42-1173-99	TURRET GEAR SHAFT
42-1174-99	PIN,PLUNGER
42-1179-99	BUSHING,LOCK PIN SLEEVE
42-1194-99	CONECTING ROD
42-1200-99	GEAR,TURRET SHAFT DRIVE
42-1224-99	PLUNGER, SPEED STOP LEVER
42-1228-99	CROSS SLIDE RACK
42-1229-99	SCREW,ADJUSTING
42-1234-1	ARBOR COLLAR
42-1242-99	TURRET SLIDE RACK
42-1266-99	CONECTING ROD
42-1274-1-99	TURRET SLIDE RACK
42-1295-99	DRIVE SPROCKET,PUMP
42-1338-99	TURRET SLIDE RACK
42-1338-ZZ	TURRET SLIDE RACK
42-1340-99	TURRET SLD ADJSTNG SCRW
42-1367-1-99	CHANGE GEAR COLLAR
42-1367-99	CHANGE GEAR COLLAR
42-1368-1-99	LEAD CAM CLAMP NUT
42-1372-99	CHANGE GEAR BUSHING
42-1393-1	LEAD CAM NUT EX
42-1415-99	CHANGE GEAR STUD COLLAR
42-1416-99	STUD NUT
42-1417-99	CHANGE GEAR BUSHING
42-1418-99	STUD,
42-1426	FEED LEVER FULCRUM
42-1430-99	DEFLECTOR SPRING PLUNGER
42-1454-99	GEAR,CROSS SLIDE CAMSHAFT
42-1464-99	GIB,FEED SLIDE

PART #	DESCRIPTION
42-1492-99	CLUTCH SHOE
42-1510-99	FEED LATCH
42-1521-99	GEAR,CAM SHAFT
42-1554-99	GIB,TURRET SLIDE
42-1560-4	SAW GUARD
42-1560-99	SAW GUARD
42-1561-99	SAW GUARD
42-1563-1	EJECTOR
42-1563-2	EJECTOR
42-1563-99	EJECTOR
42-1575-99	LEVER STOP
42-1625-1-99	BUSHING,PULLEY BRACKET
42-1659	CAM DRIVE DISK
42-1663	CAM DRIVE DISK
42-1706-99	CHANGE GEAR BUSH WASHER
42-1744-99	CARRIER RING
42-1765-99	CHUCK RING
42-1858-99	CLUTCH SHOE
42-1859-99	CLUTCH LEVER
42-1872-99	BUSHING,LOCK
42-2017	DRIVING SHAFT
42-2023	STOPPING LEVER LATCH
42-2071	FEED LEVER BLOCK
42-2132	IDLER PULLEY BUSHING
42-2182-99	RING,CLUTCH
42-2185-99	CLUTCH SLEEVE
42-2224	SPROCKET, MOTOR SHAFT
42-2501	BALL RETAINER
42-2707-1	ARBOR COLLAR
42-2707-99	SAW ARBOR COLLAR
42-2739	SLOTING SHFT BLL RTNR
42-2744	SLOTING SHAFT COLLAR
42-2748	ROTATING LEVER ROD
42-2835	SLOTING SHAFT LEVER
42-2836	ARM REST
42-2837	SLOT LEVER STOP
42-2999-99	SPROCKET

PART #	DESCRIPTION
42-3014-99	CAM, TURRET LOCKING PIN
42-3021-99	GIB, CROSS SLIDE FRONT
42-3022-99	GIB,FEED SLIDE
42-3077	CHUCK FORK SLEEVE OUTER
42-3116-99	GIB, CROSS SLIDE FRONT
42-3121	1 7/8 ROLLER BEAR CAGE
42-3142-99	FEED LATCH
42-3236	BUSHING
42-3254-99	LOCKING PIN
42-3282-99	INSERT,CLUTCH LEVER SPNDL
42-3440	ROTATING LEVER FULCRUM
42-3441	ROTATING LEVER BUSHING
42-3497-99	BUSHING NUT
42-3729-1	WORK SUPPORT
42-3729-99	FINGER BLANK
42-3750-99	CHUCK NUT
42-3820	PINION
42-3822-1-99	GEAR,BEVEL
42-3822-2	BEVEL GEAR
42-3827-99	BEVEL GEAR
42-3833-99	BEVEL GEAR
42-3834-99	DRIVING SHAFT PINION
42-3836	PINION
42-3850	FEED TB LTCH SLV
42-3868-99	SPINDLE PULLEY PLUNGER
42-3885-1	TURRET DISC
42-3965-99	PLUNGER CUP WASHER
42-3973-99	WORM
42-4010-99	LEVER SPRING PLUNGER
42-4013	CAM LEVER SPRING PLUNGER
42-4041	COUPLING,MOTOR SHAFT INTERNAL
42-4078-99	ARM STOP
42-4166-1	PLUNGER BRACKET
42-4227-1-99	TURRET GEAR
42-4228-99	INTER GEAR STUD
42-4231-99	BUSHING,GEAR
42-4333	CAM LEVER
42-4333-1	SPRING PLUNGER

PART #	DESCRIPTION
42-4397-99	CHUCK SLEEVE
42-4452-99	TURRET GEAR
42-4453-99	TURRET INTER RETURN GEAR
42-4463-1	CHUCK SLEEVE
42-4487-1-99	VERTICAL TOOL HOLDER
42-4489-1	GIB, VERT SLIDE REAR
42-4489-1-B	GIB, VERT SLIDE, OVER .020
42-4489-99	GIB, VERT. SLIDE WAY
42-4489-B	GIB, OVERSIZE, .020
42-4504-99	GUARD, VERT SLIDE WAY GIB
42-4780-99	NUT
42-4782-99	SLIDE RACK
42-4910-99	DRIVING SHAFT CLUTCH
42-4931	CLUTCH (No4)
42-4934-1-99	CLUTCH, CHANGE DRIVE
42-4942-1-99	TURRET CLUTCH
42-4944	CLUTCH
42-4945-1	CLUTCH, DRIVING SHAFT
42-4945-2-99	DRIVING SHAFT CLUTCH
42-4946-1-99	CLUTCH, REVERSING
42-4947-1-99	CLUTCH, CHANGE DRIVE
42-4949-99	TURRET CLUTCH
42-4954-1-99	CHUCK CLUTCH
42-4957-1-99	CLUTCH, REVERSE
42-5171-1-99	ADJUSTMENT NUT
42-5298	FEED LEVER
42-5307	LATCH
42-5858	FEED TUBE COLLAR
42-5873-99	LEVER
42-5897-99	5/8" SPINDLE, 0G
42-6334	FEED TUBE 5/16 CAP
42-6336-99	CHUCK FORK SLEEVE
42-6361-99	SPINDLE PULLEY
42-6408-99	DRIVE SLEEVE SPROCKET
42-6447-1	DISK, TURRET
42-6447-99	TURRET DISC (6-HOLE TURRET)
42-6536-99	SCREW HOLDER ARM STOP

PART #	DESCRIPTION
42-6562-1	HOLDER,CAM
42-6563-1	DISK,DRIVING
42-6569-1	HOLDER, CAM
42-6571-1	HOLDER, CAM
42-6572-1	DISK, CAM DRIVING
42-6573-2	CAM HOLDER
42-6576-1	DRIVING DISC
42-6577	GUARD
42-6640-99	SLOTING BUSHING
42-6660-99	MOTOR SHAFT SLEEVE FRONT
42-6808-1-99	WORK HOLDER
42-6808-99	WORK HOLDER
42-6816-99	FEED ADJUSTING SCREW
42-6818-99	FEED ADJUSTING SCREW NUT
42-6826	ROTATING CAM
42-6879	MOTOR COUPLING
42-6931	SCREW MACHINE RELATED ITEM
42-6956	CAM HOLDER
42-7014-1-99	VERTICAL TOOL HOLDER
42-7079-99	CHUCK ADJUSTING NUT
42-7093	IDLER PULLEY ARM FULCRUM
42-7107	CROSS SLIDE LEVER BACK
42-7109-2	GIB,CROSS SLIDE-FRONT
42-7109-99	GIB,CROSS SLIDE-FRONT
42-7109-ZZ	GIB
42-7110-2-99	GIB
42-7110-3	GIB,CROSS SLIDE-BACK
42-7110-99	GIB, CROSS SLIDE- BACK
42-7111-99	FULCRUM,CROSS SLIDE LEVER
42-7128-99	LUBRICATOR SPROCKET
42-7129	SPROCKET
42-7130-99	CROSS SLIDE WIPER FRONT
42-7131-99	CROSS SLIDE WIPER BACK
42-7135-99	FEED SLIDE
42-7136	FEED POINTER
42-7144-99	SHAFT SLEEVE
42-7147-99	CHUCK CLUTCH TRIP LEVER

PART #	DESCRIPTION
42-7148-99	TURRET CLUTCH TRIP LEVER
42-7149	SPINDLE FRONT BOX NUT, LEFT
42-7157-99	SLEEVE, TURRET
42-7158	CHUCK DRIVING SLEEVE
42-7159-1-99	TURRET CLUTCH
42-7160-1-99	CLUTCH, CHUCK
42-7160-1-ZZ	CLUTCH
42-7164	INSERT, STEEL, SPINDLE
42-7165-99	BUSHING, CHUCK DRIVESLEEVE
42-7166-99	CLUTCH SHOE
42-7168-99	CLUTCH LEVER
42-7170-99	TURRET & CHUCK FULCRUM
42-7171-2-99	PLUNGER SLEEVE
42-7172-1	PLUNGER SLEEVE NUT
42-7172-2-99	SLEEVE NUT
42-7173-2	FEED LATCH PLUNGER
42-7173-99	FEED LATCH PLUNGE
42-7174-1	PLUNGER WASHER
42-7174-99	PLUNGER WASHER
42-7184-1-99	CLUTCH, DRIVING
42-7186-99	PLUNGER PLATE
42-7205-99	REVERSING DOG CARRIER
42-7207-99	CAM SHAFT
42-7210-1-99	CLUTCH DRIVING
42-7218-99	CROSS SLIDE HLDR FRONT
42-7219-99	DRIVING SHAFT BUSH L
42-7221-99	WORM WHEEL
42-7222-99	FEED TUBE NUT
42-7225-1	FEED CAM ROLL PIN
42-7225-99	FEED CAM ROLL PIN
42-7226-99	STOPPING SPRING PLUNGER
42-7227-99	STOPPING SPRING JOINT
42-7233-99	TURRET DOG CARRIER
42-7234-99	DRIVING SHAFT
42-7237-99	TOOL POST ECCENTRIC
42-7262-99	REVERSING CAM
42-7270-99	TURRET LOCKING PIN CAM

PART #	DESCRIPTION
42-7272-99	DRIVE SLEEVE
42-7273-99	TURRET LOCK PIN CAM EXT
42-7275-99	CROSS GEAR
42-7277-99	SPROCKET
42-7285-99	CHUCK CAM
42-7289-99	LEAD CAM HOLDER
42-7290-99	DRIVE PULLEY SHAFT
42-7296-99	TURRET LEVER PLATE
42-7319-99	WORM DRIVING GEAR
42-7322-1-99	TURRET SHAFT CAP
42-7323-99	LEAD LEVER
42-7326-99	TURRET PIN LEVER
42-7327-99	TURRET LEVER STUD
42-7328-99	CHANGE GEAR STUD
42-7349-99	LEAD LEVER FULCRUM
42-7358-99	SPROCKET
42-7364	PLATE
42-7415	RETAINER PLUNGER
42-7443	NUT,SPINDLE
42-7445	PULLEY BUSHING
42-7445-2	SPROCKET BUSHING
42-7445-3	SPINDLE BUSHING WITH OIL GROOVE
42-7447-99	CLUTCH BODY
42-7455-99	CLUTCH FORK
42-7458	FEED TUBE COLLAR
42-7461-99	FEED TUBE COMPLETE 1/2"
42-7462	ADJUSTING NUT
42-7463-99	SPINDLE PULLEY LEFT
42-7465-99	FULCRUM, CHUCK LEVER
42-7466-99	CHUCK CLOSING TUBE
42-7470-99	CHUCK NUT
42-7479-1	CROSS SLIDE GIB, FRONT
42-7479-99	GIB,CROSS SLIDE-FRONT
42-7480-99	GIB,CROSS SLIDE-BACK
42-7483	OIL PIPE SUPPORT CAP
42-7488-99	GEAR
42-7490-99	CHUCK DRIVE SLEEVE

PART #	DESCRIPTION
42-7491-1-99	CLUTCH, CHUCK
42-7508-99	FULCRUM, REVERS
42-7509-99	CROSS SLIDE LEVER BACK
42-7510	CROSS SLIDE SEGMENT
42-7515-1-99	PLUNGER PLATE
42-7515-99	PLUNGER PLATE
42-7519-99	CHANGE GEAR STUD
42-7525-99	SHAFT
42-7530-99	COLLAR, RIGHT
42-7538	ROD
42-7549-99	CLAMP BUSH STUD
42-7553-1-99	SLEEVE RING
42-7553-2	SLEEVE RING
42-7560-99	SPINDLE REAR BOX COMP
42-7561-99	SPINDLE BOX NUT
42-7562	SPINDLE THRST NT
42-7563	ROLLER BEAR CAG
42-7566-99	WASHER
42-7579-99	COUPLING
42-7582-99	CAM HOLDER, BACK 00G
42-7592-1-99	CHUCK FORK
42-7593-1-99	LEVER STUD
42-7594-99	FEED ADJUSTING SCREW
42-7596	LATCH
42-7599-99	FEED LEVER
42-7600-99	CHUCK FORK FULCRUM
42-7603	REVERSE TRIP LEVER FULCRUM
42-7604-99	FEED LEVER FULCRUM
42-7606-99	STUD
42-7615	SUPPORT
42-7617-99	VERTICAL SLIDE WAY
42-7618	RACK
42-7619	STUD
42-7621-2	ADJUSTMENT DIAL
42-7621-99	ADJUSTMENT NUT
42-7622-1	VERT SLIDE ADJ SCREW
42-7622-99	ADJUSTMENT SCREW

PART #	DESCRIPTION
42-7625-99	SHAFT
42-7626-99	CLAMP SCREW
42-7628	1 1 & 4 RLLR BRNG CG
42-7629-99	VERTICAL SLIDE RACK
42-7630	GEAR,DRIVE
42-7637	VERT SLIDE CAM LEVER
42-7652-99	CUSHION CASE
42-7657-99	LEVER
42-7660-3	TURRET
42-7665-99	NEEDLE BEARING, REAR BOX
42-7666-1-99	TURRRET CLUTCH
42-7688	SCREW CHUTE
42-7688-2	SCREW CHUTE
42-7702-1-99	CLUTCH, CHUCK
42-7703-1-99	CLUTCH
42-7731-99	LEVER FULCRUM
42-7734-3-99	STOCK STOP
42-7734-4	STOCK STOP
42-7734-5	SWING STOP
42-7750-99	PULLEY,DRIVE
42-7751	BASE,STOCK STAND
42-7753-1	SUPPORT,PIPE
42-7753-99	STOCK SUPPORT
42-7759-2	PIPE SUPPORT
42-7767	STOCK BAR
42-7767-1	FRONT STOCK BAR, SHORT
42-7771-99	SPINDLE PULLEY PLUNGER
42-7848-1	CAM, TURRET LOCKING PIN
42-7849-1	PIN CAM
42-7853-K	BUSHING, SPINDLE PULLY
42-7870-2-99	ROLL DISC
42-7872-99	WASHER,CLUTCH BODY
42-7875-99	REAR BOX
42-7876	SPINDLE THRUST NUT
42-7881-99	NEEDLE BEARING
42-7882	CAGE, NEEDLE BEARING
42-7895	CHUCK SLEEVE

PART #	DESCRIPTION
42-7895-ZZ	CLUTCH SLEEVE, SECOND QUALITY
42-7896-1	CHUCK SLEEVE
42-7930	PIN WASHER
42-7988-99	TURRRET CUSHION PLUNGER
42-7991-99	BUSHING,TURRET SHAFT
42-8016-1-99	GUARD,GIB SCREW
42-8017-1-99	GUARD,CROSS SLIDE GIB SCREW
42-8023	STUD COLLAR
42-8024	STUD PLUNGER
42-8025	PIN,SPRING
42-8030-1-99	SLIDE WIPER,FRONT
42-8031-1	WIPER
42-8034-1-99	CLUTCH, CHUCK
42-8035-1	CHUCK CLUTCH INSERT
42-8035-2-99	CHUCK CLUTCH INSERT
42-8045	PLATE, GEAR GUARD
42-8062-99	STOP DISK PLUNGER
42-8066-1-99	TURRET CLUTCH
42-8067-99	COLLAR
42-8077-99	PLUNGER
42-8078-99	DRIVE SLEEVE INSERT
42-8091	WORM WHEEL HUB
42-8104-99	FEED TUBE, 5/8" #0G
42-8108-99	CHUCK LEVER FULCRUM
42-8108-ZZ	CHUCK LEVER FULCRUM
42-8110-99	FULCRUM SHOE
42-8111-99	SPINDLE NUT
42-8120-99	NUT,TURRET CUSHION
42-8122	SPINDLE SPEED PLATE
42-8132-99	FEED ADJUSTING SCREW
42-8135-99	FEED CAM ROLL STUD
42-8139-99	FEED ADJUSTING SCREW NUT
42-8140-99	FEED LEVER BLOCK
42-8143-99	FULCRUM,FEED
42-8151-99	LEVER STOP
42-8154-99	TURRET CHG SHAFT BUSHING
42-8161	STOPPING LEVER FULCRUM

PART #	DESCRIPTION
42-8177	DRIVING PULLEY SHAFT
42-8186-99	SHAFT,GEAR
42-8187-99	CHANGE GEAR STUD
42-8188-99	CHANGE GEAR WASHER
42-8191	ARM CLAMP STUD
42-8193-99	STOCK STOP
42-8195-99	PLUNGER
42-8201-99	SHAFT,TURRET CHANGE
42-8202-99	SHAFT,TURRET CHANGE
42-8203	STOPPING SPRING TUBE
42-8204-99	LEAD LEVER
42-8205-99	LEAD LEVER FULCRUM
42-8206-99	LOCKING PIN CAM EXT
42-8206-M	LOCKING PIN CAM EXT.
42-8207-99	CLUTCH LEVER SEGMENT
42-8218-99	CLUTCH FORK
42-8221-1-99	DRIVING CLUTCH
42-8222-99	REVERSING SHAFT
42-8225-99	DOG CARRIER
42-8233-99	TRIP COLLAR
42-8236-99	TRIP LEVER FULCRUM
42-8239-99	GUARD
42-8241-99	WORM WHEEL
42-8246-99	WORM ADJUST. SCREW
42-8249-1-99	DRIVING CLUTCH
42-8257	CAM LEVER FULCRUM, STOCK STOP
42-8260	TURRET SLIDE LEVER FULCRUM
42-8262-99	SCREW CAP
42-8263	OIL PIPE SUPPORT
42-8264-99	CHUCK FORK FULCRUM
42-8265-99	FULCRUM
42-8267-99	CLUTCH LEVER FULCRUM
42-8269	REVERSING SHAFT COLLAR
42-8275-99	RACK
42-8280-99	CROSS SLIDE WIPER FRONT
42-8281-99	CROSS SLIDE WIPER BACK
42-8285-99	GIB,CROSS SLIDE-FRONT

PART #	DESCRIPTION
42-8286-99	GIB,CROSS SLIDE-BACK
42-8296-99	TURRET SLIDE ADJUST NUT
42-8297-99	SCREW, TURRET SLIDE
42-8298-99	CAM ROLL BAR
42-8302-99	TURRET CUSHION CASE
42-8307-99	DRIVE SHAFT CLUTCH
42-8308-99	DRIVING SHAFT COLLAR
42-8314-99	SLEEVE,DRIVE PULLEY
42-8315	END PLATE
42-8317-99	BUSHING
42-8320	LOCKING SCREW
42-8321	OIL DISTRIBUTOR
42-8325-99	CHUCK FORK YOKE SLEEVE
42-8345-99	PLUNGER SLEEVE
42-8346-99	NUT,FEED LATCH PLUNGER
42-8357-99	SCREW,RACK ADJUST
42-8359-99	PINION SHAFT, V-SLIDE
42-8362-99	DRIVE GEAR,PINION SHAFT
42-8386-1-99	FEED TUBE,COMPLETE 5/8" #0G
42-8386-99	FEED TUBE, COMPLETE 3/4" #0G
42-8386-ZZ	FEED TUBE, SECOND (BENT LIP)
42-8387-99	FEED TUBE NUT
42-8391-1-99	FEED TUBE, COMPLETE 3/4 CAP
42-8405-99	WASHER
42-8423	ECCENTRIC TOOL POST
42-8426-99	SAW ARBOR GEAR DRIVEN
42-8427-99	GEAR, SAW ARBOR
42-8429	GEAR,SAW ARBOR DRIVESHAFT
42-8443-99	SLOTING SHAFT LEVER
42-8505-99	ROLL HOLDER LEFT
42-8510	WORM WHEEL WASHER
42-8513	SPINDLE INSERT (STEEL)
42-8513-1	SPINDLE INSERT (CARBIDE)
42-8513-1-A	INSERT, CARBIDE, 0.01 OVERSIZE
42-8513-1-B	INSERT, CARBIDE, 0.02 OVERSIZE
42-8513-1-C	INSERT, CARBIDE, 0.03 OVERSIZE
42-8513-1-D	INSERT, CARBIDE, 0.04 OVERSIZE

PART #	DESCRIPTION
42-8513-1-E	INSERT, CARBIDE, 0.05 OVERSIZE
42-8513-A	INSERT, SPINDLE, OVER .010
42-8513-B	INSERT, SPINDLE, OVER .020
42-8513-C	INSERT, SPINDLE, OVER .030
42-8513-D	INSERT, SPINDLE, OVER .040
42-8513-E	INSERT, SPINDLE, OVER .050
42-8513-G	INSERT, SPINDLE OVER .070
42-8514-99	CLUTCH SHOE
42-8515-99	CLUTCH LEVER
42-8551-1	SPRING PLUNGER
42-8601-2	SAW ARBOR
42-8602-99	SHAFT COUPLING
42-8612-99	SHAFT GEAR
42-8613-99	ARBOR GEAR
42-8624-1-99	FEED TUBE ADJUSTING NUT
42-8641	FEED TUBE NUT
42-9128-1	TURRET, 8 HOLE 00G
42-9129-1	DISC, TURRET
42-9131	TURRETOOL CLAMP BOLT
42-9132	CLAMP BUSHING
42-9139-99	STOCK SUPPORT
42-9147	TURRET LOCKING PIN CAM
42-9148-1-99	GUARD,CROSS SLIDE BACK
42-9148-2-99	GUARD,CROSS SLIDE BACK
42-9148-3	GUARD
42-9149-2-99	GUARD,CROSS SLIDE FRONT
42-9149-3	GUARD
42-9157	BUSHING
42-9168-1-99	CLUTCH, REVERSING
42-9169	REVERSING CAM
42-9169-1	REVERSING CAM
42-9177	WORK PAN
42-9189-99	DRIVE SHAFT BUSHING
42-9204-99	STOCK STOP LINK
42-9212	FEED PLATE
42-9222-2-99	STOCK STOP
42-9222-3-99	STOCK STOP

PART #	DESCRIPTION
42-9222-4	STOP, SWING STOCK
42-9248-99	RACK SUPPORT
42-9250-99	VERTICAL SLIDE
42-9251-ZZ	RACK, DRIVE GEAR
42-9252-99	RACK ADJ SCREW
42-9253-99	CAM LEVER STUD
42-9254-99	PINION SHAFT,V-SLIDE
42-9255-99	SCREW,VERT WAY CLAMP
42-9257-99	GEAR,PINION SHAFT DRIVING
42-9258	STUD,OPERATING RACK
42-9259-99	GEAR COLLAR
42-9260-1-99	VERTICAL TOOL HOLDER
42-9262-99	GIB,VERT SLIDE WAY
42-9263	OPERATING RACK LEVER
42-9264-99	CAM LVR SPRG PLUNG BUTTON
42-9275-1	ADJUSTING SCREW
42-9278-1-99	DRIVING CLUTCH
42-9278-ZZ	DRIVING CLUTCH
42-9286-3-99	TURRET, 6 HOLE 00G
42-9286-3-A	00G TURRET ONLY
42-9317-99	SLEEVE, CROSS BELT IDLER
42-9318-99	WASHER,BELT IDLER
42-9348	CHUCK FORK SLEEVE YOKE
42-9358-99	PIPE COLLAR
42-9359	COLLAR
42-9360-1	COLLAR
42-9360-99	PIPE COLLAR
42-9364-99	INTER DRIVE SHAFT
42-9365	WASHER, FOR CHANGE GEARS
42-9365-1	SPINDLE CHANGE GEAR WASHER
42-9367-1-99	CLUTCH, CHUCK
42-9368-1-99	INSERT, CHUCK CLUTCH
42-9369-99	CHUCK CAM SHAFT DISK
42-9374-99	REVERSING CAM
42-9375-99	REV CAM BUSHING
42-9376-99	CLUTCH BODY WASHER
42-9377-99	CLUTCH LEVER

PART #	DESCRIPTION
42-9378-99	CLUTCH SHOE
42-9379	SPINDLE INSERT (STEEL)
42-9379-1	SPINDLE INSERT (CARBIDE)
42-9379-1-A	SPINDLE INSERT O/S .010
42-9379-1-B	SPINDLE INSERT, OVER .020
42-9379-1-C	SPINDLE INSERT, OVER .030
42-9379-1-D	INSERT, SPINDLE OVER .040
42-9379-1-E	INSERT, CARBIDE .050 OVERSIZE
42-9379-A	INSERT, SPINDLE, OVER .010
42-9379-B	INSERT, SPINDLE, OVER .020
42-9379-C	SPINDLE INSERT O/S .030 STL
42-9379-D	SPINDLE INSERT, OVER .040
42-9379-F	INSERT, SPINDLE .060 O/S
42-9389-99	PLUNGER SLEEVE
42-9390	LATCH PLUNGER
42-9404	FULCRUM STUD
42-9413-99	CHUCK FEED CAM
42-9416	FEED TUBE COLLAR
42-9417-99	CAP
42-9418-1-99	FEED TUBE, 3/8"
42-9419-1	FEED TUBE, 1/2"
42-9420-1-99	FEED TUBE, COMPLETE 3/8"
42-9421	FEED TUBE, COMPLETE, 1/2"
42-9421-2	FEED TUBE, COMPLETE 1/2" CAP
42-9433-1-99	WASHER
42-9440-1-99	PIPE HOLDER
42-9440-3	PIPE HOLDER
42-9440-99	STOCK HOLDER
42-9441	STOCK PIPE HOLDER
42-9441-2	PIPE HOLDER
42-9443	DRIVING SHAFT CRNK CLTCH
42-9447-99	DRIVING SHAFT
42-9449-99	DRIVE SHAFT CRANK BUSHING
42-9451	FEED TUBE, 3/4", OG
42-9452-3-99	WASHER, FEED TUBE
42-9455-2-99	CHUCK AND FEED CAM
42-9489	ARM STOP

PART #	DESCRIPTION
42-9491-2	BRACKET, SAW SLIDE
42-9515-1	SUPPORT
42-9515-99	SCREW HOLDER SUPPORT
42-9538-1	LEVER
42-9540	CAM LEVER
42-9559	CAM LEVER
42-9562	PINION GEAR
42-9658	OPERATING RACK LEVER
42-9669-99	TURRET SLIDE GUARD
42-9670-99	TURRET DISK GUARD
42-9709-99	CAM STOP DISC
42-9712-99	PINION
42-9715	RACK
42-9716	BRACKET
42-9719	GUARD, BEVEL GEAR COVER
42-9720-99	FULCRUM,X SLIDE
42-9722-1	DISK,TURRET
42-9725	COLLAR,CAM SHAFT
42-9729-1	BUSHING,TURRET OIL
42-9729-2	BUSHING,TURRET OIL
42-9730-99	CROSS SLIDE GUARD FR
42-9731	GUARD,
42-9742-1-99	CHUCK FORK
42-9748-99	CHUCK BLANK
42-9752	EJECTOR PLUNGER BLANK
42-9752-1	EJECTOR PLUNGER
42-9761-2	OIL TUBE ELBOW
42-9768	COVER CATCH COM
42-9773-99	WORM SAFETY LATCH
42-9774-99	EXTENSION, WORM SHAFT
42-9781	WORM SHAFT COLLAR
42-9795-1	TOOL WEDGE
42-9795-99	TOOL WEDGE
42-9798-99	TOOL WEDGE
42-9799-99	TOOL WEDGE
42-9809	ADJUSTING SCREW
42-9817-99	SHAFT,TURRET CHANGE

PART #	DESCRIPTION
42-9829-99	VERT ATTACHMENT SLIDE WAY
42-9830-99	VERT SLIDE BRACKET
42-9834-99	VERTICAL SLIDE WAY
42-9835-99	BRACKET
42-9838	VERTA. SLIDE SWIVEL STOP
42-9853-99	SPINDLE REAR BOX
42-9868	STOP LEVER FULCRUM
42-9870-1	STOPPING LEVER
42-9871-99	STOPPING LEVER SCREW
42-9872-1-99	STOP LEVER ROLL STUD
42-9902-99	STOP ROD BLOCK
42-9904-99	SCREW,STOPP BLOCK RETURN
42-9905-1-99	CLUTCH
42-9910-99	WORM SLEEVE
42-9913-99	DRIVESHAFT,SAFETY CLUTCH
42-9944-99	WORM SLEEVE
42-9945-99	DRIVESHAFT,SAFETY CLUTCH
42-9961-99	VERT SLIDE WAY
42-9967-99	TOOL ADJUSTING BLOCK
42-9982-99	TURRET STOP PLUNGER
42-9990	CLUTCH PLATE
42-9992-99	CHUCK LEVER FULCRUM SHOE
42-10038-2-99	CLUTCH SLEEVE WITH RING
42-10038-2B	CLUTCH SLEEVE FIBRE
42-10038-3	SLEEVE,CLUTCH
42-10038-3-ZZ	CLUTCH SLEEVE, (NO RING)
42-10112	BAR,STOCK STAND
42-10129-1	LEAD CAM CLAMP NUT
42-10130-1	EXTENTION, LEAD CAM NUT
42-10153	SLOTING CAM SHAFT
42-10158	SLOT CAM SHAFT COLLAR
42-10160	SLOTING CAM SHAFT BUSHING
42-10161-99	LEAD CAM SHAFT
42-10163	CATCH
42-10164	LATCH HOLDER
42-10173	IDLER PULLEY
42-10176-99	CHUCK LEVER (FROM FORGING)

PART #	DESCRIPTION
42-10186-99	BELT
42-10205	GUARD CATCH HOLDER
42-10206-99	GUARD CATCH
42-10209-99	THRUST WASHER SHER
42-10223	BUSHING, SPINDLE PULLEY
42-10224-99	PULLEY BUSHING
42-10231-99	CHUCK LEVER FULCRUM
42-10232-1-99	NUT, CHUCK ADJUSTING
42-10236-99	CHUCK LEVER, NO 4
42-10242-99	FULCRUM, TRIP
42-10249	TRIP LEVER DOG TOE
42-10250	TOE , FOR DOG 42-10252
42-10252	DOG, TRIP LEVER
42-10252-NF	DOG, TRIP LEVER (NO TOE)
42-10287	SPINDLE PULLEY BUSHING LEFT
42-10347-1	SPINDLE POST
42-10362-99	DRIV SPROCKET
42-10363	DRIVING PULLEY
42-10367-1	TURRET OIL PIPE
42-10368-1	TURRET PIPE
42-10369	PIPE COLLAR
42-10371-1-99	DRIVING DISC
42-10372-1-99	CAM HOLDER
42-10388	BUSHING, WORM WHEEL
42-10398-1	PLUNGER
42-10398-99	SPRING PLUNGER
42-10412-99	SPRING PLUNGER, X SLIDE R
42-10413-99	SPRING HOLDER
42-10414-99	SPRING PLUNGER, X SLIDE F
42-10415-99	SPRING PLUNGER, X SLIDE F
42-10416-99	PLUMGER, FOR SPRING
42-10417-99	SPRING HOLDER
42-10419-99	CHUCK SLEEVE #22D
42-10432-99	FEED TUBE NUT
42-10432-ZZ	FEED TUBE NUT
42-10442-99	CLUTCH FORK FULCRUM
42-10449	SPINDLE INSERT, STEEL

PART #	DESCRIPTION
42-10449-1	SPINDLE INSERT (CARBIDE)
42-10449-1-A	SPINDLE INSERT .010 OVERSIZE
42-10449-1-B	SPINDLE INSERT, 0.20 OVERSIZE
42-10449-1-C	INSERT, SPINDLE, OVER .030
42-10449-1-D	SPINDLE INSERT, 0.40 OVERSIZE
42-10449-1-ZZ	INSERT
42-10449-A	SPINDLE INSERT, 0.10 OVERSIZE
42-10449-B	SPINDLE INSERT, .020 OVERSIZE
42-10449-D	SPINDLE INSERT, OVER .040
42-10452	CHUCK FORK FULCRUM
42-10458	FEED TUBE COMPLETE
42-10495-99	COLLAR
42-10505-99	NUT LOCK, FRONT BOX
42-10512-1	SUPPORT, PIPE
42-10515-1-99	LOADING BRACKET
42-10516	STOCK PIPE SUPPORT COLLAR
42-10516-1	COLLAR
42-10518-99	STOCK PIPE LOCKING HANDLE
42-10519-99	HOLDER
42-10522	SPINDLE FRONT BOX NUT (R)
42-10524-1	BASE, STOCK STAND
42-10524-1-0-Z	SCREW MACHINE RELATED ITEM
42-10525	STOCK SUPPORT BRACKET
42-10532-1	DRILL SPINDLE
42-10534-1	SPINDLE HOLDER
42-10539-99	CHUCK SLEEVE
42-10550	DRIVING GEAR
42-10551	DRIVEN GEAR
42-10552	SLEEVE
42-10553	RETAINER
42-10553-3	SLEEVE. #00
42-10554	CASE BUSHING
42-10555-1	CASE SUPPORT
42-10555-3	CASE SUPPORT
42-10556-2	CASE SLEEVE
42-10557-1	SHAFT, 24 TH
42-10559	SHAFT BUSHING

PART #	DESCRIPTION
42-10559-1	SHAFT COLLAR
42-10562	SHAFT COUPLING
42-10563	SPRING
42-10570-1	CASE SUPPORT
42-10571	CASE SLEEVE
42-10621-99	RETAINER
42-10632	SPACER, SPINDLE DRIVE
42-10639	SPACER,CHANGE GEAR SHAFT
42-10640-99	RATIO CHANGE GEAR SHAFT
42-10646	GEAR COLLAR
42-10648-99	DRIVE SPROCKET
42-10655-99	HINGE BLOCK
42-10656-99	PLATE, SMALL
42-10657	PLATE, RATIO GEAR
42-10659	GASKET
42-10659-1	GASKET
42-10660-99	BRACKET STUD
42-10678-99	SUPPORT CAP
42-10704-99	IDLER SPROCKET LARGE
42-10706-99	IDLER SPROCKET STUD
42-10709-99	RETAINER
42-10712-99	IDLER ADJ ROD SCREW
42-10721-99	DRIVING CLUTCH SHOE
42-10722-99	CLUTCH LEVER
42-10722-ZZ	CLUTCH LEVER
42-10728	FORWARD OIL GUARD
42-10732-99	CLOSING TUBE
42-10733-1-99	FULCRUM SHOE
42-10743-99	SLIDE CUSHION GUARD
42-10745-99	GEAR THRUST WASHER
42-10746	BUSHING,INTER.GEAR
42-10747	ROLL,TURRET INTER. GEAR
42-10748-1	TURRET GEAR
42-10748-99	TURRET INTER. GEAR
42-10749-99	INTER. GEAR PLUNGER
42-10753-99	INTER. GEAR SHAFT
42-10754-99	DEFLECTOR FULCRUM

PART #	DESCRIPTION
42-10755-99	DEFLECTOR
42-10777-99	SHAFT BUSHING (RIGHT)
42-10778-99	SHAFT BUSHING (LEFT)
42-10779-99	SLIDE LEVER (FRONT)
42-10781-99	SLIDE LEVER (FRONT)
42-10786	GIB, TOP SLIDE
42-10809-99	DEFLECTOR PLUNGER
42-10897-99	SPINDLE REAR BOX
42-10898-99	RETAINER
42-10899-99	PULLEY BUSHING
42-10913	GEAR BUSHING
42-10914	GEAR BUSHING
42-10916	GEAR WASHER
42-10917	GEAR COLLAR
42-10919-4	DRIVING SHAFT
42-10920	GEAR,DRIVEN 22T
42-10921	DRIVEN GEAR
42-10974-99	WORM WHEEL
42-11010	ADAPTER SHAFT
42-11011-1-99	ADAPTER SHAFT
42-11012-1	ADAPT SHAFT
42-11021-99	CHUCK LEVER
42-11029-99	CROSS SLIDE LEVER FRONT
42-11030-99	CROSS SLIDE SEGMENT
42-11035-2	DRILL DRIVE SHAFT
42-11035-4	TURRET & CROSS SHAFT
42-11077-99	NEEDLE BEARING
42-11078-99	NEEDLE BEARING
42-11079	NEEDLE BEARING
42-11085-99	FRONT BOX
42-11092	FORK,DRIVING CLUTCH
42-11097-99	CROSS SLIDE RACK
42-11133-99	CHUCK (BLANK) 0G
42-11151	LEAD LEVER
42-11154-99	STOCK STOP SHAFT
42-11161-99	NEEDLE BEARING
42-11164	OIL PP INTK NT

PART #	DESCRIPTION
42-11173	GEAR
42-11183-99	FEED TRIP LEVER
42-11186	SPINDLE REAR BOX NUT
42-11188-99	FRONT BOX NUT LEFT
42-11189-99	NUT,FRONT BOX RIGHT
42-11200-99	CLUTCH SLEEVE WASHER
42-11218-99	SPROCKET SPACER
42-11238	CHUCK FORK
42-11253-1	GEAR GUARD
42-11254-1	GUARD COVER
42-11258-1	DRIVING SHAFT
42-11259-99	CROSS SLIDE (FRONT)
42-11260-99	CROSS SLIDE (BACK)
42-11263-99	GUARD,CROSSLIDE GIB FRONT
42-11270-1	GUARD, GIB SCREW FRONT
42-11271-99	CROSS SLIDE RACK
42-11272-1-99	GUARD
42-11278-99	DIAL
42-11278-ZZ	DIAL
42-11286	CHUCK SLEEVE
42-11288	CLUTCH SLEEVE WASHER
42-11290-1	CROSS SLIDE DIAL
42-11295-99	TOOL WEDGE SUPPORT
42-11296	WEDGE SUPPORT
42-11297-99	TOOL WEDGE SUPPORT
42-11298-1	DRILL SPINDLE
42-11298-99	DRILL SPINDLE
42-11304-1	SHAFT EXTENSION
42-11304-99	DRILL ADAPTER
42-11340	TURRET SLIDE LEVER
42-11341-99	LEVER FULCRUM
42-11379-99	SPRING TUBE
42-11419-99	ROLL,VERT SLIDE CAM
42-11435-99	HOLDER (FRONT)
42-11448-1-99	FEED TUBE ADJUSTING NUT
42-11457-1-99	FEED TUBE ADJUSTING NUT
42-11458-99	LEVER SHAFT

PART #	DESCRIPTION
42-11465-99	ADJUSTMENT NUT
42-11467-99	CLUTCH SLEEVE WASHER
42-11493	SHAFT COUPLING
42-11494-ZZ	REBUILT SPINDLE 1/2" 00 HS
42-11495-99	FRONT BOX
42-11496-99	CHUCK NUT
42-11497	CHUCK NUT,00 COLLET
42-11500	SPDLE FRNT BX NT RGHT
42-11517-99	CROSS SLIDE CHIP GUARD
42-11542-99	TRIP LEVER
42-11549-99	DOG, TRIP LEVER
42-11554-ZZ	FRONT BOX
42-11557-99	CHUCK NUT,22 SPECIAL
42-11560-99	NUT(22D SP COL)
42-11561-99	FEED TUBE, COMPLETE 1-1/2" #2
42-11562-99	FEED TUBE, 1-1/2" #2
42-11564-99	NEEDLE ROLLER BEARING
42-11564-ZZ	NEEDLE ROLLER BEARING
42-11566	SPINDLE REAR BOX
42-11566-ZZ	SPINDLE REAR BOX
42-11567	RETAINER, REAR BOX
42-11570-ZZ	NEEDLE BEARING
42-11571	2 1&2 RLLR BRNG CG
42-11579-99	GEAR, DRIVE PULLEY SHAFT
42-11613	BELT,DRIVE SHAFT PULLEY(INSRT)
42-11614-99	LOCKING BUSH, TURRET
42-11615-99	LOCKING BUSH, TURRET
42-11616-99	LOCKING BUSH, TURRET
42-11616-A	BUSHING, TURRET, OVERSIZE +5
42-11620	OIL SHIELD (FRONT)
42-11625	OIL LABYRINTH SEAL
42-11631-99	CHUCK FORK
42-11650-99	CROSS SLIDE (BACK)
42-11651-99	CROSS SLIDE, FRONT
42-11656	LEVER FULCRUM
42-11681-99	VERT.SL.BRACKET
42-11686-1-99	PUMP SPROCKET

PART #	DESCRIPTION
42-11689-99	CHUCK SLEEVE, NO. 22 C
42-11695-2	SLIDE BRACKET
42-11696-1-99	WASHER, NEOPRENE
42-11699	SLOTING LEVER
42-11796-99	WASHER, FEED TUBE
42-11819-99	WORM WHEEL SHAFT
42-11854-99	LABYRINTH OIL SEAL, LEATHER
42-11857-99	SPROCKET
42-11860-1-99	PUMP SPROCKET
42-11860-99	PUMP SPROCKET
42-11881-99	TRIP LEVER
42-11892-1-99	SPINDLE, 5/8" CAPACITY
42-11894-99	SPROCKET
42-11896-99	BELT, CHUCK DRIVE PULLEY
42-11897-99	BELTING
42-11902-99	DRIVING CLUTCH SHOE
42-11919	WASHER
42-11921	SPINDLE NUT
42-11923	FRONT BOX, NUT LEFT
42-11927-99	CHUCK NUT
42-11930-99	NUT, REAR BOX
42-11931	RETAINER NUT
42-11933-99	SPACER, REAR
42-11938	PULLEY AND SPROCKET
42-11963	OIL GUARD GUIDE (OUTER)
42-12026	STOCK SUPPORT YOKE BAR
42-12026-1	BAR, YOKE
42-12049	HEAD
42-12068-3	GEAR CASE
42-12068-3-ZZ	GEAR CASE, 2ND QUALITY
42-12099-2	HOLDER SUPPORT
42-12101-2	WORK CHUTE
42-12101-3	WORK CHUTE
42-12101-99	SCREW CHUTE
42-12102-1	WORK HOLDER
42-12102-99	SCREW HOLDER
42-12111-99	SCREW HOLDER SUPPORT

PART #	DESCRIPTION
42-12113-99	EJECTOR
42-12159-99	SPACER, INNER
42-12164-99	GEAR,SPINDLE DRIVESHAFT
42-12166-99	CROSS SLIDE FRONT
42-12168-99	GUARD BACK
42-12171-99	SPROCKET,SPINDLE DRIVE
42-12173-1-99	IDLER SPROCKET LARGE
42-12179-99	GEAR,PULLEY
42-12180	SPROCKET
42-12181-1	DRIVE SPROCKET
42-12182-99	GEAR
42-12190-1	SPINDLE, 00B
42-12190-99	SPINDLE, 00
42-12190-ZZ	SPINDLE
42-12191-2	SPINDLE SPROCKET LEFT
42-12191-99	SPINDLE SPROCKET LEFT
42-12192-2	SPINDLE SPROCKET RIGHT
42-12192-3	SPINDLE SPROCKET, RIGHT
42-12192-99	SPINDLE SPROCKET RIGHT
42-12193-2	SPINDLE REAR BOX
42-12193-99	SPINDLE REAR BOX
42-12194	NUT,REAR BOX
42-12195-99	NUT, REAR BEARING
42-12197-99	RETAINER NUT
42-12198-99	SPACER
42-12227-99	IDLER ARM
42-12228-2-99	IDLER SPROCKET LARGE
42-12229-3-99	IDLER SPROCKET SMALL
42-12230-99	IDLER SPROCKET STUD
42-12236-99	CLUTCH RING,DRIVING SHAFT
42-12257-99	LINK,STOCK STOP
42-12258	STOCK STOP SHAFT
42-12260	CHUCK CAMSHAFT
42-12261	GEAR,CHUCK CAM SHAFT GEAR
42-12263-2	REVERSING SHAFT
42-12263-99	REVERSING SHAFT
42-12264-1-99	REV.DOG CARRIER

PART #	DESCRIPTION
42-12265-3	REVERSING SHAFT COUPLING
42-12266-99	COLLAR,CROSSLIDE CAM SHAFT
42-12268	FULCRUM
42-12269-99	TRIP LEVER
42-12270-99	CHUCK CLUTCH TRIP LEVER
42-12271	REVERSING TRIP LEVER FULCRUM
42-12280	GUARD
42-12283	COVER GASKET
42-12291	NUT,SPINDLE
42-12292	FRONT BOX, NUT
42-12293	FRONT BOX, NUT RIGHT
42-12300-99	LEAD LEVER FULCRUM
42-12302	RETAINING PIN
42-12320-1-99	BODY WASHER, FIBRE
42-12327	CROSS SLIDE DIAL
42-12327-3	DIAL ONLY
42-12327-3-ZZ	DIAL
42-12351-1-99	THRUST WASHER
42-12375-99	BUSHING,TURRET CHANGE
42-12391-99	CHUCK LEVER FULCRUM
42-12395-99	CROSS SLIDE CAM SHAFT
42-12396-99	CR SL CAM SHAFT
42-12397-99	CHUCK LEVER (FROM FORGING)
42-12480-99	SPACER, OUTER
42-12486-99	OIL TUBE
42-12489	MOTOR BRACKET
42-12489-1	MOTOR BRACKET
42-12501-99	GEAR,LEAD CAM
42-12503-99	TOOL PAN RIGHT
42-12504-99	CAM SHAFT
42-12507-99	LEAD CAM SHAFT
42-12509-99	WORM WHEEL SHAFT
42-12510-99	GEAR,WORM WHEEL
42-12511-99	WORM WHEEL
42-12514-99	BUSHING
42-12515	BUSHING
42-12518-99	WORM

PART #	DESCRIPTION
42-12522	CLUTCH
42-12523-99	THRUST WASHER
42-12525-1	EJECTOR
42-12525-99	EJECTOR
42-12527	LEVER COMP
42-12528	SLOTING LEVER
42-12531-1-99	SHAFT
42-12533-1	SHAFT, 20 TEETH
42-12544	SCREW HOLDER ARM
42-12544-2-99	HOLDER ARM
42-12544-5	WORK HOLDER ARM
42-12544-5-ZZ	WORK HOLDER ARM
42-12545	CLUTCH FORK
42-12564-2-99	SPINDLE, 1 1/4 CAPACITY
42-12565-99	SPINDLE, 1 1/2" CAPACITY
42-12581-99	ADJUSTING SCREW, SLIDE
42-12586-99	WORK HOLDER ARM
42-12587-1-99	CONNECTING ROD BAR
42-12587-1-A	BAR AND DIAL
42-12588-2-99	BEARING, FRONT BOX CYLINDRICAL
42-12591-2-99	BEARING, FRONT BOX CYLINDRICAL
42-12606	OIL STRAINER
42-12616-99	FELT WASHER
42-12617	FELT WASHER
42-12618	FELT WASHER
42-12619-99	FELT WASHER
42-12620-1	LAB. SPRING WASHER
42-12620-2	WASHER SPRING, WAVE TYPE
42-12620-99	FELT WASHER
42-12621-1	LABYRINTH WASHER, BRASS
42-12621-99	FELT LABRYINTH WASHER
42-12629-3	PLUNGER ASSM
42-12630-3	WORK SUPPORT
42-12651	CARRIER
42-12652-99	WORM SAFETY LATCH PLUNGER
42-12654-99	FULCRUM, CROSS SLIDE SEGMENT
42-12659-99	COLLAR

PART #	DESCRIPTION
42-12680	SPRING PLUNGER
42-12685	SPRING RETAINER
42-12706-99	CROSS SLIDE ADJ. COMPLETE
42-12706-A	SCREW ONLY
42-12707-1-99	SCREW,CROSS SLIDE ADJ.
42-12717	BOX PLATE
42-12721-3	SAW GUARD
42-12723-3-99	BEARING,FRT.BOX CYL,SHORT ROLL
42-12723-3B	NEEDLE BRG,FRT.BOX,LONG ROLL
42-12723-3B-C	SCREW MACHINE RELATED ITEM
42-12723-3B-R	ROLL
42-12723-3B-SR	PINS, CAGE BEARING
42-12729-99	LEVER,STOP
42-12732	ROTATING CAM HOLDER
42-12736-2	OIL SLINGER BLADE
42-12736-3-99	OIL SLINGER BLADE
42-12740-99	RETAINER, IDLER SPROCKET
42-12792	SCREW MACHINE RELATED ITEM
42-12796-99	DOG, TRIP LEVER
42-12817	COVER LATCH
42-12833	LATCH, CHANGE GEAR DOOR
42-12859-99	CHUCK&FEED CAM ST.PLUNGER
42-12861-1-99	SAW ARBOR
42-12861-2	SAW ARBOR
42-12861-99	SAW ARBOR
42-12866-1-99	DRIVESHAFT
42-12869	SHAFT COLLAR
42-12869-1	SHAFT COLLAR
42-12886-1	RING INSERT
42-12889-99	CLUTCH BODY, #2G 1 1/2
42-12890-1-99	CLUTCH SLEEVE
42-12891	CLUTCH SLEEVE RING
42-12894-99	CLUTCH BODY NO2 1-1/4"
42-12894-ZZ	CLUTCH, RE-BUILT
42-12895-99	CLUTCH SLEEVE
42-12898-2-99	CHANGE GEAR,45 TEETH
42-12906-99	SPACER

PART #	DESCRIPTION
42-12915	BODY RING
42-12916-1-99	CLUTCH BODY,#0G
42-12917-1	CLUTCH SLEEVE
42-12918-1-99	SLEEVE RING
42-12920	CLUTCH SLEEVE BUSHING
42-12938-99	LOCKING PIN LEVER
42-12946-1	SHAFT
42-12947-1	SHAFT, 28 TH.
42-12949-99	CHUCK FORK FULCRUM
42-13043-99	BELT, LEATHER, DRIVE PULLEY
42-13117	LATCH,FEED
42-13172	VERT STOP
42-13179-99	FULCRUM,LINK PIN LEVER
42-13188-99	CLUTCH SLEEVE
42-13189	CLUTCH SLEEVE RING
42-13191-1	PLUNGER BUFFER
42-13194-99	CHUCK NUT
42-13195-99	CHUCK NUT
42-13196-99	NUT,SPINDLE BOX
42-13198-99	SPINDLE NOSE OIL GUARD
42-13199-99	FELT WASHER
42-13200	FELT WASHER
42-13201-99	FELT WASHER
42-13202-99	FELT WASHER
42-13204-99	CHUCK NUT, 22D
42-13205-99	CHUCK NUT,22 SPECIAL
42-13206-99	CHUCK NUT,22C SPECIAL
42-13210-99	SPINDLE NOSE OIL GUARD
42-13216	TURRET LOCKING PIN CAP
42-13223-99	STUD,LINK PIN STUD
42-13235-3-99	BEARING, FRONT BOX
42-13235-3B	FRONT BOX BEARING, LR
42-13273-1	ARM, WORK HOLDER #2 BARRING
42-13274-99	TURRET CUSHION
42-13291-1-99	ADJUSTMENT NUT
42-13292-99	SLEEVE
42-13295-99	FEED TUBE, COMPLETE 1-1/4" #2

PART #	DESCRIPTION
42-13296-1	FEED TUBE, 1-1/4"
42-13298-99	STOPPING BLOCK
42-13306-2	SLOTING LEVER
42-13382-1-99	CHUCK FORK SLEEVE, COMPLETE
42-13382-1K	KIT,CHUCK FORK SLV,1/2"
42-13384-1-99	CHUCK FORK SLEEVE, COMPLETE
42-13384-1K	KIT,CHUCK FORK SLV,3/4"
42-13386-1-99	CHUCK FORK SLEEVE, COMPLETE
42-13386-1K	KIT,CHUCK FORK SLV,1-1/4"
42-13388-1-99	CHUCK FORK SLEEVE, COMPLETE
42-13388-1K	KIT,CHUCK FORK SLV,1-1/2"
42-13389-1-99	SHOE, CHUCK FORK SLEEVE
42-13390-1-99	SHOE, CHUCK FORK SLEEVE
42-13391	SHOE,SLEEVE, FOR 2G ONLY
42-13391-1	SHOE, CHUCK FORK SLEEVE
42-13402	CHUCK ADJUSTING NUT
42-13402-1-99	ADJUSTMENT NUT
42-13404	SHAFT CRAN
42-13409-1-99	BEARING, FRONT BOX CYLINDRICAL
42-13411	CAGE ROLLER
42-13412	SPINDLE NOSE OIL GUARD
42-13414	FRONT BOX, NUT RIGHT
42-13415-99	FRONT BOX
42-13426-ZZ	SLEEVE
42-13436-99	LEAD CAM SHAFT SLEEVE
42-13479-2	DRIVING SHAFT
42-13496	FRAME BUSHING
42-13552-2-99	FEED SLIDE
42-13554-1-99	CHUCK FORK
42-13558-99	FEED ADJUSTING SCREW
42-13559-99	FEED ADJUST SCREW CRANK
42-13562-99	FEED LEVER FULCRUM(LONG)
42-13570	OIL PIPE SUPPORT
42-13583	SPINDLE SPROCKET RIGHT
42-13584-1-99	SPROCKET (SMALL)
42-13585-1-99	IDLER SPROCKET SMALL
42-13588-99	SPINDLE NOSE OIL GUARD

PART #	DESCRIPTION
42-13589-1-99	NUT,FRONT BOX
42-13590-99	BUSHING,SPINDLE SPROCKET
42-13598-99	SHAFT BUSHING
42-13601-ZZ	PULLEY
42-13603	SP.PULLEY LEFT
42-13605-99	CHUCK SLEEVE, NO. 11C
42-13606-99	CHUCK SLEEVE
42-13606-ZZ	CHUCK SLEEVE
42-13618-99	CHUCK SLEEVE,NO.00
42-13619-1	CHUCK SLEEVE #10
42-13620-1-99	CAM LEVER STUD
42-13637-1	BUSHING HOLDER
42-13638	HOLDER SHANK
42-13639	GUIDE KEY
42-13640	WORK PUSH PLATE
42-13641-2	DRIVING SHAFT
42-13641-3	DRIVING SHAFT
42-13642-99	SPRING PLUNGER,SLIDE
42-13644	SPINDLE, REAR DRILL& BURR
42-13645	GEAR SPACER
42-13646	SPACER
42-13647-1	RETAINER
42-13648-2	ARM STOP
42-13653	BUSHING BLANK
42-13654-1	MOTOR BRACKET
42-13655	ADJUSTING PLATE
42-13656-2	GUARD, MOTOR BELT
42-13657-1	SPINDLE SLIDE
42-13658	WORK CHUTE
42-13658-1	WORK CHUTE UPPER
42-13659-2	EJECTOR
42-13661-99	WORK BUSHING BLANK
42-13663-3	SPINDLE SLIDE
42-13664-1	SPINDLE,BURRING HEAD
42-13665	BUSHING HOLDER
42-13666	BUSHING HOLDER
42-13667	SPINDLE GEAR SPACE

PART #	DESCRIPTION
42-13669-99	HOLDER STOP
42-13670-1	EJECTOR
42-13672	HOLDER GUIDE
42-13674	GUIDE KEY
42-13675	WORK CHUTE,UPPER
42-13676	SPACER
42-13678	SPINDLE GEAR
42-13681	BUSHING PLATE
42-13688	SPINDLE PLUNGER
42-13689-1	GUIDE, HOLDER BUSHING
42-13702	CHUCK HOLDER
42-13704-1	COLLET NUT
42-13705-2	PLUNGER BLANK
42-13709-99	COLLET NUT
42-13711-1	CHUCK HOLDER
42-13713-99	COLLET NUT
42-13792-99	CROSS SLIDE RACK
42-13799	CAM LEVER STUD
42-13846-99	BELT
42-13847-99	BELT
42-13848-99	BELT
42-13863-99	CHUCK CAM ROLL STUD
42-13864-1	PANEL WIRES
42-13866	MOTOR SHAFT CP GUARD
42-13866-1	PULLEY GUARD
42-13867-99	BUSHING,ARBOR DRIVESHAFT
42-13869-4	SAW SLIDE
42-13873	MOTOR GEAR
42-13873-1	MOTOR GEAR (45T)
42-13877-1	WORK HOLDER ARM
42-13877-4	HOLDER ARM
42-13879-99	SLOTING SHAFT
42-13880	SPRING GUARD
42-13881-99	WORK HOLDER ARM BASE
42-13882-1-99	LEVER
42-13889-99	CLUTCH SLEEVE
42-13892-1	SAW ARBOR DRIVESHAFT

PART #	DESCRIPTION
42-13892-99	SAW ARBOR DR SHAFT
42-13894-1-99	FRONT BOX
42-13895-99	LINER, FRONT BOX
42-13896-1-99	FRONT BOX
42-13897-1-99	LINER, FRONT BOX
42-13898-99	FRONT BOX
42-13899-99	FRONT BOX LINER
42-13900-99	FRONT BOX
42-13901-99	LINER
42-13915-3-99	BEARING, FRONT BOX CYLINDRICAL
42-13921-2-99	BEARING, FRONT BOX CYLINDRICAL
42-13927-1	CAM SHAFT CAP BUSHING
42-13929-2-99	BEARING, FRONT BOX CYLINDRICAL
42-13936	STAND BRACKET
42-13936-2	STAND BRACKET
42-13947-3-99	BEARING, FRONT BOX CYLINDRICAL
42-13963-99	GARD STRAP
42-13970-99	TURRET SLIDE
42-13971	TURRET SLIDE GD
42-13976-99	TURRET GEAR
42-13977-99	RETURN GEAR
42-13996-1-99	CHUCK FORK SLEEVE, COMPLETE
42-13996-1K	KIT,CHUCK FORK SLV,1-1/4"
42-14015-1-99	GIB, FRONT
42-14088-99	STUD,CHANGE GEAR
42-14103-99	WASHER
42-14106	SPINDLE SPROCKET BRNG RNG
42-14107	BEARING, SPROCKET CYLINDRICAL
42-14112-99	FRONT BOX
42-14113	SPINDLE FRONT BOX LINER
42-14120	SPINDLE FRNT BX BRNG RN
42-14134	RING INSERT
42-14138-99	LEVER
42-14140-99	SHOE
42-14145	FEED TUBE WASHER
42-14146-99	CHUCK LEVER
42-14147-1	FULCRUM, CHUCK LEVER (No 4)

PART #	DESCRIPTION
42-14151-1-99	FULCRUM SHOE
42-14154	INSERT,CLUTCH LEVER SPINDLE
42-14171	CLUTCH (No4)
42-14256-1	SHAFT
42-14282-99	OILER, GEAR
42-14291-99	LUB SPROCKET
42-14309-99	INSERT
42-14324-1	SAW SLIDE COVER
42-14348-1-99	SPINDLE NOSE OIL GUARD
42-14348-2	OIL GUARD
42-14348-99	SPINDLE NOSE OIL GUARD
42-14352	CHUCK & FEED CAM, WITH GEAR
42-14355	CHUCK AND FEED CAM GEAR
42-14361-1-99	LEVER ROLL PIN
42-14425-2	BRACKET,TURRET HANDLE
42-14454-99	TURRET CLUTCH
42-14455-99	CLUTCH
42-14464-3-99	ADJUSTMENT SCREW
42-14479-99	DOG, TRIP #4 TURRET
42-14480-99	DOG, TRIP RIGHT #4
42-14484-99	DOG, TRIP LEVER-TURRET
42-14506-99	TOOL POST WORM SEGMENT
42-14543-99	ROLL PIN
42-14598-99	SLOTING BUSHING
42-14599-99	SLOTING BUSHING
42-14600-99	SLOTING BUSHING
42-14601-99	SLOTING BUSHING
42-14602-1-99	SLOTING BUSHING
42-14602-99	SLOTING BUSHING
42-14603-1	SLOTING BUSHING
42-14603-99	SLOTING BUSHING
42-14650	BLOCK, TOOL POST RAISING
42-14651	TOOL POST RAISING BLOCK BACK
42-14652-99	DOG, DEFLECTOR
42-14653-99	DOG, DEFLECTOR
42-14654-99	DEFLECTOR DOG
42-14655-99	DOG, TRIP, LEFT WITH T-BOLT

PART #	DESCRIPTION
42-14655-NF	DOG, TRIP, LEFT, W/O T-BOLT
42-14656-99	DOG, TRIP, RIGHT WITH T-BOLT
42-14656-NF	DOG, TRIP, RIGHT, W/O T-BOLT
42-14658-99	DEFLECTOR DOG
42-14660-99	DOG, DEFLECTOR
42-14661-99	DOG, DEFLECTOR
42-14720-99	FEED TUBE, COMPLETE 5/8" #0G
42-14735-99	DOG DEFLECTOR
42-14736-99	DOG DEFLECTOR
42-14762-99	CHUCK NUT
42-14804-99	ROLL STUD
42-14831-99	CHANGE GEAR, 20 TEETH
42-14832-99	CHANGE GEAR, 21 TEETH
42-14843-99	CHANGE GEAR, 20 TEETH
42-14844-99	CHANGE GEAR, 22 TEETH
42-14845-99	CHANGE GEAR, 24 TEETH
42-14846-99	CHANGE GEAR, 26 TEETH
42-14847-99	CHANGE GEAR, 28 TEETH
42-14848-99	CHANGE GEAR, 30 TEETH
42-14849-99	CHANGE GEAR, 32 TEETH
42-14852-99	CHANGE GEAR, 40 TEETH
42-14853-99	CHANGE GEAR, 16 TEETH
42-14854-99	CHANGE GEAR, 48 TEETH
42-14855-99	CHANGE GEAR, 58 TEETH
42-14856-99	CHANGE GEAR, 60 TEETH
42-14859-99	CHANGE GEAR, 22 TEETH
42-14860-99	CHANGE GEAR, 24 TEETH
42-14878	LEVER DOG TOE
42-14917-99	CHANGE GEAR, 80 TEETH
42-14917-ZZ	GEAR, CHANGE - 80 TEETH
42-14919-99	CHANGE GEAR, 90 TEETH
42-14920-99	CHANGE GEAR, 110 TEETH
42-14921-99	CHANGE GEAR, 120 TEETH
42-14923-99	CHANGE GEAR, 96 TEETH
42-14943-99	CHANGE GEAR, 32 TEETH
42-14944-99	CHANGE GEAR, 35 TEETH
42-14945-99	CHANGE GEAR, 36 TEETH

PART #	DESCRIPTION
42-14946-99	CHANGE GEAR,40 TEETH
42-14947-99	CHANGE GEAR,42 TEETH
42-14948-99	CHANGE GEAR,48 TEETH
42-14949-99	CHANGE GEAR,54 TEETH
42-14950-99	CHANGE GEAR,60 TEETH
42-14951-99	CHANGE GEAR,70 TEETH
42-14952-99	CHANGE GEAR,72 TEETH
42-14953-99	CHANGE GEAR,77 TEETH
42-14954-99	CHANGE GEAR,78 TEETH
42-14955-99	CHANGE GEAR,80 TEETH
42-14956-99	CHANGE GEAR,84 TEETH
42-14957-99	CHANGE GEAR,88 TEETH
42-14958-99	CHANGE GEAR,90 TEETH
42-14959-99	CHANGE GEAR,96 TEETH
42-14960-99	CHANGE GEAR,30 TEETH
42-14961-99	CHANGE GEAR,34 TEETH
42-14962-99	CHANGE GEAR,38 TEETH
42-14963-99	CHANGE GEAR,40 TEETH
42-14964-99	CHANGE GEAR,42 TEETH
42-14965-99	CHANGE GEAR,44 TEETH
42-14966-99	CHANGE GEAR,46 TEETH
42-14967-99	CHANGE GEAR,48 TEETH
42-14968-99	CHANGE GEAR,50 TEETH
42-14969-99	CHANGE GEAR,52 TEETH
42-14970-99	CHANGE GEAR,54 TEETH
42-14971-99	CHANGE GEAR,56 TEETH
42-14972-99	CHANGE GEAR,58 TEETH
42-14973-99	CHANGE GEAR,60 TEETH
42-14974	CHANGE GEAR,70 TEETH
42-14997	TURRET INTER. SHAFT GEAR PIN
42-15034-99	CHUCK FORK SLEEVE
42-15034-A	SCREW MACHINE RELATED ITEM
42-15043	HOOK BOLT
42-15076-1-99	FULCRUM
42-15116-99	CHUCK NUT
42-15119-99	CHANGE GEAR,56 TEETH
42-15120-99	CHANGE GEAR,48 TEETH

PART #	DESCRIPTION
42-15122-99	CHANGE GEAR,33 TEETH
42-15124-ZZ	CHANGE GEAR, 36, NOT 1ST
42-15125-99	CHANGE GEAR,64 TEETH
42-15126-99	GEAR 40 TEETH
42-15127-99	CHANGE GEAR,60 TEETH
42-15128-99	DOG, TRIP, LEFT WITH T-BOLT
42-15128-NF	DOG, TRIP, LEFT, W/O T-BOLT
42-15129-99	DOG, TRIP, RIGHT WITH T-BOLT
42-15129-NF	DOG, TRIP, RIGHT, W/O T-BOLT
42-15130-99	HOOK BOLT
42-15134	FEED SCALE
42-15134-1	FEED SCALE ENGLISH
42-15139-99	YOKE
42-15145-4-99	SHAFT AND DISK COMP.
42-15145-4-NF	SHAFT ONLY
42-15150-99	DOG, TRIP, LEFT WITH T-BOLT
42-15150-NF	DOG, TRIP, LEFT, W/O T-BOLT
42-15151-99	DOG, TRIP, RIGHT WITH T-BOLT
42-15151-NF	DOG, TRIP, RIGHT, W/O T-BOLT
42-15158-1	CLAMP BOLT
42-15159-1	CLAMP BOLT FRONT
42-15161-99	HOOK BOLT, FRONT
42-15165-99	CHANGE GEAR,28 TEETH
42-15168-99	CHANGE GEAR,16
42-15170-99	CHANGE GEAR,18 TEETH
42-15171-99	CHANGE GEAR,32 TEETH
42-15172-99	CHANGE GEAR,15 TEETH
42-15174	SPINDLE CHANGE GEAR, 14T
42-15176	FEED SCALE - METRIC
42-15178-99	DOG, TRIP, RIGHT WITH T-BOLT
42-15178-NF	DOG, TRIP, RIGHT, W/O T-BOLT
42-15179-99	DOG, TRIP, LEFT, WITH T-BOLT
42-15179-NF	DOG, TRIP, LEFT, W/O T-BOLT
42-15197-99	CHUCK LEVER
42-15198	CHUCK LEVER (FROM FORGING)
42-15199-99	SLEEVE
42-15208-99	HOOK BOLT, BACK, LARGE HEAD

PART #	DESCRIPTION
42-15209	HOOK BOLT
42-15210-99	HOOK BOLT, BACK
42-15211-99	HOOK BOLT, FRONT LARGE HEAD
42-15212-ZZ	HOOK BOLT, FRONT
42-15213-99	HOOK BOLT, FRONT
42-15214-99	HOOK BOLT
42-15216-99	CHUCK LEVER
42-15217-99	CHANGE GEAR,29 TEETH
42-15218-99	CHANGE GEAR,71 TEETH
42-15270-99	CHUCK ADJUSTING NUT
42-15271	CHANGE GEAR,28 TEETH
42-15272	CHANGE GEAR,67 TEETH
42-15273	CHANGE GEAR,31 TEETH
42-15274	CHANGE GEAR,64 TEETH
42-15275	CHANGE GEAR,35 TEETH
42-15276	CHANGE GEAR,60 TEETH
42-15276-ZZ	CHANGE GEAR
42-15277	CHANGE GEAR,39 TEETH
42-15278	CHANGE GEAR,56 TEETH
42-15279	CHANGE GEAR,42 TEETH
42-15279-ZZ	CHANGE GEAR 24 TH, SECOND
42-15280	CHANGE GEAR,53 TEETH
42-15281	CHANGE GEAR,46 TEETH
42-15281-ZZ	CHANGE GEAR 32 TEETH
42-15282	CHANGE GEAR,49 TEETH
42-15287-99	FRONT BOX
42-15288-99	SPINDLE FRONT BOX
42-15289-A	CROSS SLIDE ADJ.SCREW ONLY
42-15300	STOCK HOOK
42-15301-99	DOG, TRIP, LEFT W/T-BOLT &NUT
42-15301-NF	DOG, TRIP, LEFT, W/O T-BOLT
42-15302-99	DOG, TRIP, RIGHT WITH T-BOLT
42-15302-NF	DOG, TRIP, RIGHT, W/O T-BOLT
42-15303-99	DOG, TRIP, RIGHT WITH T-BOLT
42-15303-NF	DOG, TRIP, RIGHT, NO T-BOLT
42-15304-99	DOG, TRIP, LEFT WITH T-BOLT
42-15304-NF	DOG, TRIP, LEFT, NO T-BOLT

PART #	DESCRIPTION
42-15437	CHANGE GEAR,22 TEETH
42-15438	CHANGE GEAR,25 TEETH
42-15441	CHANGE GEAR,73 TEETH
42-15442	CHANGE GEAR,70 TEETH
42-15444-1-99	SPROCKET,LEFT
42-15444-99	SPINDLE SPROCKET
42-15444-NF	SPROCKET, NO BUSHING
42-15445	SPIN SPROCKET L
42-15445-1	SPINDLE SPROCKET LEFT
42-15446	SPINDLE PULLEY LEFT
42-15452-1-99	SPROCKET RIGHT
42-15452-99	SPIN SPROCKET-R
42-15458-99	DOG, DEFLECTOR
42-15459-99	DOG, DEFLECTOR
42-15460-99	DOG, DEFLECTOR
42-15461-99	DOG, DEFLECTOR
42-15462-99	DOG, DEFLECTOR
42-15511-99	FEED TUBE, COMPLETE 5/16 #00G
42-15513-1-99	ARM BASE
42-15516	BRACKET BUSHING
42-15527-2-99	SPINDLE LABYRINTH, GRAPHITE
42-15527-3	WASHER, GRAPHITE LABRYRINTH
42-15527-3K	KIT, LABRYNTH WASHER & SPRING
42-15539	LEVER, OPER RACK
42-15572-99	SPROCKET BUSHING
42-15583	DEFLECTOR CUSHION
42-15584	DEFLECTOR CUSHION
42-15587	SLEEVE, TURRET DISK DRIVE
42-15600-1-99	CHUCK FORK SLEEVE, INNER
42-15601	CHUCK FORK SLEEVE, INNER
42-15602-1	CHUCK FORK SLEEVE, INNER
42-15603-1	CHUCK FORK SLEEVE, INNER
42-15608	CHUCK FORK SLEEVE, INNER
42-15620	TURRET DISK DRIVE SLEEVE
42-15621	SLEEVE
42-15645	FEED ROD KNOB
42-15653-3-99	SHANK

PART #	DESCRIPTION
42-15655-2	SHAFT HOUSING
42-15656-1	CUTTER ARBOR SUPPORT
42-15658-2	SHAFT GEAR
42-15661-3-99	CUTTER ARBOR
42-15662-1	COVER
42-15663-1	GEAR GUARD
42-15665	DRIVEN SHAFT
42-15669-3-99	CUTTER ARBOR DRVNG SHFT GR
42-15670-3	GEAR,CUTTER ARBOR
42-15673-1	GEAR GD
42-15674-3	SHANK
42-15675-1	DRIVEN SHAFT
42-15676-3	SHAFT HOUSING
42-15677-2	ARBOR SUPPORT
42-15678-1	SHAFT
42-15679-2	SHAFT GEAR
42-15680	GEAR
42-15680-3	GEAR,CUTTER ARBOR
42-15681-2	CUTTER ARBOR
42-15682-2	COVER
42-15683-1	GEAR GUARD
42-15710	SPIDER ARM
42-15718-99	FULCRUM
42-15758-99	SPROCKET
42-15770	OIL SEAL
42-15802	WASHER
42-15813-4-ZZ	SHAFT
42-15828	NUT, FRONT BOX
42-15830-1	NUT
42-15832	TOOL POST CLAMP BOLT COMPLETE
42-15860-99	CLAMP NUT
42-15864	GEAR,32T DRIVING
42-15864-2	MOTOR PULLEY
42-15865-2-99	PULLEY
42-15865-99	DRIVEN GEAR
42-15867-2-99	PULLEY
42-15868-2-99	MOTOR PULLEY

PART #	DESCRIPTION
42-15868-3-99	PULLEY
42-15869-2-99	PULLEY
42-15870	MOTOR PLATE
42-15876	SHAFT
42-15888	BUSHING
42-15889-99	BUSHING
42-15890	BUSHING FRONT
42-15908	INSTRUCTION PLATE
42-15916	WASHER SPRING
42-15922-99	BUSHING
42-15966-1	SUPPORT REST
42-15968-1	PUMP GEAR
42-15972-1	HOLDING SCREW
42-15973	ADJUSTMENT SCREW
42-15977-1	INTERMEDIATE DRIVE SHAFT
42-15982	PLUNGER BODY
42-15987	CABLE&PLUG
42-15991	ADJ SCREW
42-15995-1	PIN HANDLE
42-15997-1	MOTOR SPROCKET
42-16001-99	INTERMEDIATE GEAR SHAFT
42-16002-99	SPROCKET,INTER
42-16003-99	OIL SLINGER
42-16004-99	OIL SLINGER
42-16007	RETAINER
42-16009-99	CHAGE GEAR SHAFT
42-16012	DRIVE SPROCKET
42-16013	SHAFT WASHER
42-16014	SHAFT GEAR
42-16014-ZZ	SHAFT GEAR
42-16016-99	SHAFT,CHANGE
42-16017-99	RATIO CHNG GR SHFT SPCR
42-16018	INTERMEDIATE GEAR
42-16019	INTERMEDIATE GEAR
42-16020-99	SPINDLE DRIVE SHAFT,SLOW
42-16023-99	SPROCKET
42-16026	SHAFT IDLER

PART #	DESCRIPTION
42-16027	SHAFT IDLER
42-16028	DRIVE CLUTCH SHAFT ARM
42-16031-2	COVER SPEED CASE
42-16032	COVER GASKET,COVER
42-16032-1	COVER GASKET,NEOPRENE
42-16033	SPEED CASE GASKET
42-16051	CLIP
42-16053-3	HOUSING,OIL SEAL
42-16054-1	RETAINER GUARD
42-16055-1	GASKET
42-16057	SEAL,OIL
42-16058-5	BRACKET,MOTOR
42-16067-99	WORK PAN
42-16068-1	COVER
42-16069-1	GASKET
42-16070-1-99	OIL STRAINER
42-16070-2	COOLANT STRAINER
42-16075	SPROCKET ARM
42-16076	SPROCKET STUD
42-16078-1	SHAFT
42-16080	SPROCKET ARM
42-16083	ROD,ADJUSTMENT
42-16085	LOCK,ADJUSTING ROD
42-16087	FULCRUM
42-16088	STOP SHAFT LINK FRONT
42-16088-1	STOP LINK
42-16089-1	SHAFT LINK
42-16106-1	SPACER
42-16123	SHAFT BUSHING
42-16125	WASHER
42-16138	LEVER DETENT
42-16138-1-99	PLUNGER,CHUCK &FEED CAM
42-16138-2-99	PLUNGER,CHUCK &FEED CAM
42-16158	FORK FULCRUM
42-16160	CAP, FEED LEVER
42-16161-1-99	FULCRUM,FEED LEVER
42-16161-99	FULCRUM,FEED LEVER

PART #	DESCRIPTION
42-16172-1	STOCK STOP SHAFT
42-16172-3	STOP SHAFT
42-16172-4	SHAFT
42-16173-1-99	SHAFT LINK
42-16173-2	SHAFT LINK
42-16174-3	LEVER
42-16179-1	LEVER LINK
42-16185-1	BRACKET
42-16190	DOOR
42-16195-1	GUARD HINGE
42-16196	CATCH BLOCK COM
42-16197	CATCH BLOCK
42-16198	CATCH PLATE
42-16199	IDLER
42-16200	SLEEVE
42-16202	CHANGE GEAR,20 TEETH
42-16203	CHANGE GEAR,25 TEETH
42-16205	CHANGE GEAR,35 TEETH
42-16206	CHANGE GEAR,40 TEETH
42-16207	CHANGE GEAR,45 TEETH
42-16208	CHANGE GEAR,50 TEETH
42-16208-2	CHANGE GEAR,44 TEETH
42-16209	CHANGE GEAR,55 TEETH
42-16210	CHANGE GEAR,60 TEETH
42-16211	CHANGE GEAR,65 TEETH
42-16212	CHANGE GEAR,80 TEETH
42-16213	CHANGE GEAR,100 TEETH
42-16226-1	SHAFT
42-16226-1-ZZ	SHAFT
42-16227	SPACER
42-16229	SPACER
42-16230	CAM SHAFT WORM WHEEL
42-16230-2	WORM WHEEL
42-16230-2-ZZ	WORM WHEEL
42-16232	NUT
42-16232-1	NUT
42-16233	LEAD CAM SHAFT COLLAR

PART #	DESCRIPTION
42-16233-1	COLLAR
42-16234-1	LEAD CAM HOLDER
42-16235	NUT
42-16236	SHAFT
42-16239	GEAR,LEAD WORMSHAFT DRIVE
42-16240	GEAR,LEAD WORM SHAFT
42-16241	BUSHING, LEAD CAM SHAFT
42-16242	SHAFT
42-16243	GEAR,WORM SHAFT
42-16244	COLLAR
42-16245	BUSHING
42-16247-1	FRONT CAM SHAFT
42-16247-2	SHAFT
42-16248	WASHER, CAM SHAFT
42-16249-1	CARRIER
42-16250	CAM SHAFT SPACER
42-16250-1	SPACER
42-16251-1	WASHER
42-16254-2	COLLAR
42-16255-1	SHAFT, RIGHT FRONT
42-16255-3	SHAFT
42-16256	RETAINER
42-16258	FULCRUM
42-16260-1	LEVER
42-16261	SPACER
42-16263-1	COVER
42-16272	FULCRUM
42-16273-3	CLUTCH FORK
42-16276-2	LEVER
42-16277-1	CLUTCH FORK PIN
42-16278-5	LEVER
42-16281	GROMMET
42-16282-3	DRIVE SHFT BRCKT RGHT
42-16283	SHAFT
42-16284-1	CHUCK GEAR ARM
42-16285-1	FULCRUM,CHANGE GEAR ARM
42-16287-2	DRIVING GEAR & CLUTCH

PART #	DESCRIPTION
42-16288	DRIVING CLUTCH
42-16289	REVERSING CLUTCH
42-16290	REVERSING CAM
42-16291	CHUCK GEAR STUD
42-16292	BUSHING,CHANGE GEAR
42-16296-1	TURRET INTER GEAR DRIVEN
42-16296-2-99	TURRET INTER GEAR
42-16296-99	DRIVEN GEAR
42-16298-1	REVERSING LEVER
42-16299-1	LEVER LINK
42-16300-3	CLUTCH SHAFT
42-16301	BUSHING
42-16302-1	SHAFT COLLAR
42-16304-1	SAFETY CLUTCH
42-16305-2	CLUTCH GEAR
42-16314-2	TRAY,TOOL
42-16316-1	SLIDE
42-16317-2	SLIDE
42-16318-1	RACK, CROSS SLIDE
42-16318-99	CROSS SL RACK
42-16319-2	DIAL
42-16320	GIB, CROSS SLIDE FRONT
42-16321	GIB, CROSS SLIDE BACK
42-16322-1	GUARD
42-16323-3	GUARD
42-16324-2	GUARD
42-16325-1	WIPER
42-16326	WAYS
42-16328	LEVER
42-16329-1	LEVER
42-16330	FULCRUM
42-16332	FULCRUM
42-16333	SLIDE WAYS
42-16335	KEY
42-16336-1	CASE
42-16336-99	CUSHION CASE
42-16338-99	CASE SCREW

PART #	DESCRIPTION
42-16339-2-99	SPRING PLUNGER
42-16339-3	PLUNGER, SPRING
42-16340-2-99	PIN, TURRT.SLIDE SPRING PLUNGER
42-16340-3	PIN, TURRT.SLIDE SPRING PLUNGER
42-16341-1	LEVER
42-16342	FULCRUM
42-16343-3-99	TURRET SLIDE
42-16345	BUSHING
42-16346-3	OIL RESERVOIR
42-16346-3-ZZ	OIL RESERVOIR
42-16350	GIB, TURRET SLIDE
42-16351-1-99	RACK, TURRET SLIDE
42-16352-3-99	ROD BAR
42-16352-3-S	THREADED BAR, FOR REPAIR
42-16357	SHAFT
42-16358	GEAR, TURRET SHAFT ADJUST
42-16359	FULCRUM
42-16360	PIN, LOCKING
42-16361	PIN SLEEVE
42-16362-2-99	TURRET, 6 HOLE
42-16362-2-ZZ	TURRET, 6 HOLE
42-16362-3	TURRET, 6 HOLE
42-16363-99	LOCKING BUSH, TURRET
42-16363-A	LOCKING PIN, TURRET O/S .005
42-16364	DRIVING SLEEVE
42-16364-1	DRIVING SLEEVE
42-16365	WASHER
42-16366	WASHER
42-16366-1	FITTING WASHER
42-16370-2	SLIDE LEVER
42-16371-1	LEVER FULCRUM
42-16372-1	DEFLECTOR
42-16372-1-NF	DEFLECTOR PAN
42-16373-1	DEFLECTOR ARM & HUB
42-16374	DEFLECTOR ARM
42-16376	FULCRUM
42-16377	FULCRUM

PART #	DESCRIPTION
42-16378	DOG, DEFLECTOR
42-16379	DOG, DEFLECTOR
42-16380	DOG, DEFLECTOR
42-16383	FEED ADJ SCREW
42-16384	CAM BUSHING
42-16385	PLUNGER SLEEVE
42-16386	SLEEVE NUT
42-16391-3	SLIDE WAYS
42-16392-3	VERTICAL SLIDE
42-16393	OPERATING PLATE
42-16393-1	PLATE
42-16394-2	VERT.TOOL HLDR./UP TO R/S
42-16394-3	TOOL HOLDER
42-16395	TOOL WEDGE
42-16397-1	TOOL WEDGE CAM
42-16398-1	CAM BUSHING
42-16399	SWIVEL STOP
42-16400-1	OPERATING SHAFT
42-16401-1	LEVER
42-16403	SLIDE LEVER COMPLETE
42-16403-NF	SLIDE LEVER
42-16404	PIN LEVER
42-16406-1	OIL PIPE INTAKE
42-16409-5	SPINDLE 1/2"
42-16409-5-ZZ	SPINDLE 1/2" CAP.
42-16410-1	FRONT BOX
42-16411	NUT,SPINDLE BOX
42-16413	SPROCKET,SPINDLE LEFT
42-16413-1	SPINDLE SPROCKET
42-16415-3-99	CLUTCH BODY,#00 1/2"
42-16415-4	SPINDLE CLUTCH, 00B
42-16417	RING, CLUTCH BODY
42-16418-1	SPROCKET LEFT,SPINDLE
42-16418-2	SPROCKET
42-16419	SPINDLE REAR BOX
42-16419-ZZ	SPINDLE REAR BOX
42-16420	RETAINER NUT

PART #	DESCRIPTION
42-16421-1	SPACER
42-16422	SPINDLE NUT
42-16423	FRICTION DISC
42-16424	FRICTION DISC
42-16425	DISK, FRICTION 1/2" CAP
42-16427-99	SHOE, CHUCK LEVER FULCRUM
42-16428-1	NUT, CHUCK ADJUSTING
42-16429-1	FEED TUBE, COMPLETE 1/2" CAP
42-16430-1	FEED TUBE, 1/2"
42-16431	TUBE COLLAR
42-16433	FEED TUBE NUT
42-16434	ADJUSTING NUT
42-16435-99	CHUCK NUT
42-16436	BUSHING
42-16439-1	BUSHING
42-16440-1	SHAFT, SLOTTING ATTCH.
42-16441-1	SHAFT GEAR
42-16443	FULCRUM BRACKET
42-16445-1	ROTATING LEVER
42-16446-1	CAM LEVER, ROTATING
42-16447-1	LEVER SLOTTING
42-16448	LEVER FULCRUM
42-16449	SLOTTING LEVER
42-16449-1	SLOTTING LEVER
42-16450	LEVER PLATE
42-16452	YOKE, BRAKE 1/2" CAP
42-16453-1	YOKE FULCRUM
42-16454	YOKE FULCRUM
42-16455	OPERATING LEVER
42-16456	SPINDLE BRAKE LINK
42-16457-1	LEVER FULCRUM
42-16458	SHIM
42-16459	SEAL, OIL
42-16460	SEAL, OIL
42-16461	SEAL, OIL
42-16464	OIL GUARD WINDOW
42-16478-2	GUARD

PART #	DESCRIPTION
42-16483	SPINDLE SPEED PLATE
42-16485-1	SPIN. CHAIN GUARD
42-16486	SPROCKET GUARD
42-16488-1	OIL GUARD
42-16489-3	GUARD
42-16490-1	GUARD
42-16497-1	WASHER
42-16505	OIL COMPRESSION SLEEVE
42-16511	CHANGE GEAR,19 TEETH
42-16512	CHANGE GEAR,76 TEETH
42-16513	SPRING PLUNGER
42-16516	SHAFT BUSHING
42-16518-3	CHUCK FEED CAM
42-16519-3-99	CAM GEAR
42-16519-99	CAM GEAR
42-16522-2	BUSHING, DRIVING SHAFT
42-16523-1	CLUTCH & GEAR,CHUCK & FEED
42-16523-1-ZZ	CHUCK & FEED CLUTCH & GEAR
42-16523-99	CLUTCH,CHUCK & FEED
42-16524	WASHER
42-16525	SLIDING CLUTCH
42-16526-1	INSERT, CHUCK & FEED CLUTCH
42-16528-3	CHUCK & FEED DRIVING SLEEVE
42-16529	BUSHING
42-16530-1-99	DRIVING SHAFT
42-16530-2-99	SHAFT,LEFT
42-16530-4	DRIVING SHAFT
42-16531-1-99	GEAR SHAFT
42-16531-3-99	SHAFT
42-16531-3-ZZ	SHAFT
42-16531-4-99	SHAFT,CHANGE GEAR
42-16531-5-99	GEAR SHAFT
42-16531-6	GEAR SHAFT
42-16533	SPACER
42-16534-99	GEAR, DRIVE CHANGE
42-16535-99	SHAFT LEFT
42-16537	BUSHING

PART #	DESCRIPTION
42-16542-1	SHAFT SPROCKET
42-16544-1-99	DRIVING CLUTCH GEAR SHOE
42-16546-1-99	FULCRUM,CHUCK TRIP LEVER
42-16546-2	LEVER FULCRUM
42-16548-1	DISK LEVER
42-16549-1-99	TRIP LEVER
42-16559	BUSHING, FEED SLIDE
42-16560-3	FEED SLIDE
42-16561	ADJUSTMENT SLEEVE
42-16561-1	ADJUSTMENT SLEEVE
42-16562	BRACKET
42-16563	BRACKET BUSHING
42-16564	ROD BAR WAY
42-16565	SLIDE GUIDE
42-16571-2	FEED LEVER
42-16571-2-NF	FEED LEVER ONLY, NO KNOB ETC.
42-16572-2	CHUCK FORK
42-16573	LEVER FULCRUM
42-16573-1	CAM LEVER
42-16574	CAM LEVER
42-16574-1	LEVER, CAM
42-16576-1-99	CHANGE GEAR,62 TEETH
42-16576-2	CHANGE GEAR,62 TEETH
42-16576-99	CHANGE GEAR,70 TEETH
42-16581	LEVER STUD
42-16582-99	LUB ECCENTRIC
42-16587	CLAMP SCREW
42-16589-1	BUSHING
42-16596-1	BRACKET
42-16598	GUARD CLAMP
42-16599-2-99	SPACER
42-16600-1	SPACER
42-16601	SPRING RETAINER
42-16602	SPINDLE KEY
42-16605-1	THRUST NUT
42-16606	CLUTCH RING PIN
42-16610-1	HOLDER,CAM

PART #	DESCRIPTION
42-16614-1	HANDWHEEL CLUTCH
42-16614-99	CLUTCH, HANDWHEEL SHAFT
42-16615	CLUTCH SPRING
42-16616-1	PIN,DRIVE SHAFT WHEEL CLUTCH
42-16622-1	GASKET
42-16624-3-99	SPRING SUPPORT
42-16625	HANDWHEEL BRACKET **
42-16627	LINK
42-16628	LEVER
42-16629-2	CLUTCH SHAFT
42-16631-1	BUSHING
42-16632	HANDWHEEL LEVER
42-16633	LEVER HANDLE
42-16634	LEVER FULCRUM
42-16635-1	FULCRUM DOG
42-16636-1	SUPPORT WASHER
42-16637-1	INSERT, REV. CLUTCH
42-16639	SHAFT COLLAR
42-16641-2	TRAY,TOOL
42-16642-1	STOP LEVER
42-16643	SEAL
42-16645-1	CLAMP STUD
42-16646	LEVER FULCRUM
42-16647-1	PLUNGER
42-16647-99	PLUNGER
42-16648-3	GEAR SHAFT
42-16649-3	LEVER ABUTMENT
42-16650	CAM LEVER
42-16651-1-99	INDEX LEVER
42-16651-2	INDEX LEVER
42-16652-1	SPACER
42-16652-2-99	SPACER
42-16655-3-99	ROLL DISC
42-16655-4	ROLL DISC FOR 642-49-00
42-16655-5	ROLL DISK
42-16656-A	TURRET CHANGE GEAR, OVER .010
42-16656-B	TURRET CHANGE GEAR, OVER .020

PART #	DESCRIPTION
42-16658	TURRET DISK
42-16658-1	DISC, TURRET
42-16659	ROCKER LEVER
42-16661-1	LEVER FULCRUM
42-16663	RETAINER
42-16684-2	HOLDER,OIL TUBE
42-16686-2	LEVER STUD
42-16687	ADJUSTMENT SCREW
42-16688	SPACER
42-16691-1	OIL TUBE,COMPL. STRT. FITTING
42-16692-99	CHANGE SHAFT
42-16693-4	SHAFT
42-16693-99	TURRET CHANGE SHAFT
42-16697	BUSHING
42-16698-2-99	FRONT CAM SHAFT COUPLING
42-16699	NUT, SHAFT
42-16700-1	CARRIER
42-16703	RETAINER
42-16707	PLUG
42-16707-1	PLUG BASE DRAIN
42-16708	BUSHING
42-16711	SPACER
42-16714-1	PLATE
42-16715	ADAPTER,LATCH
42-16717-2	GUARD
42-16720	DOWEL
42-16726	HOLDER BUSHING
42-16728	ROD
42-16729	BRACKET, PLEXY GUARD
42-16731	NUT,CLUTCH OPER SCREW
42-16735	SPACER
42-16738-1	SPACER
42-16740-1	SEAL
42-16742-2	BUSHING
42-16744	WASHER
42-16750-1	LUBRICATOR TUBE
42-16752	RETAINER PIN

PART #	DESCRIPTION
42-16753-1	SPACER
42-16754	NUT SLOTTING
42-16755	SPRING
42-16756-2	TURRET, 8 HOLE #00
42-16759-2-99	CLUTCH GUARD
42-16764	SCREW BLOCK
42-16765	DRIVING CLUTCH HOUSING PLATE
42-16767	WASHER
42-16769	BLOCK
42-16774-2-99	TRIP LEVER STOP SCREW
42-16780-1	GUARD
42-16784-99	COUPLING CLAMP
42-16785	LEVER PIN
42-16789-1	SET OF 2 TIMING CAMS
42-16793	TURRET SLD PLNGR SCRW
42-16794	GASKET
42-16795-99	TURRET CSHN CS WSHR
42-16796-1	SEAL
42-16798-1	DISK
42-16799	CLAMP BUSHING
42-16800	CLAMP BUSHING
42-16803-1-99	WASHER
42-16808	WASHER
42-16815	CAM, DUMMY
42-16816-1	DISK
42-16822	STUD,STOP SPRING,RIGHT
42-16822-1	STUD
42-16823-3	STUD
42-16824	COLLAR,SAFETY CLUTCH GEAR
42-16828	HOOK,STOCK
42-16830	ROLL STUD
42-16831	ROLL, CAM
42-16833	LEVER FULCRUM
42-16834	CLAMP BUSHING
42-16846	SEGMENT
42-16847-99	RETAINING SPR FTTNG WSH
42-16848	RETAINING SPRNG FT WSH

PART #	DESCRIPTION
42-16849	RETAINING SPRNG FTTNG WSH
42-16851-99	CHUCK NUT
42-16856	LOCK WASHER
42-16858	ADJUSTMENT SCREW
42-16859	ADJUSTMENT SCREW
42-16865	SPRING PLUNGER
42-16879	PIN
42-16884-99	CLAMP BUSHING
42-16885	CLAMP BUSHING
42-16888	SCREW
42-16890	PIN
42-16891	HOLDER, STOP
42-16892	RACK
42-16895	SPACER
42-16901	SHAFT BUSHING
42-16902	ROLL PIN
42-16929-1-99	AUTO STOP LEVER
42-16929-2	LEVER
42-16930	ROLLER
42-16930-1	SHOE, LEVER
42-16931-2	LEVER
42-16932-4	ECCENTRIC
42-16935-1-99	ROLL, OPERATING LEVER SHAFT
42-16960-1	GASKET
42-16966	GEAR
42-16967	SPACER
42-16969-1	OPERATING SCREW
42-16969-1-B	CLUTCH OPERATING SCREW W/NUT
42-16971-1	COVER
42-16973-99	GIB, FRONT-OVERSIZE
42-16973-ZZ	GIB, FRONT-OVERSIZE
42-16974-99	GIB, BACK-OVERSIZE
42-16978-1	COUNTER SUPPORT
42-16980-1	CHANGE GEAR SHAFT GEAR
42-16980-2	GEAR, INTERMEDIATE
42-16981-1	GEAR, INTERMEDIATE DRIVE
42-16982-1-99	RETAINER

PART #	DESCRIPTION
42-16983-2	C-WASHER, CHANGE GEAR
42-16984	STUD, CHANGE GEAR
42-16985	BOLT, CLAMP
42-16986	CLAMP, MOTOR
42-16988	SPROCKET
42-16989	SPROCKET DRIVER
42-16990	GASKET
42-16991	CAP, GUARD
42-16992-1	LUBRICATOR SHAFT
42-16992-2	INTER.LUB.SHAFT
42-16993-2-99	SHAFT SPROCKET
42-16993-3-99	SHAFT SPROCKET
42-16993-4	SHAFT SPROCKET
42-16994-3-99	DRIVING SHAFT
42-16994-4	DRIVING SHAFT
42-16997-3	SPROCKET
42-17004	COVER GASKET
42-17005	HOUSING COVER
42-17006-1	SWITCH, MOUNTING PLATE
42-17007	GASKET
42-17013-1	SPROCKET
42-17020-1	IDLER SPROCKET, RIGHT
42-17022	SPACER
42-17023	ROD, ADJUSTMENT
42-17025	RETAINER
42-17033	EXTENSION, PLUNGER
42-17034	SHIM
42-17040	SCREW ADJUSTING STOP
42-17040-1-99	SCREW ADJUST STOP
42-17050-99	SPINDLE SPROCKET
42-17051	SHAFT SPROCKET
42-17055-1	CLAMP SCREW
42-17056-2	VERTICAL SLIDE
42-17056-4	UPPER SLIDE, REAR
42-17057	GIB, UPPER SLIDE
42-17057-2	GIB
42-17058-1	TOOLHOLDER

PART #	DESCRIPTION
42-17058-2-99	TOOL HOLDER
42-17058-2-ZZ	TOOL HOLDER
42-17058-4	TOOL HOLDER,FORWARD TURN.
42-17059-1	TOOL WEDGE
42-17059-2	TOOL WEDGE
42-17059-99	TOOL WEDGE
42-17062-3	OPERATING SHAFT
42-17064-1	ROLL STUD
42-17064-99	SLIDE OPRTNG SHFT RLL STD
42-17065-1	LEVER ROLL
42-17065-99	ROLL
42-17067-1	LEVER STUD
42-17068	SHEAR PIN LEVER
42-17068-1	LEVER, VERT. SLIDE
42-17069	BLOCK, VERTICAL SLIDE LINK
42-17069-1	CONNECTING BLOCK
42-17069-2	CONNECTNG BLOCK
42-17069-3	LEVER LINK CONNECT BLOCK
42-17069-3-NF	LEVER LINK BLOCK
42-17070-1	SLIDE LEVER LINK ADJ SCREW
42-17070-99	ADJUSTMENT SCREW
42-17071	LINK, VERTICAL SLIDE LEVER
42-17071-1	LEVER LINK
42-17071-2	LEVER LINK
42-17071-3	LEVER LINK
42-17082	OIL GUARD WINDOW
42-17086-3	END GUAR
42-17102-1	SWING STOP SHAFT FRT BUSH
42-17102-2	SHAFT FRONT BUSHING
42-17105	BUSHING LEFT, WORM SHAFT
42-17106	BUSHING
42-17108-99	CAM SHAFT
42-17109-1	SHAFT NUT
42-17111-1	CAM HOLDER, LEAD CAM
42-17111-2	HOLDER LEAD CAM
42-17112	RETAINER
42-17113	RETAINER

PART #	DESCRIPTION
42-17114	SPACER
42-17116-99	WORM WHEEL
42-17118	SPACER
42-17119	RETAINER
42-17121-1	SHAFT
42-17122	GASKET
42-17123	LEAD WORM DRIVING GEAR
42-17126-99	CAM SHAFT
42-17127-1	CARRIER,DOG
42-17128	RETAINER
42-17130-1	SPACER
42-17132-1-99	FRONT CAMSHAFT COLLAR
42-17133-1	FR. CAM SHAFT LEFT NUT
42-17133-2	NUT,CAM SHAFT
42-17135-1	FRONT CAM SHAFT COUPLING
42-17137-99	DOG, DEFLECTOR
42-17138-99	DOG DEFLECTOR
42-17141-99	PIVOT PIN
42-17143-99	TRIP LEVER SPACER
42-17145	DOG SHAFT
42-17146-1	FULCRUM,FORK
42-17148	PIN,LINK
42-17149	LEVER LINK
42-17150	BOLT,EYE
42-17151-1	FORK,CLUTCH
42-17152	PIN
42-17153-99	DEFLECTOR
42-17157	DEFLECTOR ARM
42-17158-1	CUSHION
42-17159-99	FULCRUM
42-17160-99	FULCRUM, DEFLECTOR ARM
42-17165-2	PLATE
42-17167-2-99	SHAFT,WITHDRAWAL CAM
42-17170	WITHDRAWAL CM 1/2 SCND
42-17171-99	SPACER
42-17172-2-99	SPACER, WITHDRAW SHAFT
42-17173	CAP,DUST

PART #	DESCRIPTION
42-17175-99	CAM SHAFT GEAR
42-17176-1	TURRET TRIP LEVER
42-17178-99	STUD,TIMING LEVER
42-17181-99	LEAD CAM LEVER
42-17182	LINK,CONNECTING
42-17183-4	LEVER
42-17184-1	PIN,CLEVIS
42-17184-2	PIN,CLEVIS
42-17185	PIN, LEAD CAM ROLL
42-17185-1	ROLLER PIN
42-17186-99	LEAD CAM LEVER FULCRUM
42-17187-1-99	PIVOT PIN
42-17187-2	PIN,PIVOT
42-17188	ROLL, CAM
42-17189	PIVOT BUSHING
42-17189-1	BUSHING
42-17189-ZZ	BUSHING, SECOND QUALITY
42-17195-99	SWING STOP LEVER PIN
42-17198	WITHDRAWAL CAM SAFETY PIN
42-17199	TURRET SLIDE LEVER
42-17210-1-99	SLIDE PLUNGER PIN
42-17218-99	TURRET GEAR
42-17220	BUSHING
42-17221	WASHER
42-17223-2-99	TURRET, 6 HOLE #2
42-17225-99	WASHER
42-17227-1	WASHER
42-17228-1	WASHER
42-17229	GIB TURRET SLIDE
42-17230-1-99	SLIDE RACK
42-17231	COVER
42-17232-1	PIN,LOCKING
42-17234	LOCKING BUSH, TURRET
42-17234-ZZ	BUSHING, TURRET LOCK
42-17235	LOCKING SLEEVE
42-17236	SLEEVE
42-17237-99	STUD,LOCK PIN LEVER

PART #	DESCRIPTION
42-17238-1-99	LOCK PIN LEVER
42-17239-1	PIVOT, LOCKING PIN LEVER
42-17239-3	PIN
42-17242	ROLLER, LOCKPIN LEVER
42-17243-2	PUSHROD PIN
42-17246	KEY, SLIDE WAY
42-17251	BUSHING
42-17252	BUSHING
42-17255-1-99	DRIVING SHAFT, RIGHT
42-17256	DRIVE SHAFT WASHER
42-17260-1-K	CLUTCH, SAME AS 42-20010-2
42-17261-1	CLUTCH, DRIVING
42-17261-99	CLUTCH, DRIVING
42-17262-99	REVERSING CLUTCH
42-17264	BUSHING
42-17265-99	DRIVING SHAFT WASHER LEFT
42-17275-2-99	CLUTCH SHAFT
42-17276-1-99	SHAFT BUSHING
42-17276-99	BUSHING
42-17277-1	SAFETY CLUTCH GEAR
42-17278-99	TURRET INTER GEAR SHAFT
42-17282-1-99	TURRET GEAR
42-17287	INT. WITHDRAWAL CAM SHAFT
42-17291	SPRING PLUNGER
42-17292	SPRING SCREW
42-17298-99	STOP LEVER
42-17299-1-99	STOP LEVER PIVOT PIN
42-17302-99	STOPPING SCREW
42-17305	CLUTCH PIN
42-17306	CLUTCH PIN
42-17310	CLUTCH INSERT
42-17324-2-99	TURRETOOL GUARD
42-17325-1-99	SPINDLE, 3/4" CAPACITY, #2
42-17326-2-99	FRONT BOX
42-17327	NUT
42-17328-1	NUT
42-17329	SPACER

PART #	DESCRIPTION
42-17331	FRONT BOX NUT LOCK RING
42-17333-99	THRUST NUT
42-17336	SPINDLE KEY
42-17337-1-99	CLUTCH BODY,#2 AUTO 3/4"
42-17337-1-ZZ	CLUTCH, RE-BUILT
42-17340-1	SLEEVE RING
42-17344	KEY,SPINDLE REAR BRG.SPACER
42-17345	SPINDLE REAR BOX
42-17345-1	SPINDLE REAR BOX
42-17346	SPINDLE RR BRNG RT NT
42-17346-1	RETAINER NUT
42-17347	SPINDLE NUT
42-17348-1	FULCRUM SHOE
42-17349	CHUCK FORK SLEEVE, COMPLETE
42-17349-K	KIT,CHUCK FORK SLV,3/4"
42-17350	CHUCK FORK SLEEVE, INNER
42-17351-1	CHUCK,ADJUSTING NUT
42-17352-3	FEED TUBE, 3/4"
42-17353	FEED TUBE SPACER 3/4 CAP.
42-17354	ADAPTER
42-17355	ADJUSTMENT NUT
42-17356	CLOSING TUBE
42-17356-ZZ	CLOSING TUBE, NOT 1ST QUALITY
42-17357	WASHER, GRAPHITE
42-17358-1	SPINDLE NOSE OIL GUARD
42-17358-99	SPINDLE NOSE OIL GUARD
42-17359	CHUCK NUT
42-17361	DISK,FRICTION (3/4")
42-17364-1	SPACER
42-17364-99	SPACER
42-17365	DISK,FRICTION (3/4")
42-17366	DISK,FRICTION (1-1/4 OR 1-5/8)
42-17367-1	DISK,FRICTION (1-5/8")
42-17369	DRIVING COLLAR
42-17375-1-99	SPINDLE,1 1/2"CAPACITY
42-17377-99	BEARING, FRONT BOX CYLINDRICAL
42-17377-B	BEARING, LONG ROLL

PART #	DESCRIPTION
42-17378	RING
42-17379-2	FRONT BOX
42-17380	BOX LINER
42-17381-99	NUT, SPINDLE SPROCKET
42-17385-1-99	CLUTCH BODY,#2 AUTO 1 1/2"
42-17387	CLUTCH SLEEVE
42-17389-99	SPRING RETAINER
42-17390-99	RETAINER NUT
42-17392	SPINDLE REAR BOX
42-17392-1	SPINDLE REAR BOX
42-17393	SPACER KEY
42-17394	RETAINER NUT
42-17395	SPINDLE NUT
42-17396-99	CHUCK ADJUSTING NUT 1 1/2 CP
42-17397-99	LEVER FULCRUM
42-17398-1-99	FULCRUM SHOE
42-17399-99	CHUCK CLOSING TUBE
42-17401-99	BEARING, FRONT BOX CYLINDRICAL
42-17401-B	BEARING, F BOX WITH LONG ROLL
42-17402	CAGE RING
42-17404-99	LINER, FRONT BOX
42-17405	FRONT BOX NUT
42-17406-2	FRONT BOX NUT
42-17407-99	NUT, SPROCKET THRUST
42-17408	SPROCKET SPACER
42-17409-99	SPIN SPROCKET-R
42-17410-99	SPINDLE SPROCKET LEFT
42-17411-1-99	CLUTCH BODY,#2 AUTO 1 1/4"
42-17412-1-99	BLANK, CLUTCH BODY
42-17413	CLUTCH BODY RING
42-17416	CLUTCH SLEEVE
42-17418	RING, CLUTCH SLEEVE
42-17419	SPINDLE KEY
42-17424	SPINDLE REAR BOX
42-17425	SPACER KEY
42-17426	REAR BOX NUT
42-17427	RETAINER NUT

PART #	DESCRIPTION
42-17428-1	CHUCK ADJUSTING NUT
42-17429	LEVER FULCRUM
42-17430-1	SHOE,CHUCK LEVER FULCRUM
42-17431	CLOSING TUBE
42-17431-ZZ	CLOSING TUBE, 2ND QUALITY
42-17432	CHUCK FORK SLEEVE, COMPLETE
42-17432-K	KIT, CHUCK FORK SLV,1-1/4"
42-17433	CHUCK FORK SLEEVE, INNER
42-17434-1	FEED TUBE, 1-1/4"
42-17435	ADJUSTMENT NUT, FEED TUBE
42-17436-1	SPINDLE NOSE OIL GUARD
42-17436-99	OIL GUARD, SPINDLE NOSE
42-17437	WASHER
42-17438	LABERINTH SPRING WASHER
42-17439	CHUCK NUT, NO. 22
42-17440	SPINDLE NUT
42-17442	CHUCK NUT
42-17446-1	YOKE FULCRUM
42-17449-2	OPERATING LEVER
42-17451-1	LINK STUD
42-17453	DISK,FRICTION (1-1/4 OR 1-5/8)
42-17455	SPACER
42-17457-1	DISK,FRICTION (1-1/4")
42-17462-99	CROSS FEED RACK
42-17465-1	GUARD,CHIP
42-17466-1-99	WIPER,FRONT CROSS SLIDE
42-17467-1-99	SLIDE WIPER,REAR
42-17474-99	GUARD,CROSS SLIDE FRONT
42-17475-99	GUARD
42-17476-1	PLUNGER
42-17477-3	SCREW,X SLIDE ADJUST CMPL
42-17477-99	ADJUSTING SCREW, X SLIDE
42-17480-99	SWIVEL
42-17482-99	SEGMENT SCREW
42-17483-99	SEGMENT SCREW COLLAR
42-17486	HOOK BOLT, LARGE HEAD
42-17488-99	HOOK BOLT

PART #	DESCRIPTION
42-17491-99	TOOL POST SEGMENT
42-17492-99	HOOK BOLT, LARGE HEAD
42-17493-99	HOOK BOLT
42-17494-99	HOOK BOLT
42-17496	ATTACHMENT KEY
42-17499	NUT,ADJUSTING
42-17502-2	CAM GEAR
42-17503	STOCK STOP CAM
42-17504	CHUCK AND FEED CAM
42-17507-1	SHAFT BUSHING
42-17507-99	BUSHING, DRIVE SHAFT
42-17508-1	CLUTCH, DRIVING
42-17508-99	DRIVING CLUTCH
42-17509	CLUTCH WASHER
42-17510-2	DRIVE GEAR,CHUCK & FEED
42-17510-99	CHUCK FEED DRIVING GEAR
42-17511	SLEEVE
42-17512-1-99	DRIVING SHAFT
42-17512-4	DRIVING SHAFT
42-17515-99	SPRING PLUNGER
42-17516	SPRING PLUNGER SEAT
42-17517-99	TRIP LEVER
42-17518-1	FEED SLIDE
42-17526-99	FEED SLIDE BUSHING
42-17527	PUNCHING FEED POINTER
42-17528-ZZ	BRACKET, FEED LATCH
42-17529-99	BUSHING,FEED BRACKET
42-17530	FEED LATCH
42-17530-1	FEED LATCH
42-17531	ROUND BAR WAY
42-17532-1	FEED SLIDE GUIDE LOWER
42-17536-2	FEED LEVER, WITH SCREW & KNOB
42-17536-2-NF	FEED LEVER - ONLY (NO FURN.)
42-17537-1	FULCRUM, FEED LEVER
42-17537-99	FULCRUM, FEED LEVER
42-17539-1	ADJUSTMENT SCREW
42-17539-1-ZZ	ADJUSTMENT SCREW

PART #	DESCRIPTION
42-17539-2	FEED ADJUSTING SCREW
42-17539-99	FEED ADJUSTING SCREW
42-17540-1	ADJUSTMENT SCREW CAP
42-17540-99	FEED ADJUSTING SCREW CAP
42-17541-2-99	CHUCK FORK, W/SLOT
42-17541-2-ZZ	CHUCK FORK
42-17541-3	CHUCK FORK
42-17542	PIN
42-17543-1	ADAPTER
42-17543-2	CHUCK FORK ADAPTER
42-17544	FULCRUM
42-17545	LINK PIN
42-17545-1	LINK PIN
42-17546-1	LEVER LINK
42-17547-1	FULCRUM,LEVER
42-17548-1	LEVER ROLL PIN
42-17548-99	LEVER ROLL PIN
42-17549-1	CAM LEVER
42-17549-99	CHUCK CAM LEVER
42-17551-3-99	VERT SLIDE CAM LEVER
42-17552-1	LEVER PIN
42-17557-99	PLUNGER
42-17560	CAM LEVER
42-17560-2	CAM LEVER
42-17566-1-99	SPACER
42-17570	GUARD CLAMP
42-17571	FEED TUBE, 1-1/2"
42-17573-1	WASHER
42-17574	FEED TUBE NUT
42-17575-99	NUT, FEED TUBE ADJUSTING
42-17576	CHUCK NUT,NO.22
42-17577	CHUCK NUT,NO.22 D
42-17578	CHUCK NUT
42-17579	HOOK,STOCK
42-17580-1	PIPE SUPPORT
42-17581-1	SUPPORT,PIPE
42-17587	WASHER, OIL RETAINER

PART #	DESCRIPTION
42-17592	STUD
42-17593-99	LOCK PIN LEVER BLOCK
42-17594-1	SHAFT
42-17595-1	CAM
42-17598-1	CAM EXTENTION, FOR LOCKING PIN
42-17599-1	ROLL STUD
42-17611-1	STUD, LINK
42-17611-2	STUD-REVERSING LINK
42-17612	TRIP LEVER ABUTMENT
42-17614-99	OIL TUBE HOLDER
42-17615	WASHER
42-17617	CONNECTOR, LINK
42-17618-99	PLUNGER,TURRET INTER GEAR
42-17619-99	PLUNGER,TURRET INTER GEAR
42-17620-99	GEAR, TURRET DRIVING
42-17621-99	TRIP LEVER CAM
42-17623	BUSHING
42-17624	TURRET INTER. GEAR SPACER
42-17625-99	WASHER
42-17626	DISK NUT
42-17628	BUSHING
42-17631	SEAL
42-17633	SPROCKET
42-17639	LOCKNUT
42-17640	WASHER
42-17641-99	BUSHING,FRONT CAMSHAFT
42-17648	SPROCKET
42-17649-1	PLATE, LOCKING
42-17658	FULCRUM KEY
42-17659-1	SPRING STUD
42-17661	CLAMP BUSHING
42-17662	CLAMP BUSHING
42-17664-2	FEED TUBE, COMPLETE 3/4"
42-17665-1	FEED TUBE, COMPLETE 1-1/4"
42-17666-99	FEED TUBE, COMPLETE 1-1/2"
42-17669-2	LEVER
42-17669-99	LEVER

PART #	DESCRIPTION
42-17671-1-99	LEVER, POSITIVE STOP
42-17671-2	LEVER
42-17674	SCALE
42-17677-99	STOP SHAFT LINK-REAR
42-17680-99	WASHER, LEAD CAM SHAFT
42-17682-99	CHUCK CAM SHAFT PIN
42-17685-2	WASHER
42-17687	ADJUSTING SCREW
42-17690	SPLASH GUARD
42-17701	BUSHING
42-17702	SLOTTING SHAFT
42-17704	SHAFT COLLAR
42-17712	FULCRUM COLLAR
42-17715	CAM LEVER
42-17716-1	ROLL STUD
42-17717-2	ARM REST
42-17718	LEVER, STOP
42-17725-99	WASHER
42-17727-99	WASHER
42-17741-1-99	STUD, LEVER SPRING, LOWER
42-17741-2	STUD, SPRING
42-17742-1	STUD, SPRING
42-17743	SLEEVE, DRIVE SHAFT
42-17744	SLEEVE
42-17745	SHAFT BUSHING
42-17758	SPECIAL COUPLING
42-17759	DRIVING PIN
42-17759-2	DRIVING PIN
42-17762	CHANGE GEAR KEY
42-17770	LEVER, BRAKE OPERATING
42-17783	SHAFT NUT
42-17785	GASKET
42-17788-1-99	PLUNGER
42-17789	STUD, CUP PACKING
42-17790-99	CUP PACKING WASHER
42-17793	GASKET
42-17795	SHAFT

PART #	DESCRIPTION
42-17795-ZZ	SHAFT, TURRET, 2ND QUALITY
42-17797-99	SPROCKET BUSHING, NO.4
42-17802-99	TRIP LEVER SHOE
42-17808-2-99	END PLATE FRONT
42-17809-1-99	END PLATE BACK
42-17815-1	GUARD, EXTENSION
42-17816	GIB, BACK-OVERSIZE
42-17817	GIB, FRONT-OVERSIZE
42-17818-99	BUSHING
42-17819	RING, SNAP
42-17822	PIN, SLIDE PLATE
42-17823	MOTOR PULLEY
42-17824	MOTOR PULLEY
42-17825	SPINDLE PULLEY
42-17830-3	SUPPORT, STOCK
42-17831	OIL PIPE BUSHING
42-17837	SHIM
42-17841	SHAFT SHOE
42-17843-2	PANEL WIRES
42-17849	GIB, OVERSIZE
42-17849-ZZ	GIB, OVER, SECOND QUALITY
42-17851	SHAFT SPACER
42-17854-99	SPACER
42-17858-1	GUARD, PLEXY
42-17859	PIN
42-17868-2	HOOK, STOCK
42-17871	CAP, OIL FILLER
42-17872	CAM, DUMMY
42-17880	COLLAR
42-17882	HANDLE ROLL
42-17894-1-99	CLUTCH UNIT
42-17895	CLAMP BUSHING, TURRET TOOL
42-17896-99	SPROCKET FAN
42-17896-A	BLADE FOR FAN
42-17899-1-99	TRIP LVR TMNG LVR SCRW
42-17911-1	CHANGE GEAR, 76 TEETH
42-17912-1	GEAR INSERT

PART #	DESCRIPTION
42-17914-1	FRICTION CHANGE GEAR
42-17915	CLAMP SCREW
42-17919	CAM ROLL STUD
42-17922-1	PLUNGER SCREW
42-17932-99	SPINDLE SPROCKET BRNG RNG
42-17934-99	WASHER, SPROCKET
42-17948-99	WASHER, SPROCKET
42-17962	TUBE CLAMP
42-17964-99	EXPANDER
42-17967	LEVER FULCRUM
42-17968	LEVER FULCRUM
42-17970	SPRING, WAVE TYPE
42-17974	CLAMP NUT
42-17979	RETAINER
42-17998-99	FULCRUM, STOP LEVER
42-17999	INSERT, KEYWAY
42-18319	GASKET
42-18323	RETAINER
42-18325-1	SPROCKET IDLER (IMPROVED)
42-18326	SPACER
42-18328-1	BELT GUARD
42-18329	SPINDLE PULLEY
42-18388-2	CRANK
42-18389-2	SHAFT CRANK
42-18390	GEAR, TURRET CHANGE
42-18390-A	BUNG
42-18391-1	SLEEVE
42-18392-1	WASHER
42-18393-1	WASHER
42-18402-3	PRINTED MATTER
42-18404	SPRING, WAVE TYPE
42-18409	SHOE, CARBIDE, FOR INSERT
42-18460-99	GIB, OVERSIZE
42-18461	SHAFT SPACER
42-18461-2	SHAFT SPACER
42-18468	PLUG
42-18478	SPRING

PART #	DESCRIPTION
42-18487	GUARD KEY
42-18496	MOTOR SPROCKET
42-18497-2	CHUCK CAM
42-18499	SPROCKET FAN
42-18506-2	PLATE, X-SLIDE END, FRONT
42-18507-2	PLATE
42-18508-1	LATCH STRAP
42-18509	STOP SCREW
42-18510	PIN
42-18511	CROSS SLIDE END PLATE GUARD
42-18513	THRUST WASHER
42-18514	LOCKING SHOE
42-18522	WASHER
42-18523	SLEEVE
42-18524	SPRING
42-18525	TOOL SUPPORT STRAP
42-18537	TRANSFER CAM
42-18541	TRANSFER CAM
42-18542	ADVANCING CAM
42-18543	TRANSFER CAM
42-18544	PLUG
42-18546	SPEED PLATE
42-18547	WASHER
42-18549-99	ROLL STUD WITH NUT
42-18550	PLUNGER STOP
42-18551	FITTING WASHER
42-18552	SPACER
42-18553-1	BRACKET
42-18554	TORQUE LMTR SPRT BSH
42-18554-1	TORQUE LIMITER SPKT BUSHING
42-18555	GASKET
42-18556	GASKET
42-18560	SPRING
42-18563	ARBOR SPACER
42-18564	ARBOR SPACER
42-18565	ARBOR SPACER
42-18567-1	COLLET NUT

PART #	DESCRIPTION
42-18574	LOCATING PIN
42-18606	CHUCK NUT
42-18607	SPINDLE FRONT BEARING NUT
42-18608	LOCK NUT, FRONT BOX
42-18616	RET. SPRING FITTING WASHER
42-18636	CHUCK LEVER FULCRUM SHOE
42-18656	WASHER
42-18657-1	GUARD
42-18658-1	GUARD
42-18659	NUT
42-18660	LEVER
42-18661	LEVER
42-18662-2	PLUNGER BRACKET
42-18663-1	SWITCH LEVER
42-18664	LOCATING PLUNGER
42-18665-1	FULCRUM BLOCK
42-18666-1	PLUNGER BUSHING
42-18667-1	DRIVER GEAR
42-18668-2	GEAR
42-18669	GEAR PINION
42-18670-1	RACK,ROTATING GEAR
42-18671-2	OPERATING LEVER
42-18672-1	ROD END
42-18673-1	CONNECTING PIN
42-18674-1	ATT MOUNT BRKT
42-18675	PLATE
42-18676	BLOCK BRACKET
42-18678	RACK BUSHING
42-18679	CLAMPING PLATE
42-18680	CLAMPING PLATE
42-18681-2	GEAR, SPINDLE ROTATING 157 TH
42-18682-2	GEAR, SPINDLE ROTATE,157TH 3/4
42-18683	RING,LOCATING
42-18684	RING,LOCATING
42-18685	RING,LOCATING
42-18686-1	RISER BLOCK
42-18689	LEVER FULCRUM

PART #	DESCRIPTION
42-18690	FULCRUM, CHUCK LEVER
42-18691	FULCRUM
42-18692	LOCATING PLUNGE ROLL PIN
42-18694	INDEXING BLACK
42-18695-1	MOUNT BRACKET
42-18696	PLATE
42-18697	DISK, FRICTION
42-18698	DISK, FRICTION OUTER 1-1/4
42-18699	DISC, FRICTION
42-18703-1	OIL SEAL, REAR SPINDLE COVER
42-18704	BELT, DRIVE PULLEY W/ INSERTS
42-18710	KEY WEDGE
42-18711	KEY
42-18712	KEY
42-18713	KEY COLLAR
42-18715-1	ARBOR NUT
42-18717	SPACER WASHER
42-18718	SPACER WASHER
42-18722	SWING STOCK STOP
42-18723	BEVEL GR THRST WSHR
42-18724	FITTING WASHER
42-18725	DRIVEN SHAFT
42-18728	SPACER
42-18730	SAW ARBOR GEAR
42-18731	DRIVE SHAFT
42-18732	SPACER
42-18736	SLIDE COVER
42-18737	COVER GASKET
42-18740	PULLEY GUARD
42-19071	SPACER
42-19072	ADAPTER PLATE
42-19073	CLAMP NUT
42-19074	PRINTED MATTER
42-19094	MOUNTING BLOCK
42-19130	SPRING
42-19137-1	SWITCH PLATE
42-19138-1	LEVER SPACER

PART #	DESCRIPTION
42-19139	FITTING WASHER (0.040 THICK)
42-19140	FITTING WASHER (0.050 THICK)
42-19141-99	FITTING WASHER (0.060 THICK)
42-19142	FITTING WASHER (0.050 THICK)
42-19143	FITTING WASHER (0.060 THICK)
42-19144-99	FITTING WASHER (0.070 THICK)
42-19145	FITTING WASHER (0.030 THICK)
42-19146	FITTING WASHER (0.040 THICK)
42-19147-99	FITTING WASHER (0.050 THICK)
42-19151	DRIVING SHAFT
42-19152	DRIVEN GEAR
42-19153	CROSS MLL DRVN GR BSHNG
42-19154	GEAR COLLAR
42-19156	DRIVE COLLAR
42-19158	DRIVING SLEEVE
42-19160	CASE CAP
42-19186	LEVER
42-19187	LEVER
42-19188	BUSHING
42-19188-2	FOLLOWER, CAM
42-19189-2	STUD
42-19189-99	SWITCH OPR LVR PVT ST
42-19191-1	SPRING
42-19192-1	INSERT, CAM
42-19193	CONTACT SCREW
42-19219	OPER LEVER
42-19221	SLIDE LEVER
42-19222	PIN LEVER
42-19223-2	SPRING HOLDER
42-19224	CONNECTOR, LINK
42-19228	NUT,CAM
42-19236-2	SHAFT, UPPER SLIDE
42-19239	GIB,FOURTH SLIDE
42-19241	SWITCH STOP
42-19242	SPRING PLUNGER
42-19242-1	SPRING PLUNGER
42-19243	SPRING

PART #	DESCRIPTION
42-19243-1	SPRING,UPPER SLIDE
42-19244	BUSHING
42-19245	LINK,CONNECTOR
42-19246-1	LEVER SHAFT
42-19246-99	SHAFT
42-19249-2	BRAKE YOKE
42-19250	FULCRUM LEVER
42-19251	OPERATING LEVER
42-19253	BRAKE LINK
42-19259	PRINTED MATTER
42-19260	PIN,TAPER
42-19262-3	TOOL HOLDER
42-19264-5	TOOL HOLDER 1/2"
42-19268	MOTOR BRACKET
42-19269	MOTOR BRCKT RSNG BLCK
42-19271-2	SPROCKET,CLUTCH SHAFT
42-19272-99	CHAIN GUARD
42-19273-1-99	DRIV CLTCH SHFT GR
42-19273-2	GEAR,DRIVING CLUTCH SHAFT
42-19274	BUSHING,DRIVE CLUTCH GEAR
42-19277-2	TORQUE LIMITER ASSEMBLY
42-19278	LOCATING PIN
42-19278-1	LOCATOR PIN,TOOL HOLDER
42-19280-1	HOLDER STRAP
42-19287	PLUG
42-19292-1	SPRING
42-19293-1	SUPPORT,PIPE
42-19297-1	SPRING
42-19301	MOTOR WIRES
42-19304	COLLAR,PIPE
42-19305	COLLAR
42-19306-1	COLLAR,PIPE
42-19316	ADVANCING CAM
42-19319	CARBIDE SHOE
42-19323-1	CLUTCH BUSHING
42-19323-99	BUSHING, DRIVE SHAFT CLUTCH
42-19325	CHANGE GEAR,44 TEETH

PART #	DESCRIPTION
42-19327	CHANGE GEAR,62 TEETH
42-19328	CHANGE GEAR,30 TEETH
42-19336	ARBOR NUT
42-19337	KEY
42-19341	SPACER
42-19342-1	ROLL PIN
42-19347	GEAR BOLT
42-19348-1	TOOLHOLDER, BACKWARD NO WEDGE
42-19348-99	TOOL HOLDER
42-19350	PIN BUSHING
42-19351	STAND POST
42-19357	SPRING RETAINER
42-19364	MOUNTING BRACKET
42-19365	BOLT SLEEVE
42-19371	SPACER, PULLEY
42-19372	TIMING BELT PULLEY
42-19373	WORM SPACER
42-19374	TIMING BELT PULLEY
42-19375	TIMING BELT PULLEY
42-19376	WORM GEAR, DRIVE SHAFT
42-19378	RETAINER CAP
42-19379	WORM WHEEL
42-19380	SPACER
42-19381	SLIDE COVER
42-19382	GASKET
42-19383	CHUTE EXTENSION
42-19385	SCREW LINER
42-19406	CAM CARRIER
42-19411-99	SPACER RETAINING RING
42-19412	KIT, SPRING
42-19413	KIT, SPRING
42-19414	KIT, SPRING
42-19419	BUSHING,DRIVE CLUTCH
42-19420	CAM ROLL
42-19421	CLUTCH BUSHING
42-19423	GIB, UPPER SLIDE, OVERSIZE
42-19424	NUT,ADJUSTING

PART #	DESCRIPTION
42-19482	SHAFT, VERT SLIDE
42-19483	WASHER
42-19484	PIN WRENCH
42-19485	NEUTRAL POSITIO DOG
42-19486-1	SW MOUNT BRCKT
42-19489-1	ROD GUIDE
42-19490-1	CYLD ADAPTER
42-19491-1	ROD ESTENSION
42-19500	ADJUSTMENT SCREW NUT
42-19500-1	NUT
42-19501	ADJUSTMENT SCREW
42-19501-1	SL ADJ SCREW
42-19502	SCREW COLLAR
42-19503	DIAL,SLIDE ADJUSTING
42-19503-1	SLIDE ADJ DIAL
42-19504	DIAL SETTING PIN
42-19518	TRANSFER CAM
42-19519	ADVANCING CAM, 6 TO 11
42-19520	TRANSFER CAM
42-19521	ADVANCING CAM, 12 TO 1000
42-19522	TRANSFER CAM
42-19523	LOCATING PIN
42-19593-1	PINION RACK ROLLER
42-19597	RETAINER SPACER
42-19598	SPRING, COMPRESION, SPROCKET
42-19599	SPRING,DISC
42-19600	END COLLAR
42-19602	LOCKING PIN CAM
42-19608	FITTING WASHER
42-19609	SHANK
42-19610-1	DRIVEN SHAFT
42-19637-1	PIN,SPRING
42-19638	STUD, PIVOT
42-19643	THRUST NUT
42-19645	RETAINER
42-19646	DISK, FRICTION 3/4" CAP
42-19649-1	FRW OIL GUARD

PART #	DESCRIPTION
42-19650	SPINDLE, 3/4" CAPACITY, #00
42-19651	CHUCK SLEEVE
42-19652-1	PIN, CHUCK SLEEVE
42-19653	FRONT BOX
42-19654	OIL GUARD, SPINDLE NOSE
42-19655	SPINDLE SPROCKET
42-19656	SPACER
42-19657	SPRING RETAINER
42-19658	CLUTCH BODY 3/4"
42-19660	RING, CLUTCH BODY
42-19661	CLUTCH SLEEVE
42-19663	SLEEVE RING
42-19664	SPINDLE REAR BOX
42-19665	SPACER
42-19666	CLOSING TUBE
42-19667	FULCRUM SHOE
42-19668	CHUCK LEVER FULCRUM
42-19669	CHUCK FORK SLEEVE, COMPLETE
42-19669-K	KIT, CHUCK FORK SLV, 3/4"
42-19670	CHUCK FORK SLEEVE, INNER
42-19671-1	NUT, CHUCK ADJUSTING
42-19672	SPINDLE SPROCKET
42-19672-1	SPINDLE SPROCKET 3/4"
42-19672-ZZ	SPROCKET, SECOND QUALITY
42-19673	SPACER
42-19674	SPACER KEY
42-19675-1	FORK, CLUTCH
42-19676	FEED TUBE, COMPLETE 3/4" #00
42-19677	FEED TUBE, 3/4" #00
42-19678	SHIELD
42-19679	YOKE, BRAKE 3/4" CAP
42-19680	CHUCK NUT
42-19682-1	CHUCK NUT, # 11
42-19683	SPACER KEY
42-19684	SHOE, CHUCK FORK SLEEVE
42-19685	SPINDLE NUT
42-19686	LATCH, FEED

PART #	DESCRIPTION
42-19688	LEVER
42-19689	WASHER
42-19690	CHUCK SLEEVE, 11C
42-19691	FEED TUBE NUT
42-19695	WAVE TYPE LABERINTH WASHER
42-19696	LABYRINTH WASHER
42-19697	SPRING, WASHER TYPE
42-19698	RETAINER NUT
42-19699	SHOE, LEVER
42-19701	COVER
42-19702	GASKET
42-19704-1	CARRIER, DOG
42-19706	CAMSHAFT BEARING BRACKET
42-19708	CAP
42-19709-1	COVER
42-19710-A	TURRET SLIDE WAYS PLUG
42-19710-B	TURRET SLIDE WAYS PIN
42-19713-1	PLATE
42-19715	PLUNGER
42-19716	SPRING
42-19717	SPRING
42-19718	PIN
42-19719	SCREW
42-19720	BUSHING
42-19721-2	TURRET, 6 HOLE #2
42-19722-2	TURRET, 8 HOLE #2
42-19723	DRIVING SLEEVE
42-19723-1	BUSHING
42-19724	SLEEVE
42-19725	NUT
42-19726	WASHER
42-19727	LEVER
42-19728	PIN LEVER
42-19729	PLATE, LEVER
42-19730	RACK, TURRET SLIDE
42-19731	COVER
42-19732	SHAFT

PART #	DESCRIPTION
42-19733	GEAR, TURRET
42-19734	GEAR, TURRET INTER. RETURN
42-19735	TROUGH, OIL
42-19736	LEVER STUD
42-19738	GEAR, CLUTCH SHAFT DRIVEN
42-19740	SHAFT,WORM
42-19741	CLUTCH LEVER
42-19742	SHAFT,CAM
42-19743-1	GEAR, W/DRAWAL CAM SHAFT
42-19745-1	RING,RETAINING
42-19747	SPACER
42-19748	RETAINER
42-19749	CAP, CAMSHAFT
42-19750	LEAD CAM LEVER
42-19750-2	CAM LEVER
42-19751	FULCRUM,LEVER
42-19752-2	SHAFT
42-19752-2-ZZ	LEAD CAM SHAFT
42-19753	GUARD, PLEXY
42-19758	LEVER LINK PIN
42-19760-1	PIN,SPRING
42-19761	SPRING
42-19762	CONNECTING ROD PIN
42-19764	HINGE,DEFLECTOR
42-19765	PIN,HINGE
42-19766	SEAL,OIL
42-19767	CLAMP INSERT
42-19768-1	SLIDE, DEFLECTOR
42-19769-C	URETHANE DEFLECTOR BUMPER
42-19770	SLIDE PIN
42-19771	WORK DEFLECTOR & GUARD
42-19774-1	BRACKET,PUMP
42-19775	GEAR, DRIVE
42-19776-1	PUMP GEAR, FIBER GEAR ONLY
42-19777	SPROCKET DRIVER
42-19778	GEAR SLEEVE
42-19780	SWITCH DOG 5/100

PART #	DESCRIPTION
42-19781	SWITCH DOG 4/10
42-19782	SWITCH DOG, 3/100
42-19783	SWITCH DOG 2/100
42-19784	SWITCH DOG EXTENTION
42-19784-NF	EXTENTION DOG (W/O SCREW)
42-19787	BRACKET,IDLER
42-19788-1	SHAFT,HANDWHEEL
42-19789	SEAT,LEVER
42-19790-2	SHAFT
42-19790-2-ZZ	SHAFT
42-19792	LEVER
42-19795	BLOCK
42-19796	BLOCK
42-19797	STUD BUSHING
42-19798	STUD, IDLER
42-19799-1	FULCRUM,LEVER
42-19803	GEAR BOX BRKT COVER
42-19817-1	STORAGE BOX, FEED GEARS
42-19823	BASKET,WORK
42-19825-1	RAIL,PAN SLIDE
42-19826-1	PAN,CHIP
42-19828	GUARD
42-19829-1	PAN,OIL DRIP
42-19830	OIL DRIP PAN EXTENSION
42-19832	STRAINER PLATE
42-19837-1	BOX,SWITCH MTG
42-19838	MOUNTING BRACKET
42-19839-2	COVER PLATE
42-19842	GASKET
42-19847-1	PLATE GASKET
42-19852	SHAFT SPROCKET
42-19853	SLINGER BLADE
42-19854	GEAR SHAFT
42-19855	SPACER
42-19856	GEAR, CLUTCH DRIVER
42-19856-1	CLUTCH GEAR DRIVER
42-19857	RETAINER

PART #	DESCRIPTION
42-19858	RETAINER
42-19859	GEAR SPACER
42-19860-1	DRIVING SHAFT
42-19860-2	HI-SPEED SHAFT
42-19861	FITTING WASHER
42-19862-1	CLUTCH GEAR COMPLETE
42-19863-1-99	INNER SHAFT, ELECTRO CLUTCH
42-19864	CLUTCH SLEEVE GEAR
42-19865	SPACER
42-19866	SPACER, OUTER
42-19867	SPROCKET, SPINDLE DRIVING
42-19869	DRIVING CUP
42-19870	RETAINER NUT
42-19871	GEAR SHAFT
42-19872	DRIVING SHAFT
42-19873	SHAFT SPACER
42-19879	SPINDLE DRIVE SHAFT,FAST
42-19880	SLEEVE
42-19880-ZZ	SLEEVE, SECOND QUALITY
42-19881	SPACER
42-19882	SPACER
42-19883	GASKET
42-19884	OIL TROUGH
42-19886	SPACER
42-19888-2	SHAFT OILER
42-19889-2	TUBING RETAINER
42-19890	SLEEVE SPACER
42-19891	WASHER
42-19900	CLUTCH SPIDER
42-19901-1-NF	CLUTCH SHAFT, NO CLUTCH
42-19909	SEAL,OIL GUARD
42-19912	SEAL,OIL GUARD
42-19914	HOLDER, TUBE
42-19915-1	BRACKET,LUBR
42-19916-1	GUARD
42-19917-1	BOOT
42-19920	GUARD

PART #	DESCRIPTION
42-19921	PLATE
42-19922	PLATE
42-19923	GUARD
42-19927	PLATE, LEVER SLIDE
42-19928-2	END GUARD-DR SH BRKT
42-19929	SEAL,CHIP GUARD
42-19937	GUARD
42-19937-2	GUARD FORWARD OIL SIDE
42-19938	OIL GUARD WINDOW,PLEXIGLASS
42-19940-1	TUBING CLIP
42-19942	GUARD, COMPLETE
42-19942-A	PLEXEY
42-19943	PLEXIGLAS GUARD
42-19944	PLEXIGLAS GUARD, LOWER
42-19945	GUARD
42-19951	FULCRUM
42-19953-1	SLIDE CAM LEVER
42-19953-2	CAM LEVER
42-19954	FULCRUM PIN
42-19954-1	LEVER FULCRUM
42-19955	SPINDLE BODY
42-19955-ZZ	SPINDLE, MINOR DEFECT
42-19956	SLEEVE PIN
42-19957-1	SPINDLE NOSE OIL GUARD
42-19957-99	SPINDLE NOSE OIL GUARD
42-19958	LABYRINTH WASHER SPRING
42-19958-1	SPRING
42-19959	WASHER, GRAPHITE
42-19959-1	LABYRINTH WASHER
42-19960	FRONT BOX
42-19960-1	FRONT BOX
42-19960-1-ZZ	FRONT BOX
42-19961	NUT
42-19961-1	NUT
42-19962-1	SPINDLE,1 1/4" CAPACITY
42-19963	SPINDLE REAR BOX
42-19963-1	SPINDLE REAR BOX

PART #	DESCRIPTION
42-19964	THRUST WASHER,SPINDLE
42-19964-1	THRUST WASHER
42-19965	SPRING
42-19966	SPACER, RIGHT
42-19967	SPINDLE SPROCKET
42-19968	SPINDLE SPROCKET
42-19969-1	SPINDLE,3/4"CAPACITY,#2
42-19970	BELVILLE TYPE SPRING
42-19971	SPACER
42-19971-1	SPACER
42-19972	SPINDLE SPROCKET
42-19973	SPINDLE SPROCKET
42-19976	SPINDLE,1 5/8"CAPACITY
42-19976-2	SPINDLE,1 5/8"CAPACITY
42-19977	SPINDLE SPROCKET
42-19978	SPINDLE SPROCKET
42-19979-1	SPRING
42-19980-2	NUT,CHUCK ADJUSTING
42-19980-3	NUT,CHUCK ADJUSTING
42-19981	CHUCK LEVER FULCRUM
42-19982	FULCRUM SHOE
42-19983	CLOSING TUBE
42-19984-1	CHUCK FORK SLEEVE, COMPLETE
42-19984-1-ZZ	CHUCK FORK SLEEVE
42-19984-1K	KIT,CHUCK FORK SLV,1-5/8"RS
42-19984-99	CHUCK FORK SLEEVE, COMPLETE
42-19984-K	KIT,CHUCK FORK SLV,1-5/8"
42-19985	CHUCK FORK SLEEVE, INNER
42-19985-1	CHUCK FORK SLEEVE, INNER
42-19987-1	FEED TUBE, COMPLETE 1-5/8"
42-19988	FEED TUBE, 1-5/8"
42-19988-1	FEED TUBE, 1-5/8"
42-19989	WASHER
42-19990	FEED TUBE NUT
42-19991	FEED TUBE ADJUSTING NUT
42-19992	SPACER
42-19994	GUARD, SPINDLE SPROCKET

PART #	DESCRIPTION
42-19994-1	GUARD
42-19999	GEAR, PUMP DRIVEN-FIBER 50CY
42-19999-1-A	PUMP GEAR COMPLETE
42-20002	SHAFT BUSHING
42-20003	DRIVING SHAFT
42-20004	GEAR, ACCELERATOR
42-20005	WASHER
42-20006	REVERSING CAM
42-20008	REVERSING CLUTCH
42-20009	CLUTCH INSERT
42-20010-2	CLUTCH,TURRET (WAS42-17260)
42-20012	BUSHING, UNDERSIZE
42-20012-A	BUSHING, FINISHED SIZE
42-20013-1	TURRET DRIVING GEAR
42-20014	GEAR BUSHING
42-20015	WASHER
42-20016	GEAR SHAFT
42-20017	WASHER
42-20018	INTERMEDIATE GEAR
42-20019	TURRET INT. GEAR PLUNGER #1
42-20019-1	PLUNGER
42-20019-1-ZZ	PLUNGER
42-20020-1	PLUNGER
42-20021	SPRING
42-20022-1-99	CLUTCH SHAFT
42-20022-2	CLUTCH SHAFT
42-20023-99	WASHER, SAFETY CLUTCH
42-20025-1	CLUTCH GEAR
42-20025-99	SAFETY CLUTCH GEAR
42-20026-1	SAFETY CLUTCH
42-20026-99	SAFETY CLUTCH
42-20027-1-99	CLUTCH SLEEVE
42-20027-2	SAFETY CLUTCH SHAFT
42-20027-3	CLUTCH SLEEVE
42-20028-99	HOUSING GEAR
42-20029-99	HOUSING,GEAR SPACER
42-20031	SHAFT COLLAR

PART #	DESCRIPTION
42-20032-1	CLUTCH SHAFT
42-20032-99	ACCELERATOR CLUTCH SHAFT
42-20033-1	DRIVE GEAR
42-20037-99	SPACER SMALL
42-20039	CLUTCH SPACER
42-20040-1	CLUTCH SLEEVE
42-20041	CLUTCH SLEEVE
42-20049	LEVER FULCRUM
42-20051	RETAINER COLLAR
42-20052	IDLER GEAR
42-20053	GEAR STUD
42-20054	DRIVE GEAR
42-20059	SHAFT GEAR
42-20061	INDEXING DOG CARRIER
42-20061-1-ZZ	CARRIER, SECOND
42-20063	GEAR COVER
42-20065	GEAR SPACER
42-20067-1	SHAFT GEAR
42-20068	LEVER FULCRUM
42-20069	TRIP LEVER
42-20070	TRIP LEVER
42-20070-ZZ	TRIP LEVER
42-20071	ABUTMENT SCREW
42-20073	LEVER ABUTMENT
42-20074	SPRING RETAIN
42-20075	SPRING
42-20076	PULL OUT LEVER
42-20077	LEVER FULCRUM
42-20078	PLUG
42-20081	PLUNGER - ROLLER TYPE
42-20081-1	PLUNGER -SOLID TYPE
42-20082-1	PLUNGER
42-20083	SPRING
42-20084-1	SWITCH LEVER
42-20085	SWITCH LEVER
42-20086	RETAINER SEGMENT
42-20088	REVERSING LEVER

PART #	DESCRIPTION
42-20089	ROLL STUD
42-20100	CROSS SLIDE
42-20101	CROSS SLIDE
42-20103-1	WAY, CROSS SLIDE
42-20104	RACK
42-20105	RACK
42-20106-1	CROSS SLIDE LEVER,FRT
42-20107-1	CROSS SLIDE LEVER BACK
42-20108	LEVER,CROSS SLIDE
42-20109	FULCRUM
42-20110-1	PLATE, END
42-20111	PLATE, END
42-20112	GIB, SLIDE, FRONT & BACK
42-20113	CROSS SLIDE ADJUSTING SCREW
42-20113-2	SCREW,ADJUSTING
42-20114	SCREW, ADJUSTING (COMPLETE)
42-20114-A	SCREW ONLY, X-SLIDE ADJUSTING
42-20115	STRAP
42-20118	WIPER
42-20119	WIPER
42-20120	GUARD
42-20121	GUARD
42-20122	GUARD
42-20123-1	SCREW,ADJUSTING
42-20124	GUARD
42-20126	BODY WASHER
42-20127	CLUTCH BRACKET
42-20128	CLUTCH BRACKET
42-20133	CASE SUPPORT
42-20134	CASE SLEEVE
42-20136	CAM LEVER PIN,3RD&4TH SLIDEWAY
42-20137-2	4TH SLIDE CAM LEVER
42-20140	ADJUSTMENT SCREW
42-20140-1	SLIDE ADJUSTING SCREW
42-20140-2	SLIDE ADJ SCREW VERTICAL
42-20143	PIN LEVER
42-20145-1	OPERATING PLATE

PART #	DESCRIPTION
42-20145-2	OPERATING PLATE, UPPER SLIDE
42-20147-1	UPPER SLIDE
42-20148-1	RETAINER STUD
42-20150-1	LEVER, UPPER SLIDE
42-20150-2	OPER LEVER
42-20151	OPER LEVER
42-20151-2	OPER LEVER
42-20152-1	PIN WRENCH
42-20160	BRACKET
42-20161	FULCRUM BUSHING
42-20162	FULCRUM BUSHING
42-20163	CAM SHAFT
42-20164	OUTER SPACER
42-20166	RETAINER
42-20167	COUPLING
42-20169	LEVER GEAR
42-20170	FITTING WASHER
42-20172	ROTATING CAM LEVER
42-20174	ROTATING LEVER
42-20177	LEVER,STOP
42-20178	LEVER,STOP
42-20179-1-A	SLOTING GEAR W/O ARM
42-20181-1	SLOTING LEVER
42-20183	FULCRUM, SLOTING LEVER
42-20185	KEY
42-20186	SHAFT GEAR
42-20187	BRG RETAINER
42-20189	LOCK NUT
42-20190	SPRING
42-20191	PIN,SPRING
42-20192	SPRING RETAIN
42-20193	ARM STOP
42-20194	GUARD
42-20195	GASKET
42-20196	GASKET
42-20197	COLLAR
42-20198	HOLDER ARM

PART #	DESCRIPTION
42-20199	DRIVE SHAFT SPEED PLATE
42-20200	CHAIN TENSION NOTICE PLATE
42-20202	CHAIN TENSION INST. PLATE
42-20206-1	PLATE, REVERSING SWITCH
42-20208	SPEED PLATE
42-20209	SPEED PLATE
42-20210-1	SPEED PLATE
42-20224-1	LEVER
42-20226	COUPLING
42-20226-1	COOLANT SHAFT COUPLING
42-20228	COLLAR PIN
42-20229	GASKET
42-20235	SPACER
42-20242-1	SEAL,OIL
42-20247-1	COLLECTOR,OIL
42-20248-1	OIL GUARD
42-20251	NUT
42-20253	PINION
42-20254	DRILL SPINDLE
42-20255	SPINDLE HOLDER
42-20256	SHAFT EXT
42-20257	SLEEVE
42-20259	DOG SCREW
42-20260	EXT KEY
42-20262	COLLAR,RETAINING
42-20264	SPRING
42-20265-1	LEVER
42-20266-2	SPINDLE,2"CAPACITY
42-20267-99	CHUCK NUT
42-20268-1	GUARD,SPINDLE NOSE OIL
42-20269	SPINDLE WASHER
42-20270	SPRING, WAVE TYPE
42-20271	FRONT BOX
42-20272	LINER, FRONT BOX
42-20273	NUT,SPINDLE BOX
42-20274	BEARING, FRONT BOX CYLINDRICAL
42-20276	THRUST NUT

PART #	DESCRIPTION
42-20277	SPRING, BEARING RETAINER
42-20278	SPINDLE SPROCKET
42-20279	SPINDLE SPROCKET
42-20280	RING, RETAINING
42-20281	SPRING RETAINER
42-20282	CLUTCH BODY, #2 ULTRA 2 3/8"
42-20284	RING, CLUTCH BODY
42-20285-A	RING BLANK, CLUTCH
42-20287	SLEEVE RING
42-20289	CLUTCH SLEEVE
42-20289-ZZ	CLUTCH SLEEVE
42-20290	SPACER
42-20291	KEY
42-20292	REAR BOX
42-20293	RETAINER NUT
42-20294	NUT, REAR BOX
42-20295	SPACER
42-20296	SPINDLE NUT
42-20297	FULCRUM SHOE
42-20299-1	CHUCK ADJUSTING NUT
42-20301-1	FEED TUBE, 2"
42-20302-1	FEED TUBE, COMPLETE 2"
42-20303	WASHER, FEED TUBE
42-20304	OIL SHIELD, FEED TUBE
42-20305	FEED TUBE NUT
42-20306	NUT, FEED TUBE ADJUSTING
42-20307-2	CHUCK FORK SLEEVE, COMPLETE
42-20307-2K	KIT, CHUCK FORK SLV, 2&2-3/8"
42-20308	SLEEVE
42-20308-2	CHUCK FORK SLEEVE, INNER
42-20309-1	SUPPORT, FEED BRACKET
42-20310	FORK, CLUTCH
42-20313	DISK, FRICTION (2")
42-20315	DISK, FRICTION (2")
42-20317	POINTER
42-20318-1	SHOE
42-20320-1	FEED LATCH

PART #	DESCRIPTION
42-20321-2	FEED LATCH BRKT
42-20322	FULCRUM
42-20323	FULCRUM
42-20325	PLUNGER COMP
42-20325-NF	HOUSING ONLY, FEED PLUNGER
42-20327	BRKT FULCRUM
42-20328	THRUST NUT
42-20331	COLLAR,PIPE
42-20332	SUPPORT,PIPE
42-20333	HANDLE
42-20334	SUPPORT,PIPE
42-20335	YOKE, LOCK
42-20336-1	CARRIER EXT
42-20337	MOUNT BLOCK
42-20338	HANDLE, STOCK SUPPORT
42-20342	NUT,LOCK
42-20343	FEED LATCH SPACER
42-20345	NUT
42-20346-1	FEED SLIDE
42-20350	SLEEVE PIN
42-20351	CHUCK SLEEVE
42-20352	CHUCK NUT,NO.22 D
42-20355	CHUCK SLEEVE,23&23-M
42-20356	CLAMP SCREW
42-20357	CLAMP BUSHING W/NO CUT
42-20358	SLEEVE
42-20359	CHANGE GEAR,90 TEETH
42-20360	NUT,SPINDLE BOX
42-20360-1	FRONT BOX NUT
42-20361	RING,RETAINING
42-20362	RING
42-20363	RING, RETAINING
42-20365	SLEEVE PIN
42-20366	NUT
42-20367-1	SHAFT SPACER
42-20368-2	SHAFT SPACER
42-20369	FRONT BOX

PART #	DESCRIPTION
42-20369-1	FRONT BOX
42-20370	SHAFT SPACER
42-20375	PLATE,GAGE MOUNTING
42-20377-1	LEVER SEAT
42-20378-1	THRUST NUT
42-20379	THRUST NUT
42-20380-1	THRUST NUT
42-20381	SPRING RETAINER
42-20383	CLUTCH BODY 1-5/8 IN
42-20384-1	PIN HANDLE
42-20386	THRUST NUT
42-20387	SPRING RETAINER
42-20388-1	SPROCKET NUT
42-20390	CLUTCH BODY,#2 ULTRA 1 1/4"
42-20392	HOOK,LEVER
42-20393	THRUST NUT
42-20394-1	SPROCKET THRUST NUT
42-20396	CLUTCH BODY #2 ULTRA 3/4"
42-20397	RETAINER
42-20401	KEY, REAR SPACER
42-20402	ADJ SCREW
42-20403	SPRING
42-20404	RELEASE LEVER
42-20405	WINDOW RETAINER
42-20406	WORM WHEEL
42-20406-2	WORM WHEEL
42-20420	ROLL FULCRUM
42-20421	STOCK ROLL
42-20447	GASKET
42-20451-1	MOUNTING BRACKET
42-20454	HOLDER ARM
42-20455	FEED ROD END
42-20458-1	MOTOR WIRES
42-20459	SWITCH BLOCK
42-20460-A	ACTUATOR
42-20468	DIE CLOSER
42-20469	KIT, DOUBLE INDEX PARTS

PART #	DESCRIPTION
42-20470	KIT, DOUBLE INDEX (6-HOLE)
42-20472	CABLE&PLUG
42-20473-2	ATTACH WIRES
42-20476-1	CLUTCH GEAR
42-20487	GIB, OVERSIZE
42-20487-ZZ	GIB, OVERSIZE
42-20502-1	GUARD
42-20503-1	GUARD
42-20504	GUARD, PLEXY SPLASH
42-20512	GUARD
42-20514	WINDOW FRAME
42-20515-99	DOOR GUARD, 00
42-20516	WINDOW,SLIDING OIL GUARD
42-20517	RELEASE LEVER
42-20519	ROLLER BRACKET
42-20520	DOG CARRIER
42-20521-1	SHAFT NUT
42-20522	BRACKET, SWITCH MOUNTING
42-20523	PIPE CLIP
42-20524	PIPE SUPPORT
42-20525-2	GUARD
42-20527-1	BRACKET
42-20528-1	BRACKET
42-20529-1	LEVER
42-20533	PLEXY GUARD AND BRACKET
42-20534-1	OIL GUARD
42-20538	SPEED PLATE
42-20544	GASKET, CONTROL SW. COVER PLT
42-20545	CONTROL SWITCH COVER PLATE
42-20545-1	PLATE
42-20550-2	PIPING ARRANGE
42-20554-1	MOTOR WIRES
42-20555-1	SWING WIRES
42-20557	CABLE,WIRES
42-20559-1	PANEL WIRES
42-20563	BRACKET
42-20603	PAN,DRIP

PART #	DESCRIPTION
42-20606	SETTING BRACE
42-20614	SEAL
42-20616-1	RES COV PLATE GASKET
42-20617-1	OIL RES COVER GASKET
42-20619-1	TUBING
42-20621-1	SWITCH CONDUIT
42-20623-1	SUPPORT,CABINET
42-20900-2	WASHER
42-20902-1	CLUTCH GEAR 58T DRIVE
42-20903	CLUTCH GEAR
42-20903-1	CLUTCH GEAR 38T DRIVE
42-20904-1	FAST DRIVE GEAR, 58T
42-20905-1	FAST DRIVE GEAR,38T
42-20907-2	GASKET
42-20908	SPROCKET
42-20908-1	SPROCKET
42-20909-1	DRIVING SHAFT, INTERMEDIATE
42-20909-1-ZZ	INTERMEADIATE SHAFT
42-20911	IDLER ARM
42-21001	NUT, LEFT
42-21002	NUT
42-21004	SPACER
42-21019	SWITCH BOX COMPLETE
42-21022	DRAIN COVER
42-21023-3	ACCEL PANEL BASE 4SP
42-21024-4	FOUR SPEED PANEL BASE
42-21025	RELAY PANEL
42-21026-4	ACCEL PANEL BASE 2SP
42-21027	ARM KEY
42-21029	SPRING
42-21030	GEAR,DRIVEN 16T
42-21031	ADAPTER SHAFT
42-21033	CLUTCH WIRES
42-21035	GEAR NUT
42-21038	SHOE PLUNGER
42-21039	ADJUSTMENT NUT
42-21040	BOX WIRE

PART #	DESCRIPTION
42-21043	CHUCK SLEEVE, NO. 11
42-21044	CYLINDER SUPPORT
42-21045	FULCRUM
42-21052-1	GUARD,TURRET BEVL GR
42-21053	HOSE CLAMP
42-21054	PRINTED MATTER
42-21069-1	DRIVING SHAFT
42-21071	SPACER
42-21076	BAR BUSHING
42-21086	CAM SHAFT
42-21088	SPACER,CAMSHAFT BRG
42-21089	CAM HOLDER
42-21090	FULCRUM, 3/4" CAP
42-21091	CHUCK LEVER FULCRUM GEAR
42-21092	FULCRUM 1-1/4" CAP
42-21093	FULCRUM, 1-5/8" CAP
42-21093-ZZ	FULCRUM 1-5/8
42-21094	FULCRUM, 2" CAP
42-21096	DRIVE GEAR, 1-1/4,1-5/8 OR 2"
42-21097	DRIVEN GEAR STUD
42-21098	DRIVEN GEAR SPACER
42-21100	CAM HOLDER PIN
42-21103-1	STOP CAM
42-21104-1	SHAFT
42-21109	ADJUSTMENT SCREW
42-21111	THRUST WASHER
42-21116-1	RETAINING PAD
42-21117	RETAINING COLLAR
42-21122	SLIDE BLOCK
42-21132	CAM ROLL
42-21133	MOUNTING BLOCK, CAM ROLL
42-21137	LEAD CAM, 1"
42-21138	LEAD CAM, 2"
42-21139	LEAD CAM, 3"
42-21145-3	INSTRUCTION PLATE (IMPERIAL)
42-21154	BUSHING
42-21167	CHUCK SLEEVE,NO.22

PART #	DESCRIPTION
42-21168	CHUCK NUT,NO.22
42-21169	CHUCK NUT,NO.22 C
42-21173-1	DOG, TRIP, CENTER POINT
42-21173-1-NF	DOG, TRIP, W/O T-BOLT
42-21173-2	DOG, TRIP,UNIVERSAL W/ T-BOLT
42-21173-2-NF	DOG, TRIP UNIVERSAL NO T-BOLT
42-21180	SLEEVE PIN
42-21181	GIB, 4TH SLIDE, OVERSIZE
42-21182	CASE PLUG
42-21184	CLUTCH SEAL
42-21186-1	SWITCH CONTROL
42-21189	PANEL BASE
42-21191-3	CABLE, THD CHASING
42-21192	PLATE
42-21200-1	RING GEAR
42-21204	RETAINER SPRING
42-21206	RESERVOIR DRAIN
42-21208-1	TUBE, DR SHFT OIL SUP
42-21209	OIL TUBE
42-21210	SPACER
42-21222	RETAINER
42-21223-1	CLUTCH,ELECTROMAGNETIC
42-21224-1	CLUTCH,ELECTROMAGNETIC
42-21225	TURNING SLIDE
42-21226	TURNING SLIDE WAYS
42-21227	BASE
42-21228-1	PUSHER BLOCK
42-21229	SLIDE CONNECTOR
42-21230	TOOL HOLDER, LONGE.TURN ATTCH
42-21231	TOOL MOUNT, LONGE TURN ATTCH
42-21232	GIB
42-21233	SLIDE STRAP
42-21234	SLIDE STRAP
42-21235	ROLLER PIN
42-21236	RACE
42-21237	CHUCK NUT,NO.23 AM
42-21239-99	IDLER PULLEY

PART #	DESCRIPTION
42-21240	CAP
42-21241	SPRING, PLUNGER
42-21242-1	ADJUSTING KNOB
42-21243	PLUNGER SPRING, BELVILLE TYPE
42-21244	PLUNGER SLEEVE
42-21245	SCREW,SHLDR
42-21246	SHEAR PIN
42-21247	SPACER
42-21248	PULLEY AND ARM
42-21249	SPROCKET AND ARM
42-21250	MOTOR SPROCKET
42-21253	GASKET
42-21254	PLATE
42-21256	COVER
42-21258-1	PIPE
42-21262	NAMEPLATE
42-21270	KEY
42-21272	SHAFT NUT
42-21328	NUT
42-21430	CLEVIS, CABLE
42-21431-2	LEVER,CONTROL
42-21432	CABLE LINK
42-21433	SUPPORT,SPRING
42-21434-2	STUD, CABLE
42-21435	ROLL STUD
42-21436	DEFLECTOR ROLL
42-21437	BRACKET,CABLE
42-21439-99	CLAMP BUSHING, WITH FLAT
42-21439-R	CLAMP BUSHING, WITH RADIUS
42-21440-K	KIT, CABLE OPER DEFLECTOR
42-21441-1	LEVER CAM
42-21442	BEARING RETAINER
42-21444	MOUNT COVER
42-21445	GASKET, FILTER MOUNTING COVER
42-21446	INLET TUBE
42-21450	WASHER, SPRING
42-21453	TORQUE LIMITER

PART #	DESCRIPTION
42-21457	WASHER, GRAPHITE LABRYRINTH
42-21458	NUT, FRONT BOX
42-21459	THRUST WASHER
42-21460	SPACER
42-21461	SPACER
42-21463	NUT
42-21465	SPIN SPRKT
42-21465-ZZ	SPROCKET, SPINDLE (OVER BORE)
42-21466-K	KIT, PUMP GEAR
42-21518	CAM ROLL
42-21519	CAM ROLLER PIN
42-21520	SPIN REAR BOX
42-21521	BELTING
42-21558	PLUNGER,CHUCK N FEED GEAR
42-21559	BRACKET,OPERATING SHOE
42-21560	UP SLIDE STRAP,LARGE
42-21561	UP SLIDE STRAP SM
42-21562	OIL PIPING ARR
42-21564	GIB,UPPER SLIDE
42-21566	UP SLIDE ADJ DIAL
42-21566-1	UPPER SLIDE ADJ DIAL
42-21568	OILER
42-21569	TOOL HOLDER 1"
42-21570	UP SLIDE STRAP LG
42-21571	UP SLIDE STRAP SM
42-21572	PLATE SHOE
42-21573	COVER
42-21575	GUARD
42-21576	MTG CLIP
42-21576-1	MTG CLIP,COOL PIPING
42-21577	CONT LVR SUPPORT
42-21580	COVER
42-21581	WRENCH,HEX&PIN
42-21583	COLLAR,TUBE
42-21584	BLK SUPPORT
42-21585	PIN,SHEAR
42-21586	SHEAR PIN KIT

PART #	DESCRIPTION
42-21587	SHEAR PIN
42-21588	SPROCKET
42-21589	FEED TUBE EXT 15/16-20
42-21590	CHUCK SLEEVE, OUTER-NO.11
42-21591	CHUCK SLEEVE, INNER #11
42-21592	FEED TUBE EXT. 1-7/16 - 20
42-21594	CHUCK SLEEVE (INNER)
42-21595	FEED TUBE EXT. 1 13/16 - 20
42-21596	SLEEVE, CHUCK
42-21597	CHUCK SLEEVE (OUTER)
42-21598	CHUCK SLEEVE (INNER)
42-21599	CHUCK SLEEVE, INNER
42-21600	CHUCK NUT
42-21601	CHUCK SLEEVE (OUTER)
42-21602	CHUCK SLEEVE (OUTER)
42-21603	CHUCK SLEEVE (INNER)
42-21605	NUT STUB COLLET
42-21606-K	DOUBLE GRIP, 22DS 1-5/8"
42-21608-K	DOUBLE GRIP #22-2"
42-21610-K	DOUBLE GRIP #11 3/4"
42-21611-K	DOUBLE GRIP #22 1- 5/8"
42-21634	ANTI VIBRATION SHOE
42-21635	SPRING
42-21636	DOG, TRIP, UNIVERSAL W/ T-BOLT
42-21636-NF	DOG, TRIP, UNIVERSAL NO T-BOLT
42-21638	TOOL WEDGE
42-21639	SUPPORT BAR
42-21640	SUPPORT BAR EXT
42-21650	PLUNGER
42-21651	SPRING PLUNGER HEAD
42-21652	SPRING
42-21653	ROLL, CAM
42-21654	CAM SHFT NUT
42-21656	COLLAR, LONG
42-21657	SPACER BUSHING
42-21660	MOUNTING BRACKET
42-21663-1	MTG PLATE

PART #	DESCRIPTION
42-21671	CAM SET
42-21684	CLUTCH BUSHING
42-21685	RETAINER
42-21686	CLIP, GUARD
42-21687	CLIP, GUARD
42-21688	GUIDE, OIL TUBE
42-21689	GIB, UPPER SLIDE
42-21691	HOUSING WASHER
42-21692	SPRING
42-21702	CAM LEVER
42-21703	LEVER PIN
42-21705	CONNECTING BLOCK
42-21709	PIN, LINK
42-21711	LEVER STUD
42-21712	SCREW LONGITUDE
42-21713	DIAL LONGITUDE
42-21715	SPRING INNER
42-21716	SPRING, OUTER
42-21717	TUBE
42-21718	SHOE
42-21720	LOCATING PIN
42-21721	TOOL HOLDER
42-21722	GIB
42-21723	TOOL WEDGE
42-21724	SHEAR PIN (K)
42-21726	LEVER SPACER
42-21727-1	OILER, CLUTCH
42-21728	DOG, TRIP (4 SPEED) W/ T-BOLT
42-21728-NF	DOG, TRIP, 4 SPEED, NO T-BOLT
42-21729	T BOLT, TRIP DOG
42-21731	HOLDER, DISC
42-21732	CARRIER, DOG
42-21734	SPACER
42-21735	MOUNTING BRACKET
42-21736	LEVER LINK
42-21737	OPERATING SHAFT
42-21738	SLIDE WAY

PART #	DESCRIPTION
42-21738-0-Z	SLIDE WAY PART
42-21739	SLIDE
42-21740	OPERATING PLATE
42-21743	TOOL HOLDER
42-21744	CLAMP PIN
42-21745	TOOL CLAMP
42-21747	SPACER
42-21748	LINK
42-21750	DOG, TRIP, CHUCK CLUTCH
42-21750-NF	DOG, TRIP, CHUCK CLUTCH
42-21752	RETAINER
42-21753	NUT
42-21754	BRKT, BRAKE
42-21758	GUARD
42-21761	GIB
42-21763	WASHER
42-21764	WASHER
42-21765	SCREW
42-21766	COVER PLATE
42-21768-1	HOLDER ARM
42-21769	WORK HOLDER
42-21803	SPRING
42-21809	RETAINER ROD
42-21810	SPRING RETAINER
42-21820	TAPERED PIN
42-21920	COIL, ELECTOMAGNETIC CLUTCH
42-21921	CLUTCH DISC REPLACEMENT KIT
42-21922	COIL & HOUSING ASSEMBLY
42-21923	CLUTCH DISC REPLACEMENT KIT
42-21924	COIL & HOUSING ASSEMBLY
42-21932	SPRING
42-21982	DISK
42-21983	PLUNGER
42-21984	SPACER
42-21985	SPACER
42-21986	SPRING, DISC
42-21988	JOURNAL, MOTOR BRACKET

PART #	DESCRIPTION
42-21989	JOURNAL,MOTOR BRACKET
42-21990	GASKET
42-21991	PAN
42-21993	GUARD
42-21993-A	SCREW MACHINE RELATED ITEM
42-21994	WORKPIECE STOP
42-21995	BAFFLE
42-21996	MOUNT ANGLE
42-21997	DOG, LOW-LIFT
42-21998	SPRING
42-21999	SPRING
42-22007	SKIRT
42-22009	ENCLOSURE SKIRT
42-22017	HOSE CONNECTOR
42-22030	PANEL CLIP
42-22036	OIL GUARD
42-22038	GASKET
42-22044	ENCL PANEL CLIP
42-22045	BUMPER, RUBBER FOR ENCLOSURE
42-22046	BLOCK, RUBBER
42-22047	GUARD
42-22054	PLASTIC, GUIDE
42-22055	SLIDING GUARD WINDOW,RIGHT
42-22060	END GUARD
42-22062	PANEL CLIP
42-22070-1	ENCLOSURE BELT LEFT
42-22073	RAIL RETAINER
42-22073-1	RETAINER RAIL FRONT
42-22075	BLOCK
42-22076-1	RETAINER,RAIL LT.REAR
42-22077-1	RETAINER RAIL RT.REAR
42-22083	OIL GUARD
42-22087	OIL GUARD SIDE
42-22099	LEFT CLIP
42-22102	BRACKET COVER
42-22103-1	BRACKET,PIVOT
42-22112	BOX COVER

PART #	DESCRIPTION
42-22115	SEAL,OIL
42-22124	PANEL CLIP
42-22125	SUPPORT ROD
42-22135	SUPPORT CLIP
42-22136	SUPPORT CLIP
42-22137	BRACKET SUPPORT
42-22144	PAD
42-22156	BRKT COVER
42-22166	GASKET
42-22172	OIL GUARD
42-22174	DRIP PAN GUARD
42-22184	SUPPORT ARM
42-22185	CONTROL LEVER
42-22187	GUARD CLIP
42-22194	FELT WASHER
42-22208	CABLE
42-22209	LEVER HUB
42-22211	CLAMP, CONDUIT
42-22212	SPINDLE COVER
42-22215	SHIELD,OIL
42-22225	BRKT CLIP
42-22227	CLAMPING STRAP
42-22231	ENCL SLIDING GD WINDOW
42-22232	LIGHT BRACKET
42-22233	ED WINDOW
42-22236	HOOK,STOCK
42-22240	COVER PLATE
42-22244	GD LATCH CLIP
42-22246	SPLASH GUARD,REAR
42-22247	SPLASH GUARD,RIGHT
42-22255	ATT WIRES
42-22266	LATCH HANDLE
42-22268	FLTING CHIP SHIELD
42-22271	PANEL WIRES
42-22280	KIT,LUBRICATION
42-22281	RAKEOUT PL EXTENSION
42-22282	SPACER

PART #	DESCRIPTION
42-22289	SHIELD,ENCL REAR OIL
42-22290-1	CLUTCH SLEEVE FIBRE
42-22290-1ZZ	CLUTCH SLEEVE (EXTRA GROOVE)
42-22297-1	MOTOR BRACKET CUSHION
42-22300	SEGMENT
42-22302	PLATE,STOCK STAND
42-22306	SLEEVE,FEED PLUNGER
42-22307	PLUNGER, FEED LATCH
42-22309	ROL BRG CAGE RING
42-22310	SHAFT
42-22311	SPACER,SPINDLE DRIVE
42-22312	CLUTCH GEAR
42-22313	DRIVER CLUTCH
42-22316	POINTER
42-22317	SHAFT, CAM
42-22317-S-1	SCREW MACHINE RELATED ITEM
42-22318	SPLASH GUARD ENCLOSED R
42-22320	WORM SHAFT
42-22321	BRKT,SERVO
42-22322	WASHER,CHANGE GEAR R
42-22323	SPACER
42-22324	CLAMP
42-22325	SLEEVE
42-22327	RETAINER
42-22328	CLAMP
42-22329	POINTER
42-22335	SLEEVE
42-22345	TURRET LEVER
42-22348	CNC #1 CAM
42-22349	CAM #4
42-22352	CAM #2
42-22353	CLAMP
42-22354	SLEEVE
42-22357	STRAINER,TUBING
42-22358	VALVE,TUBING ASS'Y
42-22360-81	SUP.COLUMN CAB. ITEM F
42-22362	LUB JUNC BRACKET

PART #	DESCRIPTION
42-22363	BRKT
42-22364-1-81	19" LONG HINGE
42-22365	LEVER,TRIP
42-22365-2	LEVER,TRIP
42-22366-1	TRIP LEVER ABUTMENT
42-22367-2	BRKT,CYLINDER MTG
42-22368	PIN
42-22369	CLEVIS
42-22370	BRKT
42-22371	CLIP
42-22372	CLIP
42-22373	CUP-CLUTCH DRIVING
42-22377	BRKT
42-22378	BRKT
42-22386	GUARD
42-22388-1	STRAP,UPR DRV GUARD
42-22389	TOOL PAN
42-22391	GUARD
42-22396-1	BUSHING,BASE DRAIN
42-22397	STUD
42-22406	GUARD
42-22415	BASE PLATE
42-22416	GASKET
42-22422	WINDOW
42-22427	PLATE
42-22428-1	PUSHER
42-22429	GUARD
42-22430-1	BLOCK,PUSHER
42-22432	TROUGH,WORM
42-22436-1	BLOCK,SWITCH MTG BRKT
42-22437	PLATE
42-22439-1	GUARD,TURRET SLIDE
42-22445	FRAME
42-22456	SPACER FD BRKT SUPPORT
42-22461	COVER CAM SHAFT GD
42-22462	BRG RETAINER
42-22463	NUT,SPHERICAL

PART #	DESCRIPTION
42-22465	BALL SCREW
42-22467	HOUSING
42-22468	CONICAL SEAT
42-22469	SPHERICAL WASHER
42-22470	BRKT BRG
42-22472	ADAPTER
42-22474	PULLEY
42-22475	PULLEY
42-22476	SPACER
42-22477	PULLY, MOTOR FLANGE
42-22479	CLAMP
42-22480	GUARD
42-22481	GASKET
42-22483	BRKT DIE CLOSER
42-22490	SEAT, LEVER
42-22491	POINTER-TURRET SLIDE
42-22492	MARK-TURRET SLIDE
42-22493	HOLDER-OIL TUBE
42-22499-1	FILTER ASSEMBLY
42-22518	MOUNTING RAIL
42-22521	BEARING RETAINER
42-22522	COUPLING SHAFT
42-22524-1	BRACKET
42-22527	LIMIT SWITCH TRIP DOG
42-22529	BEARING SPACER
42-22538-1	KIT FOR LUBRICATOR PUMP
42-22538-1-F	FILTER FOR 42-22538-1
42-22539	KIT, BELT -DRIVE PULLEY
42-22541	IDLER PULLEY ASSY
42-22543	SPINDLE BRAKE YOKE 2"
42-22544	COUNTER MTG PLATE
42-22545	MOUNTING PLATE-GASKET
42-22546-1	COUNTER KIT
42-22553	SWITCH BOX GASKET
42-22554	NAMEPLATE-ULTRA CNC
42-22556	TEE NUT
42-22557	CLAMP WASHER

PART #	DESCRIPTION
42-22563	STRAP,SUPPORT
42-22569	REV. SWITCH COMPLETE
42-22577	CAM ROLL, WITH CHROME ID
42-22577-ZZ	ROLL, CAM, NO CHROME ID
42-22579	SLINGER-OIL
42-22580	PLUNGER-SLEEVE SHOE
42-22583	MTG BRKT,TUBE CLIP
42-22586	STUD ROLLER
42-22587	BRKT,SPDL BRAKE
42-22592	SHAFT,RESOLVER PULLY
42-22594	SPACER,BEARING OD
42-22595	PULLEY-RESOLVER
42-22599	YOKE-SPINDLE BRAKE
42-22600	YOKE-3/4 SPDL BRAKE
42-22602	MTG BLK PUSHER
42-22603	SPACER,RESOLVER BRKT
42-22604	GUARD SPINDLE BREAK LEVER
42-22606	PRINTED MATTER-BOX OF
42-22610	PULLEY-1 5/8 SPINDLE
42-22611	PULLEY-2,2 3/8 SPINDLE
42-22612	FULCRM ASY-CHUCK LVR
42-22614	FULCRUM AND PULLEY
42-22615	GUARD,BELT FRONT
42-22616	GUARD,BELT REAR
42-22617	CABLE,RESLVR FEDBACK
42-22620	SHAFT,TRIP LEVER
42-22621	GEAR-TURRET DRIVING
42-22623	SPACER,TRIP LEVER
42-22624	FULCRUM,STOP LEVER
42-22625	GUARD, TURRET
42-22626	BUSHING,TURRET OIL
42-22627	CLAMP PLATE-OIL BUSH
42-22631	FEED LATCH ASSM 2 & 2-3/8
42-22631-1	FEED LATCH ASSM. 2 & 2-3/8
42-22633	GASKET,RECEPT COVER
42-22634	MTG PLATE
42-22635	GASKET,MTG PLATE

PART #	DESCRIPTION
42-22637	BRACKET UP R OIL GD
42-22640	ACOUSTICAL PAD-LEFT
42-22644	TURRET SLIDE CHIP GUARD
42-22645	CAM SH.BRG. IN.SPACER
42-22646	TRANS. MECH.CAM SHAFT
42-22650-1	KIT FOR LUBRICATOR
42-22652	FEED TUBE PIN HANDLE
42-22654	FILTER RETAINER
42-22660	SPRING BUSHING-RIGHT
42-22661	CONDUIT,1/2"
42-22663	BRAKE MOTOR SHIELD
42-22664	SHIELD BASE PLATE
42-22666	BASE PLATE BRACKET
42-22668	EXTENDED CHUCK KEY
42-22669	TRIP LEVER CLEVIS
42-22670	CYL. BRKT. SPACER
42-23384	STOP NUT MOTOR BRACKET
42-23393	SLIDE STRAP
42-23395	LIGHT, WORK (WAS 414-219)
42-23396	CABLE ASSY,I/O INPUT CON
42-23398	CBL.ASY.I/O OUTPUR PW.CON
42-23399	CABLE,RESOLVER (A-D)
42-23400	CABLE,RESOLVER (B-C)
42-23401	CABLE,RESOLVER (W)
42-50020	TOOLHOLDER LOCATING PIN
42-50021	ADJ.STUD,3RD&4TH SLIDEWAY
42-50024	SPHERICAL WASHER
42-50027	ADJUSTING STUD HOLDER
42-50050	STOCK STOP CLAMP BUSHING
42-50051	SWING STOP CLAMP BUSHING
42-50052	SWING STOP CLAMP SCREW
42-50104	DRIVESHAFT BELT, 120 RPM OPEN
42-50105	DRIVESHAFT BELT,120RPM CROSSED
42-50122	NUT,SPINDLE THRUST,LEFT
42-50123	NUT, FRONT BOX
42-50124	FRONT SPINDLE BOX LOCKWASHER
42-50128	TURRET RACK BAR

PART #	DESCRIPTION
42-50129	SCREW,TURRET SLIDE ADJUSTING
42-50132	CHANGE SHAFT PLUNGER
42-50141-1	STOCK PIPE STOP
42-50142	STOCK PIPE COLLAR
42-50195	FLASHER UNIT
42-50202	JUNCTION BAR (8 HOLE)
42-50205	ACCELERATOR CABLE STOP
42-50217	TERRY CLIP
42-50223	STUD
42-50224	SCREW MACHINE RELATED ITEM
42-50239	BUSHING
42-50245	OIL CAP
42-50248	OPERATING FORK SHOE
42-50251	OPERATING SPRING BUTTON
42-50265	SPINDLE DRIVE SHAFT SPACER
42-50270	COLLAR SCREW
42-50271	JUNCTION BAR WASHER
42-50277	SPHERICAL SEATING
42-50284	STRIKER
42-50291	SPACER,TURRET GEAR
42-50294	TURRET PLUNGER SPRING SCREW
42-50308	PLUNGER SPRING
42-50346	TURRET CHG ROLL DISC (8-HOLE)
42-50348	TURRET DISC
42-50424	SHEAR PIN BUSHING
42-50437	
42-50442	VERT SLIDE FORM TOOLHOLDER
42-50448	OIL CHECK PLATE
42-50873	NOSE OIL GUARD
42-50896	RETAINING RING
42-50937	TUBING SLEEVE
42-50974-1	TURRET SPRING
42-50974-2	TURRET SPRING
42-51037-1	TURRET TOOL OIL GUARD
42-51097	INDEX INSTRUCTION PLATE
42-51103	NYLON WASHER
42-51295	FEED CHANGE GEAR, 35T

PART #	DESCRIPTION
42-51296	FEED CHANGE GEAR, 36T
42-51297	FEED CHANGE GEAR 41T
42-51300	FEED CHANGE GEAR, 53T
42-51306	FEED CHANGE GEAR, 67T
42-51307	FEED CHANGE GEAR,72 TEETH
42-51311	WORM WHEEL
42-51312	WORM
42-51314	WORMWHEEL SHAFT
42-51315	CROSS SLIDE CAMSHT GEAR
42-51316	GEAR
42-51320	WASHER
42-51321	ADJ. WASHER, SMALL
42-51323	END CAP
42-51391	SCREW HOLDER (1/2" CAP)
42-51392	SLOTING BUSHING BLANK
42-51467-ZZ	TURRET SLIDE RACK
42-51468	ADJUSTING SCREW
42-51469	THREADED PIVOT PIN
42-51470	LINK
42-51474	ROLLER
42-51475	ROLLER PIN
42-51476	PIN
42-51478	PIN
42-51492	CHANGE GEAR COLLAR
42-51527	SPDLE SPROCKET BRG RET SPRING
42-51608	TURRET HANDLE
42-51610	CONNECTING ROD BUSHING
42-51626	IDLER SPROCKET, RIGHT
42-51649	SPACER
42-51706	CHAIN DRIVE PULLEY
42-51708	CHUTE
42-51708-1	CHUTE
42-51712	PICK-UP ARM
42-51719	END CAP
42-51723	CHAIN GUARD
42-51727	SCREW MACHINE RELATED ITEM
42-51729	COLLET HOLDER (1/2" CAP)

PART #	DESCRIPTION
42-51834	DRIVING PULLEY SHAFT
42-51835	BACKSHAFT CHANGE GEAR 85T
42-51836	CHANGE GEAR 60T
42-51853	REVERSING CLUTCH
42-51856	SPINDLE SPEED PLATE, 1/2" 2 SP
42-51926	STOCK PIPE SUPPORT
42-51934	SCREW MACHINE RELATED ITEM
42-51934-0-Z	MOTOR APAPTOR PLATE, LH
42-51935	85T BACKSHAFT GEAR 120 RPM
42-51943	MOTOR ADAPTOR PLATE LH
42-52011	CHUCK LEVER FULCRUM 1/2" CAP
42-52014	THD MILL SPROCKET GUARD
42-52033	GEAR
42-52104	THD MILL SPROCKET GUARD
42-52105	TOOL SUPPORT
42-52142	BLANKING PLATE, REAR
42-52336	GEAR BRACKET
42-52337	SPINDLE
42-52338	SPACER
42-52339	GEAR SLEEVE
42-52340	GEAR SPACER
42-52341	GUARD
42-52462	ECCENTRIC INSERT
42-52492	GIB, CROSS SLIDE REAR
42-52507	PLATE
42-52591	PIN WRENCH SPECIAL
42-52592	TIE STRAP
42-52595	RACK SUPPORT
42-52598	CHUCK FORK SPECIAL
42-52605	RACK
42-52606	RECESSED SPACER
42-52607	GEAR SLEEVE (MOD)
42-53017	MINI 16 PIN
42-53027	GIB, MINI 16
42-53027-1	GIB, CROSS SLIDE MINI-16
42-53041	CROSS SLIDE THRUST SCREW
42-53043	CROSS SLIDE LEVER PIN

PART #	DESCRIPTION
42-53066	BAR
42-53285	MINI 16 SCREW
42-53342	PIVOT
42-53384	LOCK NUT, MINI 16
42-53399	BEVEL GEAR DRIVEN, MINI 16
42-53401	LEAD CAM SHAFT NUT
42-53466	MINI 16 BUSHING
42-53490	MINI 16 CLUTCH
42-53494	BEARING BOX
42-53511	MINI 16 SHAFT
42-53512	CAMSHAFT SPACER, MINI 16
42-53519	SWING STOP ARM, MINI 16
42-53536-1	THRUST PIN, MINI 16
42-53537	PIVOT PIN, MINI 16
42-53570	MINI 16 PIN
42-53624	LINK PIN (UPPER) MINI 16
42-53641	LATCH SUPPORT PLATE
42-53642	LATCH SPRING
42-53752	MINI 16 DISC
42-53785	MINI 16 CAM
42-53790	OIL GUARD SLEEVE
42-53831	TOOLHOLDER, SQUARE TOOLS
42-53937-1	DRIVE CLUTCH
42-53938-1	CLUTCH
42-53971	MINI 16 NUT
42-53972	MINI 16 NUT
42-53977	MINI 16 SHOE
42-54095	MINI 16 BUSHING
42-54097	SCREW MACHINE RELATED ITEM
42-54109	MINI 16 SLEEVE
42-54139	ROPE TUBE
42-54166	MINI 16 FULCRUM
42-54172	SHAFT
42-54223	BLANK
42-54245	PRESSURE PLATE
42-54248	PRESSURE PAD PIN
42-54252	H S PUSHER TUBE

PART #	DESCRIPTION
42-54254	MILI 16 TIP REF:MELBOURNE
42-54319	COLLET BLANK (1/2" CAP)
42-54379	V-BELT SHEAVE (DRIVER)
42-54539	SPINDLE
42-54540	NUT,CHUCK ADJUSTING/MINI 16
42-54543	CHUCK FORK SHOE
42-54615	SHAFT
42-54616	BUSHING
42-54618	BUSHING
42-54623	BLANK
42-54627	2B PART
42-54630	PLUNGER
42-54631	DRIVE CLUTCH
42-54640	WASHER
42-55038	GEAR 90T
42-55067	LEGEND R.A.
42-55073	REAR ATTACH COND WIRE AS
42-55083	NAME PLATE
42-55086	SPD PLATE 19-2SP 00U
42-55088	PLATE
42-55090	PLATE
42-55091	PLATE
42-55107-0-10	PLATE, TURRET CHANGE SHAFT
42-55111	PLATE
42-55133	COUNTER SETTING PLATE
42-55140-1	LIMIT SWITCH HOUSING
42-55184	CLUTCH SHAFT
42-55197	HOUSING
42-55262	ROLLER
42-55278	GEAR, 42T
42-56002	CHANGE GEAR SPACER
42-56006	BEARING
42-56011	WASHER
42-56012	FEED TUBE,2B
42-56013	SPINDLE REAR BRG SPACER 3/4"
42-56015	WASHER
42-56025	NEEDLE BEARING

PART #	DESCRIPTION
42-56026	NEEDLE BEARING
42-56028	THRUST RACE
42-56029	NEEDLE BEARING
42-56038	LOCKING BUSH, TURRET
42-56039	PIN, TURRET LOCKING
42-56058	BRONZE BEARING
42-56059	NEEDLE BEARING
42-56070	IDLER BRACKET RETAINING RING
42-56090	OIL LABYRINTH GASKET
42-56100	WORM SHAFT
42-56103-1	WORK HOLDER ARM, SWAN NECK
42-56105-1B	BRARINGS FOR CLUTCH 42-56105
42-56107	CL.SHFT.DRVG.GEAR SPACER
42-56124	BALL BEARING
42-56127	CIRCLIP
42-56152	DRIVING PULLEY (24 GROOVE)
42-56153	NEEDLE BEARING
42-56155	EXTRA LIGHT BALL JOURNAL
42-56171	GUARD, REAR
42-56174	GUARD, FRONT
42-56183	LIMIT SWITCH
42-56196	BACKING PLATE
42-56197	DRIVING PLATE
42-56198	SPROCKET BUSHING
42-56246	QUADRANT PAD
42-56249	SCREW FASTENER
42-56253	JUNCTION BAR (5 WAY)
42-56254	JUNCTION BAR (14 HOLE)
42-56261	DRAW BOLT
42-56275	SCREW MACHINE RELATED ITEM
42-56277	BLANK, COLLET
42-56280	PULLY, 20 TEETH W/ FLANGE
42-56281	DRIVE BELT
42-56284	SLEEVE, TURRET DISC DRIVING
42-56304	TIMING BELT
42-56306	ECCENTRIC PIN
42-56308	GUARD

PART #	DESCRIPTION
42-56315	SCREW MACHINE RELATED ITEM
42-56317	EJECTOR
42-56320	GUARD, PULLEY
42-56324	EJECTOR
42-56326	STOP, WORK HOLDER ARM
42-56328	SCREW HOLDER
42-56329	SCREW
42-56330	SLOTING BUSHING BLANK
42-56333	SLABBING HOLDER WORK SUPPORT
42-56334	SLABBING HOLDER PLUNGER BODY
42-56417	ADJUSTING SCREW NUT
42-56444	WORK PAN
42-56459	OIL GUARD ROLLER
42-56468	SPACER
42-56474	SCREW MACHINE RELATED ITEM
42-56499	FEED ADJUSTING SCREW CAP
42-56506	SLOTING CAM ROLL
42-56518	NUT
42-56519	STEM
42-56563	SPRING PIN
42-56565	GIB, CROSS SLIDE
42-56566	PIVOT
42-56567	TENON
42-56568	TEE NUT
42-56573	SLIDE SPRING
42-56573-1	LONG. SLIDE SPRING
42-56577	WASHER
42-56578	LEVER
42-56584-1	BEARING CARRIER
42-56586	BUSHING
42-56665	UNIVERSAL JOINT
42-56675	FULCRUM AND GEAR
42-56692	CHUCK FORK SLVE PLUNGER SHOE
42-56693	SPACER,SHORT
42-56695	SPACER RIGHT,IDLER ADJ.ROD
42-56712	TURRET SLIDE RACK
42-56713-1	OIL COMPARISON PLATE

PART #	DESCRIPTION
42-56713-2	OIL COMPARISON PLATE
42-56717	SWITCH DOG, 20/100
42-56718	SWITCH DOG
42-56734	CHUCK NUT, 22C
42-56737	OIL COMPRESSION SLEEVE
42-56738	DEFLECTOR PIN
42-56752	NEEDLE BEARING
42-56798	SPROCKET FAN COMPLETE 60 CYCLE
42-56804	OIL TUBE ADAPTOR
42-56808	SPHERICAL SEATING
42-56812	THRUST PLATE
42-56819	SLIPPER PLATE
42-56828	COVER
42-56842	ECCENTRIC SCREW
42-56860	RACK
42-56861-1	WIPER PLATE
42-56864	RACK
42-56865	GEAR SHAFT
42-56866	HEADED BUSH
42-56868	CAM SPACING COLLAR
42-56869	ROLLER,DRIVE
42-56870-1	WIPER PAD
42-56888	BRACKET
42-56909	TAPER PIN
42-57018	SPRING TUBE PLUG
42-57027	NYLON PAD
42-57144	WASHER, GUARD
42-57145	SCREW
42-57187	GEAR,SPECIAL 33 TEETH
42-57205	OVERLOAD SPRING
42-57206	DEFLECTOR CABLE ASSY
42-57283	DEFLECTOR DOG
42-57321-1	PLATE
42-57335	CAMSHAFT GEAR PLUNGER #3
42-57336	PLUNGER
42-57381	SCREW MACHINE RELATED ITEM
42-57431	PLATE,FEED CHART - 3/4 SEC

PART #	DESCRIPTION
42-57443	PIN
42-57444	PIVOT PIN
42-57488	REAR STOCK SUPPORT BRACKET
42-57489	FRONT SUPPORT BRACKET
42-57562	LEAD CAM SHAFT NUT
42-57563	NUT
42-57569	CHUCK SLEEVE, 22C
42-57575	22D ADAPTOR
42-57589	ADJUSTING COLLAR
42-57590	SUPPORT SCREW
42-57591	SUPPORT SCREW (SHORT)
42-57680	INPUT GEAR
42-57715	TAKE-OFF GEAR
42-57716	INTER. GEAR
42-57797	TURRET LOCK PIN SPRING
42-57801	DRIVING COLLAR
42-57816	GIB
42-57821	BUSHING, TURRET TOOL CLAMP
42-57824	CHUCK NUT, 22
42-57844	STOCK PIPE COLLAR
42-58006	CHUCK SLEEVE, 22
42-58054	INTER GEAR 2" CAP
42-58055	TAKEOFF GEAR, 2" CAP
42-58056	INPUT GEAR, 2" CAP
42-58147	SPROCKET
42-58177	BASE PLATE
42-58318	STOCK FEED PLATE
42-58341	SAFETY CLUTCH
42-58365	THREADING ATTACH MTG PLATE
42-58385	60MM LEAD CAM
42-58398	SUPPORT, FRONT STOCK
42-58451-1	CONNECTING SHAFT
42-58468	CAM
42-58484	BUSHING, OPERATING SHAFT
42-58485	OPERATING SHAFT BEARING REAR
42-58488	PLATE SET
42-58523	WORMWHEEL, CAMSHAFT

PART #	DESCRIPTION
42-58526	TRIP LEVER DOG SHAFT
42-58530	FEED TUBE NUT
42-58531	FEED FINGER BODY
42-58532	SPACER, FEED TUBE
42-58543	DOG CARRIER ASSY
42-58543-0-A	ATTACHMENT DOG CARRIER
42-58548	REVERSE TRIP LEVER, LOWER
42-58563	CARRIER PLATE
42-58666	FEED CHANGE GEAR, 70T
42-58667	GEAR
42-58668	FEED CHANGE GEAR, 75T
42-58671	CHANGE GEARS, THREAD CHASER
42-58711	CH. GEAR COVER ASSY
42-58712	WORMWHEEL SHAFT
42-58718-1	LOCKING PIN LEVER
42-58722	TURRET SLIDE RACK
42-58725	ADJUSTING NUT
42-58726	SPACER
42-58746	SHAFT
42-58757	IDLER PULLEY R.H.
42-58759	IDLER SPROCKET SHAFT SPACER
42-58900-1	BASE SLIDE
42-58903-1	UPPER SLIDE
42-58903-2	UPPER SLIDE
42-58906	SPRING BRACKET
42-58911	SPRING ROD
42-58912	SPRING BUSH
42-58913	STOP NUT
42-58914	ROLLER THRUST BLOCK
42-58924	OPERATING ROLLER
42-58925	VERTICAL RACK
42-58926	SHAFT, RACK COVER
42-58927	RACK CAP
42-58929	RACK
42-58930	ROLLER CARRIER
42-58931	RACK GUIDE
42-58968	ADJ. STOP SCREW

PART #	DESCRIPTION
42-58974-1	SPACER
42-58988	STOP SCREW
42-59013	CLAMP WASHER
42-59015	DRIVE GEAR - 1/2" PITCH CHAIN
42-59032	FLEXIBLE PIPE ASSEMBLY
42-59036	FEED FINGER ADAPTOR
42-59037	CHUCK SLEEVE
42-59038	CHUCK NUT
42-59040	COOLANT PUMP DRIVE GEAR
42-59041	GEAR, COOLANT PUMP DRIVEN
42-59042	SCREW MACHINE RELATED ITEM
42-59083	MAIN GUARD
42-59094	SPRING SUPPORT BUSH
42-59103	RETAINING WASHER
42-59104	SPACER
42-59105	SPACER
42-59107	CH. GEAR ARM ASSY
42-59108	CHANGE GEAR STUD
42-59121	SPACER
42-59121-1	SPACER
42-59131	SPINDLE SPROCKET, LEFT
42-59132	SPINDLE SPROCKET, RIGHT
42-59134	CLUTCH FORK
42-59136	SHAFT HOUSING INNER
42-59140	SPACER
42-59141	SPACER
42-59151	SHAFT HOUSING OUTER
42-59153	SPACER
42-59155	SPACER
42-59158	SPACER
42-59159	SPACER
42-59161	SPINDLE SPROCKET, LEFT
42-59162	SPINDLE SPROCKET, RIGHT
42-59165	CHANGE GEAR, 75T
42-59173	PUMP BRACKET
42-59184	SLIDE ADJUSTING SCREW
42-59198	GUARD

PART #	DESCRIPTION
42-59199	CHUCK CLUTCH TRIP LEVER
42-59205	KEY
42-59224	5-WAY JUNCTION BLOCK
42-59261	SHAFT LINK PIN
42-59272	INSTRUCTION PLATE
42-59273	PAD FOR WRENCH
42-59274	PAD, FOR WRENCH
42-59334	DRIVING GEAR, 3/4" CAP ONLY
42-59349	SCREW MACHINE RELATED ITEM
42-59352	STEEL PIN
42-59356	SPINDLE SPROCKET RIGHT
42-59390	SHAFT, LONGITUDINAL SLIDE
42-59392	BRACKET
42-59410	CLUTCH SLEEVE GEAR
42-59411	CLUTCH BEARING SPACER
42-59414	CLUTCH SLEEVE GEAR
42-59477	ADAPTER
42-59481	ADAPTER
42-59507	STUD,DRIVE SHAFT SPROCKET
42-59508	SEAL, OIL LABYRINTH
42-59509	ADAPTOR PLATE
42-59578	ARBOR, SPANNER
42-59637	SPECIAL KEY
42-59675	LEGEND SPINDLE START
42-59676	LEGEND INTERNATIONAL STOP
42-59807	BLOCK,SPACER
42-66192	ACTUATOR RAIL
42-66267	UNIVERSAL JOINT
42-66304	GEAR SHAFT STUD
42-66376	ALLEN KEY
42-66585	SLIDE, CROSS
42-66586	SLIDE, CROSS #2 W/ 2 T SLOTS
42-66607	LIGHT SHIELD BRACKET
42-66608	LIGHT SHIELD
42-66647	SOCKET HEAD CAP SCREW
42-66680	MOD.TO SPINDLE BRAKE LINK
42-66683	MOD. TO CHIP GUARD EXT.

PART #	DESCRIPTION
42-66684	MOD. TO SPINDLE COVER REAR
42-66719	GEAR, 64T
42-66720	GEAR HUB
42-90006	TROUBLESHOOTING, AUTO & CNC
42-90007	TMS LUB ASSEM
42-90013	CNC SOFTWARE MANUAL
42-90014	ENGINEERING MANUAL
42-90015	ADVANCED ENG. MANUAL
42-90016	WORKBOOK, ENGINEERING
42-90017	WORKBOOK, ADVANCED ENGINEERING
42-99990-1	A.S.M. HANDBOOK
42-99990-22	MANUAL,PARTS #2, ATTACHMENTS
42-99990-36	#2G DIMENSIONS
42-99990-40-5	INSTRUCTION SHEET
42-99990-41	PRINTED MATTER
42-99990-46	ATTACHMENT PARTS BOOK,OO ULTRA
42-99990-47	SPD TABLES, 2&3 ULTRA, W/4SPDS
42-99990-60	SPD TABLES,2&3ULTRA W 2 SPDS
42-99990-63	PRINTED MATTER
42-99990-64	SPEED TABLES, OO ULTRA, 4 SPD
42-99990-67	TAG
42-99990-76	OP&MANT BOOK 2&3 ULTRA
42-99990-76-1	MANUAL, OPM & MAINT. #2ULTR
42-99990-77	PARTS BOOK,2&3 ULTRA PRE R/S
42-99990-77-1	PARTS MANUAL, #2 ULTRA R/S
42-99990-78	PARTS MANUAL, OO ULTRA
42-99990-79	MANUAL, OPM OO ULTRA
42-99990-84	#2 ULTRA ATTCHMENT BOOK
42-99990-96	MANUAL, PARTS MINI 16
42-99990-97	PRINTED MATTER
42-99990-102-1	STK STAND ASSY 2 3/8
42-99990-135	CAM LAYOUT PAD, #2 ULTRA (25)
42-99990-136	OP & MANT BOOK 00 ULTRA
42-99990-137	REPAIR PTS BOOK 00 ULTRA
42-99990-150	PAD,CAMLAYOUT, #00 AUTO
42-99990-172	MANUAL, OPM OO ULTRA R/S
42-99990-173-1	MANUAL, OPER & MAINT ULTR CNC

PART #	DESCRIPTION
42-99990-174	MANUAL,REPAIR PARTS
42-99990-175	MANUAL,TOOL HOLDER
42-99990-176	MANUAL,PROGRAMMING
42-99990-176-1	MANUAL,PROGRAMMING CNC
42-99990-184	TM5 LUB. ASSEMBLY
42-99990-5055-3	DIAGRAM, WIRING #2
42-100043M	SHAFT
42-100102	CHUCK KEY, EXTENDED
44-12-99	GIB,STOP HOLDER
44-53802	BUSH
44-53803	SCREWED PIN
44-53899	ADJUSTABLE PIN
44-54002	SCREW MACHINE RELATED ITEM
44-54115	PIN
45-60-1-99	CHUCK FORK
45-61-99	FEED LEVER
45-68	FEED GUIDE
45-70-99	FEED ADJUSTING SCREW
45-71-1	FEED ADJ KNOB
45-72-99	FEED ADJUSTING SCREW CAP
45-73-99	SLEEVE
45-74-1-99	FEED LEVER FULCRUM SHORT
45-75-99	FEED LEVER FULCRUM LONG
45-76-99	CHUCK FORK FULCRUM
45-77	FEED SCALE (ENGLISH)
45-78-99	PLUNGER
45-79-1	FEED POINTER
46-58-99	SCREW HOLDER
46-62-1-99	CLUTCH LEVER
46-72-1-99	CLUTCH LEVER BLOCK
47-197	WORM WHEEL
47-471-99	GIB, TURRET SLIDE OVERSIZE
47-473-99	GIB, TURRET OVER .035
47-476-2-A	TURRET ONLY (W/SLEEVE)
47-673-1	GIB, X-SLIDE FRONT, OVERSIZE
47-673-1-ZZ	GIB
47-674	GIB, CROSS SLIDE BACK OVERSIZE

PART #	DESCRIPTION
47-675-99	GIB, CROSS SLIDE FRONT, OVER-S
47-678-99	GIB,CROSS SLIDE-FRONT
47-679-99	GIB,CROSS SLIDE
47-701-99	BOX SLEEVE
50-21043-1	CARBIDE SHOE
50-21044	ORIFICE,.96MM
50-21055-1	VALVE ACTUATOR SCREW
50-21073	LEVER SHAFT
50-21080	SPRING,CLUTCH
50-21096	RING
50-21111	FITTING WASHER
50-21148	CLAMP BUSHING
50-21150	NUT
50-21155	SHOE
50-21171	SPRING ANCHOR
50-21190	BRG SPACER
50-21191	CLUTCH SPACER
50-21198	LOCKNUT WASHER
50-21205	FITTING WASHER
50-21298	SEAL
50-21311	CAM ROLLER
50-21319	SCREW MACHINE RELATED ITEM
50-21322	ROLL, VALVE
50-21323	CHIP SHIELD
50-21324	VALVE ACTUATOR
50-21339	PIVOT PIN
50-21345	LEVER,STOP
50-21413	FEED TUBE WASHER
50-21475	CONTACT INSULATOR
50-21476-1	CONTACT,DPTH STP SW
50-21479	SWITCH CONTACT
50-21486	TERMINAL COVER
50-21512	GEAR SPACER
50-21521	LEVER WASHER
50-21525	DOG SCREW
50-21537	BUSHING
50-21608	SCREW

PART #	DESCRIPTION
50-21614-2	STUD
50-21615	WASHER
50-21633-1	CHECK NUT
50-21639	FULCRUM
50-21652	CLUTCH INSERT
50-21732	FITTING SPACER
50-21759	FITTING WASHER
50-21771	LINK,FORK
50-21791	ACTUATOR ROD
50-21794	SOLENOID EXT
50-21851	FLX CONCENTRATOR
50-21851-1	FLUX CONCENTRATOR
50-21899	SCREW,STOP
50-21901	SCREW,STOP
50-21910	RAM,DOG
50-21959	NUT RETAINER
50-21967	BEARING BUSHING
50-22052	ACTUATOR ROLLER
50-22069	SPACER
50-22070	SPACER
50-22074	DRIVE DETENT
50-22075	SHAFT SPACER
50-22140	MOUNT SCREW
50-22146	REAR STOP RETURN SPRING
50-22149	SPACER
50-22167	SPRG. RETAINER
50-22171	CLUTCH SPACER
50-22206	SEAL RETAINER
50-22212	STOP SCREW ABUT.
50-22236	CLUTCH END CAP
50-22247	DETENT PIN
50-22284	WEDGE PIN
50-22287	LOCK YOKE
50-22400	WEDGE PIN
50-22406	THRUST WASHER
50-22480	SPRING BUSHING
50-22524	WASHER

PART #	DESCRIPTION
50-22533	ROLL STUD
50-22608	VALVE STUD
50-22610	BUSHING, SPLIT
50-22611	METER UNIT
50-22612-1	CONT BUTTON SLV
50-22613-1	CONTACT BUTTON
50-22637	LEVER FULCRUM
50-22825	SPRING RETAINER
50-22834	MODULE,FRONT BUFFER
50-22835	MODULE,CONTROL
50-22835-55	MODULE,CONTROL
50-22836	MODULE,MEMORY
50-22837-55	MODULE,TIMER
50-22838-55	MODULE,PSC INPUT
50-22839	MODULE,OUTPUT
50-22841	SHAFT WASHER
50-23003	THRUST COLLAR
50-23102	WOODRUFF KEY HDN 611
50-23112	WOODRUFF KEY HDN 610
50-23134	CHUCK SLEEVE PIN
50-23177	SUPPRESS SPPRT ASSY
50-23349	PLATE,IMPACT
50-29013	VALVE REPAIR KIT
50-29014	VALVE REPAIR KIT
50-31056	OPERATING ROD
50-31070	INDEX GEAR SHAFT
50-31078	GEAR CLUTCH
50-31105	MAGNET HOLDER
50-31116	STOP SCREW
50-31121-1	DRUM DRIVE SHAFT
50-31137	SPECIAL GEAR
50-31137-1	DRUM SFT SPIRAL GEAR DRUM
50-31138	GEAR
50-31138-1	DRUM INTMD SPUR GEAR
50-31143	LOCKING RING
50-31168	DRIVE SHAFT LEFT
50-31174	LEVER FULCRUM

PART #	DESCRIPTION
50-31200	SPECIAL LOCKNUT
50-31259	TUBE NUT
50-31268	ADJ NUT
50-31274-1	BOARD,COMMON FUNCTION
50-31274-1-55	BOARD,COMMON FUNCTION
50-31274-2	BOARD,COMMON FUNCTION
50-31275-2-55	BOARD,TURRET W/DEEP HOLE
50-31279-1	BOARD,LONG TURN LOGIC
50-31279-1-55	BOARD,LONG TURN LOGIC
50-31302	SPRING PLUNGER
50-31307	PLUNGER GUIDE
50-31308	CAM PLUNGER
50-31309	SPRING RETAINER
50-31312	ROLLER GUIDE
50-31313	GUIDE RETAINER
50-31316-1	METERING PISTON ROD
50-31318-1	PISTON ROD GUIDE
50-31327	PLUNGER
50-31351	CAM PLUNGER
50-31353	LINK EXTENSION
50-31354	ROLL PIN
50-31437	RAM GIB
50-31495	CHUCK SLEEVE
50-31496	CHUCK SLEEVE
50-31499	COLLET RETAINER
50-31501	CHUCK SLEEVE
50-31566	DISC SPRING (SET OF 12)
50-31567	RECESS ATT DISC SPRING
50-31568-1	REC TUR UNCLP RING
50-31569	TUR CLAMP SPR LOAD WASHER
50-31577	DISC SPRING OPER ROD
50-31578	NUT
50-31583	DRUM INT SHAFT SPIRALGEAR
50-31583-1	DRUM SFT SPIRAL GEAR DRUM
50-31669-2	BOARD,TRACER LOGIC
50-31725	ROD
50-31744	STOP SCREW

PART #	DESCRIPTION
50-31799	ACTUATOR LATCH
50-31867	SLINGER
50-31955	CHASING GIB
50-32014	DRIVE PULLEY
50-32015	FULCRUM
50-32062	VALVE ADAPTER
50-32063	FEED DOG RAMP
50-32080	CLUTCH COUPLING
50-32126	COLLECT RETAINER
50-32127	COLLET RETAINER
50-32133	FRICTION SEAL WASHER
50-32134	SPINDLE NOSE GUARD GASKET
50-32168	VALVE SPACER
50-32207	LOCKING BRACKET
50-32208	PLUNGER EXT
50-32209	RELIEF PISTON
50-32234	CLUTH BODY
50-32235	DRIVEN RING
50-32237	CLUTCH SHAFT
50-32244	DETENT PLUNGER
50-32250	MIN DIAL
50-32254	POSITION RING
50-32257	WHEEL DETENT
50-32302	SWITCH HARNESS
50-32321	INDEX COMPLETE
50-32351	VALVE HARNESS
50-32352	SWITCH CABLE
50-32404	PLUNGER HOUSING
50-32409	FLO CONT VALVE INDICATOR
50-32410	SCALE SPACER
50-32412	SPRING RETAINER
50-32451	DRIVER, LOGIC
50-32473	RETAINER
50-32566-1	DIAL
50-32576	SWITCH HARNESS
50-32750-1	BOARD
50-32828	SHAFT NUT

PART #	DESCRIPTION
50-32852	CAM SHFT NUT
50-32911	SUPPRESSOR ASSEMBLY
50-32929-1	RTNR, DRILL SPIN BRG
50-32939	GASKET
50-32971	NUT
50-33071	FEED TUBE ADJUST NUT
50-33073	CHK VALVE HSG BOTTOM
50-33074	CHK VALVE HSG TOP
50-33288	ADAPTER ENCODER (D.R.C.)
50-33308	PIN,REC DEPTH STOP
50-33428	LINK,SOLENOID
50-41007	UNCLAMP LEVER
50-41022	CAM LEVER
50-41034	FEED TUBE
50-41069	LEVER SHAFT
50-41074	DRIVE GEAR
50-41079	WORM WHEEL
50-41086	MOUNT SHAFT
50-41146-2	8 TOOL ROUND TURRET
50-41149	FEED RATE SCALE
50-41149-1	SCALE
50-41160-1	SHIELD,OIL,INNER
50-41162	SEAL
50-41166	GIB
50-41175	GEAR
50-41178	SPEED SHAFT
50-41179	SPEED SHAFT
50-41181	DRIVEN GEAR
50-41184	DRIVEN GEAR
50-41186	CLUTCH GEAR
50-41188	SPEED SHAFT
50-41203-1	DRUM SHAFT GEAR
50-41208	CLUTCH SPIDER
50-41209	CLUTCH GEAR
50-41269	FORK SLEEVE
50-41296	LABYRINTH SEAL GASKET
50-41304	VALVE LEVER

PART #	DESCRIPTION
50-41333-1	COVER F/F VLV BLOCK
50-41379-2	CH & FD WORM WHEEL
50-41395	SLIDE WIPERS
50-41404	CLUTCH GEAR
50-41411-1	SHIELD,OIL,OUTER
50-41412	LEVER FULCRUM
50-41426	GASKET
50-41428	GASKET
50-41451	MODULE,TIC TAC
50-41467	OIL GUARD
50-41477	SWITCH HOUSING
50-41535	CHUCK GUARD
50-41704-1	DIAPHRAGM SPRING BLK
50-41729	SUPPORT
50-41741	COVER
50-41949	LONGITUDINAL BALL SCREW
50-41950-1	BALL SCREW,CROSS FEED
50-41986	FRONT SLIDING DOOR WINDOW
50-42067	FEED DOG
50-42135	SPINDLE EXT
50-42269-1	ARM,FR STK SWINGING
50-42270	STOCK SUPPORT, OPERATING
50-42476	COLLET SLV 22
50-42477	SLEEVE INNER 22
50-42808	RETURN TUBE
50-43064	TUR SL GIB OVER SIZE
50-43072	CHECK VALVE HOUSING
50-43152	DRUM DRV SHAFT SHORT
50-43295	ABUTMENT, RECESS STOP
50-43385	ADJ NUT, STK TUBE SP
50-43396	VALVE, CHECK XSL
50-51156	FORK,CHUCK
50-51300-1	BLOCK,FAST/FEED VALVE
50-51306	VALVE BODY
50-51335-1	BLOCK,FEED OUT VALVE
50-51338-1	BLOCK,F TO F VALVE
50-51349-1	BLOCK,FEED OUT VALVE

PART #	DESCRIPTION
50-52267-1-80	STAND, FRONT STOCK
50-52267-1-81	STAND, FRONT STOCK
50-52267-1-82	STAND, FRONT STOCK
50-52267-1-88	STAND, FRONT STOCK
50-52268-1	STAND, REAR STOCK
50-99990-25	MANUAL, OPERATION & PROGRAM
50-99990-26	MAINTENANCE PTC MANUAL
50-99990-27	COMPONENT PART
50-99990-37	MANUAL, PARTS (PTC)
50-99990-40	REPLACEMENT PARTS MANUAL
50-99990-43	MANUAL, COLLET & TOOL EQ.
50-99990-45	MANUAL, ELECTRO. SERVICE
50-99990-46	MANUAL, PARTS 2ND EDITION PTC
50-99990-48	MANUAL, PTC PROGRAMMING
50-99990-49	MANUAL, PTC OPER
51-23-502C-99	ROLLER
51-27-503B-99	CVA-8 PART
51-35-503B-99	CLUTCH ADJ. PLUNGER
51-37-503B-99	BEARING CAGE
51-44-503B-99	WEARING RING
51-48-501D	LOCK RING
51-50-501D-99	DUST SHIELD
51-54-501D-99	CHUCK LEVER CVA 20
51-60-503B-99	ADJ. NUT
51-64-502C-99	SHOE, CLUTCH (2A-64)
51-67-502C-99	CLUTCH TOGGLE PIVOT
51-68-502C-99	CLIP
51-70-503B-99	BOX LINER
51-71-502C-99	PLATES, 19-2
51-71-OS-503B	INSERT
51-79-503B-99	SCREW
51-87-503B-99	BRASS PAD
51-128-503B-99	UK MFG PART
51-135-503B-99	ROLLER CAGE (3A135)
51-160-503B-99	PIN, PIVOT
51-173-503B-99	BUSH
51-175-503B-99	TURRET LOCKING PIN (1007)

PART #	DESCRIPTION
51-181-503B-99	TURRET CHANGE ROLL STUD
51-186-503B-99	SINGLE INDEXING DOG
51-187-503B-99	BUSHING, INDEX
51-187A-503B-99	WASHER, EXTRACTION
51-189-503B-99	BOLT
51-203-503B-99	TURRET CHANGE ROLL STUD NUT
51-247-501D-99	SCREW
51-343-503B-99	NUT
51-344-503B-99	BLOCK
51-356-503B-99	CAMSHAFT STOPPING DISC
51-392-503B-99	COLLAR
51-491-503B-99	GRUB SCREW
51-621-503B-99	CHUCK CLUTCH
51-630-503B-99	TAPER PIN
51-717-503B-99	RACK-FRONT
51-770-502C-99	FEED ARM PIN
51-1042-503B-99	CLUTCH OPERATING SCREW
51-1043-503B-99	LOCKNUT
51-1052-503B-99	COVER LATCH
51-1242-501A-99	CROSS SLIDE CAM ROLL PIN
51-2022-503F-99	BACKING PLATE (3AV2022)
51-2033-503F-99	TOOL WEDGE (3AV2033)
51-2034-503F-99	DOWEL (3AV2034)
51-2383-503F-99	SLOTING LEVER BUSH
51-2384-503F-99	SLOTING CAM LEVER ROLL
51-2385-503F-99	ROLL PIN
51-2391-503F-99	ROTATING CAM LEVER ROLL
51-2392-503F-99	CAM ROLL PIN
51-2475-503F-99	PLATFORM
51-2476-503F-99	EJECTOR PLATE
51-2478-503F-99	SLOTING BUSH HOLDER
51-40087-9X-99	NUT, FOR SCREW (67-8)
51-40088-2X-99	NYLOC NUT
51-40740-8E-99	SCREW
51-40742-4X-99	SCREW, CUP POINT
51-40757-0X-99	SCREW
51-40757-1X-99	SOC HD CAP SCREW

PART #	DESCRIPTION
51-40758-9X-99	SCREW, [BRIT.THREAD
51-40759-5X-99	SCOKET HEAD CAP SCREW
51-40762-6X-99	SOCKET CAP SCREW (CVA)
51-40776-2X-99	SCREW, RD HEAD (STD93)
51-40780-9X-99	SCREW, C/SUNK HD
51-40796-1X-99	SCREW, DOG POINT
51-40947-3X	DOULBE ROW TAPER BEARING
51-40948-4B-99	DOUBLE ROW ROLLER BEARING
51-71319-5070	CLUTCH RING
51-71326-5070	THRUST WASHER
51-75032-507B-99	GEAR 24T
51-75033-507B-99	UK MFG PART
51-75034-507B	30 TOOTH CHANGE GEAR
51-75040-507B-99	GEAR 53T (CVA)
51-75517-507B-99	UK MFG PART
51-76143	DIAL
51-76143-507B-99	DIAL
51-78392-507C-99	PLATE,TOGGLE COMPENSATING
51-78422-5070	TOGGLE, CLUTCH (20-4)
51-78423-5070	CLUTCH TOGGLE PIVOT PAD
51-78571-5070	GEAR 57T, FIBRE
51-79493-507B-99	TOOL TRAY, R.H.
51-80178-507B-99	INSERT, O/S .020
51-80252-507B-99	WORM WHEEL,CROSS DRIVE
51-83959-507A-99	PLUNGER
51-84861-507B-99	PIN
51-85797-507B-99	SPRING
51-90522	PIN
51-90607-507A	CLUTCH TOGGLE PIVOT
51-90609-507B-99	FEED TUBE COMPLETE
51-90811-5070	SPRING PLUNGER
51-90869-5070	ROLL (CVA)
51-90870-5070	ROLL PIN (CVA)
51-90981-5070	THRUST WASHER
51-90982-5070	THRUST WASHER
51-91162-5070	TAPER GIB
51-91183-507A	SHAFT

PART #	DESCRIPTION
51-91186-507A-99	BOLT, TOOL CLAMP
51-91187-507A-99	PAD, CLAMPING
51-91207-507A-99	EXTRACTION WASHER
51-91208-5070	BUSHING, INDEXING
51-91209-507B-99	BUSHING
51-91210-507B-99	PLUNGER BUSHING FRONT
51-91255-5070	CAM ROLL PIN
51-92634-507B-99	NUT, FRONT PULLEY THRUST
51-92689-5070	FRONT BRG
51-92698-5070	TUBE INSERT
51-92704-5070	YOKE
51-92959-5070	RETAINER, BUSHING
51-93007-507A-99	FEED ADJ. SCREW
51-93203-5070	JOCKEY SPROCKET
51-93290-5070	PICK OFF GEAR, 77T
51-93868	SCREW MACHINE RELATED ITEM
51-94691	DRILL SPINDLE
51-98478	SPECIAL NOSE CAP
51-98479-5070	NOSE CAP, 22C COLLET
57-176-707-0	TONGUE
57-315-375	CLAMP
57-13711	SCREW, ADJUSTING
67-1444-3	SCREW MACHINE RELATED ITEM
67-1449-2	SCREW MACHINE RELATED ITEM
68-109	BEARING
81-226	SCREW, PAN HD 8-32X1/4
81-227	SCREW
81-238	CONDUIT NPPL 1/2 X 1 1/4
81-263	TERMINALS
81-282	WASHER, 3/4" CONDUIT
81-284	WASHER, 1/2" CONDUIT
81-305	MICRO SWTCH CLMPNG PLT
81-306	MICRO SWITCH
81-346	CONDUIT NIPPLE
81-365	CLOSURE, KNOCKOUT, 1/2"
81-386	CONDUIT NIPPLE
88-2-1	PLATE, ELECTRICAL DATA

PART #	DESCRIPTION
88-3-1	PLATE,PATENT
88-4-27	PLATE,WASHER
88-4-29	NAMEPLATE
88-4-30	CHAIN TENSION PLATE
88-4-31	NAMEPLATE
88-4-32-2	INSTRUCTION PLATE
88-4-33	TURRET INST. PLATE (ASM)
88-4-34	PLATE,IDENT.
88-4-47	SCALE
88-4-52	NUMBERS,GEAR BOX
88-4-60	PROGRAM SHEET
88-4-165	PLATE, INST
88-5-7	NAMEPLATE
88-6-4-4	CAUTION PLATE
88-6-51	PLATE, WARNING WHL GRD
88-7-9	NAMEPLATE
88-7-10	ASM PLATE
88-7-11	NAMEPLATE
88-7-13	NAMEPLATE
88-7-16	NAMEPLATE
88-7-18	PLATE, SPINDLE DIRECTION
88-7-21	NAMEPLATE
88-7-22	SPINDLE SPEED PLATE 4 SPEED
88-7-23	NAMEPLATE
88-7-24	NAMEPLATE
88-7-25	NAMEPLATE
88-7-26	NAMEPLATE
88-5125-816	THUMB SCREW
88-5125-1232	THUMB SCREW
88-5725-6	KNOB,KNURLED STL (.1875 HOLE)
88-5805-10	HANDLE,HANDWHEEL(.58DIAX1.44LG
88-9020-624	ROLL PIN M6X24
88-20101-307	WASHER
88-20101-510	WASHER,FLAT (M5 SCR 10MM OD)
88-20101-816	WASHER,FLAT (M8 SCR 17MM OD)
88-20101-1230	WASHER,FLAT (M12 SCR 24MM OD)
88-20101-2037	FITTING WASHER

PART #	DESCRIPTION
88-20111-1225	WASHER
88-20301-1225	SCREW MACHINE RELATED ITEM
88-20311-15	METRIC LOCK WASHER
88-20311-25	METRIC LOCKWASHER
88-20311-40	METRIC LOCK WASHER
88-20311-50	METRIC LOCK WASHER
88-20311-65	METRIC LOCKWASHER
88-20321-506	WASHER,LOCK (M5) SERRATED
88-20321-808	WASHER,LOCK (M8) SERRATED
88-20321-1010	WASHER,LOCK (M10) SERRATED
88-20321-1211	WASHER
88-20321-1815	LOCKWASHER, SERRATED
88-50101-816	SCREW,SQ HD(M8X16) HALF DOG
88-50101-840	SCREW,SQ HD(M8X40) HALF DOG
88-50301-520	SCREW,HHC (M5 X 20)
88-50301-635	SCREW,HHC (M6 X 35)
88-50301-816	SCREW,HHC (M8 X 16)
88-50301-840	SCREW,HHC (M8 X 40)
88-50301-1235	SCREW,HHC (M12 X 35)
88-50301-1245	SCREW,HHC (M12 X 45)
88-50301-1265	SCREW,HHC (M12 X 65)
88-50501-510	SCREW,SHC (M5 X 10)LOW HD
88-50501-612	SCREW,SHC (M6 X 12) LOW HD
88-50501-816	SCREW,SHC (M8 X 16) LOW HD
88-52701-510	SCREW,SHLDR (6DX10LG M5)
88-52701-616	SCREW,SHLDR (8DX16LG M6)
88-53801-412	SOC HD CAP SCREW M4XM12
88-53801-516	SCREW,SHC (M5 X 16)
88-53801-520	SCREW,SHC (M5 X 20)
88-53801-525	SCREW,SHC (M5 X 25)
88-53801-530	SCREW,SHC (M5 X 30)
88-53801-625	SCREW,SHC (M6 X 25)
88-53801-630	SCREW,SOCKET HEAD CAP
88-53801-816	SCREW,SHC (M8 X 16)
88-53801-820	SCREW,SHC (M8 X 20)
88-53801-825	SCREW,SHC (M8 X 25)
88-53801-830	SOCKET HEAD CAP SCREW

PART #	DESCRIPTION
88-53801-840	SOCKET HEAD CAP SCREW
88-53801-860	SCREW,SHC (M8 X 60)
88-53801-1020	SCREW,SHC (M10 X 20)
88-53801-1235	SCREW,SHC (M12 X 35)
88-53801-1245	SCREW
88-53851-310	SCREW,BHC (M3 X 10)
88-53851-408	SCREW,BHC (M4 X 8)
88-53851-510	SCREW,BHC (M5 X 10)
88-53851-512	SCREW,BHC (M5 X 12)
88-53851-610	SCREW,BHC (M6 X 10)
88-53851-612	SCREW,BHC (M6 X 12)
88-53851-812	SCREW,BHC (M8 X 12)
88-53851-1016	SCREW,BHC (M10 X 16)
88-53901-505	SCREW,SET (M5 X 5) CUP POINT
88-53911-304	SCREW,SET (M3 X 4) FLAT POINT
88-53911-505	SCREW,SET (M5 X 5) FLAT POINT
88-53911-608	SCREW MACHINE RELATED ITEM
88-53911-616	SCREW MACHINE RELATED ITEM
88-53911-1212	SCREW,SET (M12 X 12) FLAT PT
88-60101-86	NUT,HEX (M8)
88-60151-52	NUT,HEX (M5 THIN)
88-60161-65	NUT,WELD (M6)
88-60181-5	NUT,ELASTIC STOP (M5)
88-60181-8	NUT,ELASTIC STOP (M8)
88-60181-10	LOCK NUT
88-60431-20	LOCKNUT,BALL BRG (M20X1)
88-60431-25	LOCKNUT,BALL BRG (M25X1.5)
88-60431-35	LOCKNUT,BALL BRG (M35X1.5)
88-60431-40	LOCKNUT,BALL BRG (M40X1.5)
88-89001-332	TAPER PINS CARBON STEEL
88-89001-432	PIN,SHEAR
88-89001-540	TAPER PINS CARBON STEEL
88-89011-1060	PIN,TAPER (INT THRD) 60SHAFT
88-90001-420	DOWEL PIN 4MM X 20MM
88-90001-816	PIN,DOWEL (8MM X 16MM) SOFT
88-90001-824	PIN,DOWEL (8MM X 24MM) SOFT
88-90201-212	PIN,SPIROL (2MM X 12MM LG)

PART #	DESCRIPTION
88-90201-216	PIN,SPIROL (2MM X 16MM LG)
88-90201-310	PIN,SPIROL (3MM X 10MM LG)
88-90201-320	PIN,SPIROL (3MM X 20MM LG)
88-90201-416	SPIRAL PIN
88-90201-520	PIN,SPIROL (5MM X 20MM LG)
88-90201-632	PIN,SPIROL(6MM X 32MM LG)
88-90301-616	PIN,SPIROL (HEAVY DUTY)
88-98001-610	WOODRUFF KEYS
91-1-78	CLUTCH STOP
91-1-99	TOOL HOLDER SCREW
91-1-100	VERTICAL HOLDER SCREW
91-1-103	SAW SLIDE ADJUSTING SCREW
91-3-5	TOOL POST TOOL CLAMP
91-3-54-1	TOOLCLAMP SCREW
91-5-194	PLATE ADJUSTING SCREW
91-7-28	CLUTCH OPERATING SCREW
91-7-28-1	SCREW,CLUTCH OPERATING
91-7-28B	SCREW & NUT, CLUTCH OPERATING
91-7-49	ADJUSTING SCREW
91-7-49-B	ADJUSTING SCREW & NUT
91-7-115	TURRET CUSHION ADJ SCREW
91-15-88	LEVER SPRING BUSHING
91-15-92	TOOL CLAMP SCREW
91-15-93	TOOL CLAMP SCREW
91-18-10	FEED LEVER ROLL STUD
91-18-25-1	TURRET STOP SCREW
91-18-26	CLUTCH OPERATING SCREW
91-18-26B	SCREW & NUT, CLUTCH OPERATING
91-18-27	CLUTCH OPERATING SCREW
91-18-27B	SCREW & NUT, CLUTCH OPERATING
91-27-53	TURRET CHANGE ROLL STUD
91-27-288	ROTATING LEVER STUD
91-37-13	SET SCREW, TAPER PT.
91-37-14	SCREW,SET
91-37-17	SCREW,SET (HEADLESS)
91-70-66	FEED LATCH KNOB
91-79-1-1	HANDWHEEL HANDLE

PART #	DESCRIPTION
91-88-26	PLUG
91-88-28	PLUG
91-89-20	SPROCKET PIN
91-90-10	TRIP LEVER PIN
91-90-33	PLUNGER
91-90-49	CLUTCH PIN
91-90-50	CLUTCH PIN
91-90-50-ZZ	CLUTCH PIN
91-90-51	DRIVE GEAR TAPER PIN
91-90-51-1	CLUTCH PIN
91-90-81	PLUNGER
91-90-82	LEVER PIN
91-90-83	PIN
91-90-93	CAM HOLDER PIN
91-90-121	LEAD CAM HOLDER PIN
91-90-132	SLOTING SHAFT LEVER PIN
91-90-133	SLOTING SHAFT LEVER PIN
91-90-206	LEAD CAM HOLDER PIN
91-90-216	REV CPLNG SPRNG PN
91-90-243	ROTATING LEVER ROD
91-90-262	REVERSING CAM PLUNGER
91-90-362	NEEDLE BEARING ROLL
91-90-363	WORM ADJ. CASE FULCRUM
91-90-404	ROLL PIN
91-90-421	ROLL PIN LEFT
91-90-438	PIN
91-90-441	ROTATING LEVER ROD
91-90-465	CROSS SLIDE CAM PIN
91-90-470-1	TAPER PIN
91-90-485	CHUCK FORK ROLLER STUD
91-90-588	TOOL HOLDER FEED STUD
91-90-589	YOKE GUIDE
91-90-594	TOOL HOLDER FEED STUD
91-90-595	YOKE GUIDE
91-90-645	LEVER PIN
91-90-699	SHAFT FULCRUM
91-90-700	SLIDE LEVER PIN

PART #	DESCRIPTION
91-90-701	STOPPING SPRING PLUNGER
91-90-705	LEAD LEVER PIN
91-90-708	CABLE FD GR BRNG
91-90-713	BRACKET FULCRUM
91-90-714	WIRE PIPE LOCK HAND PIN
91-90-715	WIRE PIPE STOP PIN
91-90-716	ALUMINUM PLUG
91-90-717	ALUMINUM PLUG
91-90-718	ALUMINUM PLUG
91-90-721	ALUMINUM PLUG
91-90-723	ALUMINUM PLUG
91-90-738	SLIDE LEVER PIN
91-90-741	STOCK STOP CAM ROLL PIN
91-90-743	STOCK STOP LINK PIN LOWER
91-90-750	FEED LATCH SHEAR PIN
91-90-752	SLIDE LEVER PIN
91-90-761	CLUTCH PIN
91-90-765	CONNECTING LINK PIN
91-90-769	RIVETS
91-90-770	TRIP LEVER DOG RIVET
91-90-782	FEED LATCH SHEAR PIN
91-90-792	CHUCK LEVER ROLL PIN
91-90-793	TRIP LEVER PIN
91-90-795-1	CLUTCH PIN
91-90-798	SHAFT COUPLING PLUNGER
91-90-820	NEEDLE BEARING ROLL
91-90-821	NEEDLE BEARING ROLL
91-90-822	NEEDLE BEARING ROLL
91-90-851	STOCK STP CM RLL PN
91-90-854	ROLL
91-90-876	SLOTING LEVER FULCRUM
91-90-883-1	CLUTCH LOCKING PIN
91-90-884	SPINDLE PLY BSHNG PN
91-90-885	CHUCK SLEEVE PIN
91-90-886	CHUCK SLEEVE PIN
91-90-887	CHUCK SLEEVE PIN
91-90-889	REVERSING SPRING PIN

PART #	DESCRIPTION
91-90-891	TURRET LCKNG PN LV FLCRM
91-90-945	SPRING RETAINING RING
91-90-946	SPINDLE PLUNGER
91-90-966	TIMING CM LV RLLR PN CRS
91-90-988	SHEAR PIN
91-90-991	SHEAR PIN
91-90-1001	SHEAR PIN
91-90-1002	SHEAR PIN
91-90-1006	CLUTCH SLEEVE BUSHING
91-90-1042	LINK PIN
91-90-1043	CAM ROLL PIN
91-90-1046	SLIDE LEVER ROLL STUD
91-90-1047-1	VERTICAL SLD SPRNG PLG
91-90-1051-1	SWING STP SHFT LNK PN
91-90-9095	LEAD CAM ROLL PIN
91-91-12	STARTING LEVER
91-91-26	ROTATING CAM LEVER STOP
91-91-98	PIN
91-91-102	PLUNGER
91-91-141	TURRET PIN
91-91-141-1	TURRET SLD SPRG PLNGR P
91-91-143-1	TURRET SLD SPR PLNGR
91-91-172	RELIEF VALVE PLUNGER
91-91-184-1	PAWL OPERATING BAR PIN
91-91-217	STAY ROD
91-91-224	CM DRVNG DSC RVT
91-91-264	RIVET
91-91-266	FEED CHANGE YOKE PIN
91-91-323	SLOTING DRIVE RIVIT
91-91-329	TUR SLD SPRN PLNGR PN
91-91-360	SPEED CASE DOWEL PIN
91-91-416	STUD
91-91-417	TAPERED PIN
91-91-423	PIN, ADJUSTING SCREW
91-91-423-ZZ	ZZ PIN
91-91-436	SPINDLE HD CVR DWL
91-91-510	STAY ROD

PART #	DESCRIPTION
91-91-511	STAY ROD
91-91-512	STAY ROD
91-91-527	CHUCK FORK YOKE PLUNGER
91-91-528	PLUNGER
91-91-534	PLUNGER, FEED TUBE
91-91-554	STUD
91-91-555	SPRING HOLDER
91-91-556	SPRING HOLDER FRONT
91-91-566	STOP RACK
91-91-567	SLIDE STOP BACK
91-91-603-1	CHUCK FORK SHOE PLUNGER
91-91-604	CHUCK FORK SHOE PLUNGER
91-91-610	LEVER ROLL PIN
91-91-611	TURRET ROLL STUD
91-91-618	NAME PLT WLDNG PLG
91-91-619	STOP LEVER PAWL
91-91-642	PLUNGER, SPRING
91-92-64	CROSS FD TRP PNN DTNT
91-92-69	PLUNGER
91-94-12-1	CAM DRIVING DISC PIN
91-97-230	KEY ARBOR SLEEVE
91-97-251	DOVETAIL KEY
91-97-355	DOVETAIL KEY
91-97-358	SPINDLE KEY
91-97-359	KEY
91-97-370	SPINDLE KEY
91-97-371	SPINDLE KEY
91-97-371-1	KEY
91-97-372	CHUCK LEVER FULCRUM KEY
91-97-378	CHUCK LEVER FULCRUM KEY
91-97-381	CHUCK FORK SLEVE KEY
91-97-414	KEY, DRIVE SHAFT
91-97-426	LEAD CAM HOLDER KEY
91-97-427	KEY
91-97-434	LEAD CAM HOLDER KEY
91-97-499	CLUTCH BODY KEY
91-97-519	SWIVEL KEY

PART #	DESCRIPTION
91-97-525	CAMHOLDER REAR KEY
91-97-9003	KEY
91-100-2	SPRING
91-100-2-1	SPRING
91-100-12	SPRING
91-100-12-1	SPRING
91-100-24	SPRING
91-100-38	SPRING
91-100-47	SPRING,ROTATING LEVER
91-100-50	SPRING,SLOTTING SHAFT
91-100-75	SPRING
91-100-93	SPRING
91-100-123	SPRING
91-100-145-1	SPRING
91-100-154	SPRING,CLIP
91-100-182	SPRING
91-100-250	SPRING
91-100-315	SPRING
91-100-349	SPRING
91-100-353	SPRING
91-100-361	CAM LEVER SPRING
91-100-370	SPRING
91-100-380	SPRING ROTATING CAM LEVER
91-100-399	SPRING
91-100-410	SPRING
91-100-412	SPRING
91-100-421	SPRING
91-100-432	SPRING
91-100-434-1	SPRING
91-100-436	SPRING, GEAR
91-100-438	SPRING
91-100-440	SPRING
91-100-441	SPRING,CROSS SLIDE
91-100-441-1	SPRING
91-100-444	SPRING
91-100-453	SPRING
91-100-467	SPRING

PART #	DESCRIPTION
91-100-471	SPRING
91-100-476	SPRING
91-100-480	TURRET SLIDE SPRING
91-100-486	SPRING
91-100-495	SPRING
91-100-497	SPRING
91-100-501	IDLER ADJ. SPRING
91-100-506	SPRING
91-100-514	SPRING
91-100-523	SPRING
91-100-531	SPRING
91-100-542	SPRING
91-100-551	SPRING
91-100-557	SPRING
91-100-561	SPRING
91-100-563	SPRING
91-100-585	SPRING
91-100-594-1	SPRING
91-100-596	SPRING
91-100-602	SPRING
91-100-603	SPRING
91-100-611	SPRING WORM SAFETY LATCH
91-100-613	SPRING
91-100-616	SPRING
91-100-622	SPRING
91-100-626	SPRING
91-100-640-1	SPRING
91-100-651	SPRING
91-100-653	STOPPING SPRING
91-100-659	SPRING
91-100-664	SPRING
91-100-665	SPRING
91-100-700	SPRING
91-100-738	SPRING
91-100-770	SPRING
91-100-778	SPRING
91-100-779	SPRING GEAR BUSH RETANER

PART #	DESCRIPTION
91-100-780	SPRING VERTICAL SLIDE
91-100-781	SPRING SLOTTING SHAFT
91-100-807-1	SPRING
91-100-820	SPRING
91-100-821-2	SPRING
91-100-822-1	SPRING
91-100-825	SPRING
91-100-826-1	SPRING
91-100-827-1	SPRING,FEED SLIDE
91-100-828	SPRING VERTICAL SLIDE
91-100-833	SPRING
91-100-835-1	SPRING
91-100-836	SPRING
91-100-840	SPRING ROTATING LEVER
91-100-841	SPRING
91-100-846	SPRING,DRIVE GEAR
91-100-850-1	SPRING
91-100-851-1	SPRING
91-100-852-1	SPRING
91-100-853-1	SPRING
91-100-858	SPRING
91-100-862	SPRING
91-100-865	SPRING
91-100-866	SPRING
91-100-867	SPRING
91-100-870	SPRING
91-100-878	SPRING
91-100-9000	SPRING
91-100-9009	SPRING
91-100-9010	SPRING
91-100-9012	TURRET SPRING
91-100-9016	COLLET SPRING
91-100-9019	SPRING
91-100-9024	SPRING
91-100-9029	SPRING
91-100-9031	SPRING, CLUTCH
91-100-9090	SPRING

PART #	DESCRIPTION
91-100-9091	TURRET SLIDE SPRING
91-100-9092	SPRING
91-100-9094	SPRING
91-100-9223	SPRING
91-100-51263	SPRING
91-101-1-1	TURRET STOP SCREW NUT
91-101-4	PLUNGER SPRING SCREW
91-101-20	NUT, CLUTCH OPERATING SCREW
91-101-46	CHECK NUT
91-101-60	CLUTCH OPERAT.SCREW NUT
91-101-119	FEED ADJUSTING SCREW NUT
91-101-153	CHUCK CAM SHAFT NUT
91-101-9000	HEX NUT 7/16 UNF
91-104-3	WHEEL SLEEVE NUT
91-104-4	SPINDLE NUT RIGHTHAND
91-104-20	LEAD CAM NUT
91-104-21	SLIDE CAM SHAFT NUT
91-104-24	TURRET DISH NUT
91-104-24-1	TURRET DISK NUT
91-104-37	NUT, ASM SLIDE CAM SHAFT
91-104-58	SLOTING CAM NUT
91-104-59	ROTATING CAM NUT
91-104-139	TURRET DISK NUT
91-104-139-1	TURRET DISK NUT
91-104-160	LEAD CAM SHAFT NUT
91-104-223	223 RTTNG C HLDR NT
91-104-229	SLIDE CAM SHAFT NUT
91-104-295	PLUNGER NUT
91-104-322	CHUCK ADJUSTING NUT
91-104-324	CHUCK NUT
91-104-419-1	SPLIT NUT
91-104-422	FEED SCREW NUT
91-104-445	TURRET RETURN STOP NUT
91-104-449	ARBOR BUSHING NUT
91-104-563	WORM SHAFT NUT
91-104-567	SPINDLE NUT
91-104-570	CHUCK ADJUSTING NUT

PART #	DESCRIPTION
91-104-582	NUT
91-104-588	SPINDLE NUT
91-104-598	SPINDLE REAR BOX NUT
91-104-599	WORM SLEEVE NUT
91-104-615	SPINDLE BOX NUT,LEFT
91-104-628	SPINDLE DRV SLV NUT
91-104-642	TURRET DISK NUT
91-115-34	CHANGE GEAR NUT
91-115-38	ADJ. SCREW CAP
91-125-45	TURRET SLIDE AD SCREW NUT
91-201-23	DRIVING SHAFT WASHER
91-201-115	PINION WASHER
91-201-288	WASHER
91-201-321	SLIDE CAM SHAFT WASHER
91-201-322	WASHER
91-201-414	SLOT SHAFT BALL RETAINER
91-201-471	SAW ARBOR WASHER
91-201-472	SAW ARBOR WASHER
91-201-473	SAW ARBOR WASHER
91-201-474	SAW ARBOR WASHER,11/32"
91-201-479	SAW ARBOR WASHER
91-201-480	SAW ARBOR WASHER
91-201-481	SAW ARBOR WASHER
91-201-551	TURRET DSK WSHR
91-201-693	HANDLE COLLAR
91-201-694	WASHER
91-201-695	HEAD HANDLE STUD COLLAR
91-201-805	PINION WASHER
91-201-822	WASHER
91-201-823	SPINDLE SPROCKET THRST WSHR
91-201-829	SWITCH TERMINAL WASHER
91-201-832	TURRET TL CLMP BLT WSHR
91-201-833	SPINDLE DRV PNN FT WSHR
91-201-835	WASHER
91-201-844	WASHER
91-201-845	SPINDLE PULLEY WASHER
91-201-846	SPINDLE PULLEY WASHER

PART #	DESCRIPTION
91-201-850	SPINDLE PLY WSHR BSH
91-201-851	SPINDLE PULLEY WASHER
91-201-852	SPINDLE PULLEY WASHER
91-201-855	STOP SHFT GR WSHR
91-201-856	FEED MOTOR SWTCH WASHER
91-201-880	SLIDE CAM SHAFT WASHER
91-201-883	FEED PLUNGER WASHER
91-201-909	WASHER
91-201-929	WASHER
91-201-930	SPACER
91-201-932	WASHER, WORM DRVNG GEAR
91-201-949-1	BRACKET HINGE PIN WASHER
91-201-954	SPINDLE PLY BSHNG WSHR
91-201-973	DRIVE BRACKET WASHER
91-201-1001	STRADDLE MLL ARBR CLLR
91-201-1002	STRADDLE MLL ARBR CLLR
91-201-1208	WASHER
91-201-1209	SAFETY CLUTCH GEAR WASHER
91-204-63	CROSS SLIDE CAMSHAFT SLEEVE
91-204-286	WASHER, TURRET SLIDE PLUNGER
91-204-295	ARBOR WASHER, SMALL
91-204-309	TURRET RTRN STP WSHR
91-204-370	OILER BUSHING
91-204-455	SPIN DRV SLV SPCR
91-204-472	PINION SHFT DRV GR CLL
91-204-474	VERTICAL SLD EXTNSN SLV
91-204-483	WASHER, TURRET SLIDE PLUNGER
91-204-555	SPINDLE DRVNG SPRCKT WSHR
91-204-559	TURRET CHNG SHFT CLLR
91-204-579	IDLER SPRING SPACER
91-204-591	OPERATING SHAFT COLLAR
91-204-593	SLOTING LEVER COLLAR
91-211-1	WHEEL SLEEVE WASHER
91-211-15	DRIVE SHAFT WASHER
91-211-23	DRIVING SHAFT WASHER
91-211-23-1	DRIVE SHAFT WASHER
91-215-3	CAM ROLL

PART #	DESCRIPTION
91-215-4	ROLL, CHANGE
91-215-6	ROLL, CAM
91-215-6-1	ROLL, CAM
91-215-8	CAM ROLL
91-215-9	CAM ROLL
91-215-10	ROLL, CHANGE
91-215-11	CHANGE ROLL
91-215-12	LEVER ROLL
91-215-17-1	ROLL, CAM
91-215-18	ROLL, CAM
91-215-19	CAM ROLL
91-215-35	LEVER ROLL
91-215-36	SLOTING LEVER ROLL
91-215-62	BACK REST ROLL
91-215-126	SHEAR PIN BUSHING
91-215-133	CHUCK & FEED CAM ROLL
91-215-135-1	LEAD CAM LEVER ROLL
91-215-158	CHUCK LEVER ROLL
91-215-162-1	ROLL
91-215-178	TABLE FEED YOKE ROLL
91-215-193	SHEAR PIN BUSHING
91-215-210	OPERATING RCK SPPRT RLL
91-215-211	ROLL, CAM
91-215-212	ROLL, CAM
91-215-219	STOCK STOP CAM ROLL
91-215-220	ROLL, CAM
91-215-222	CAM ROLL
91-215-223	SUPPORT ROLL
91-215-225	SHEAR PIN BUSHING
91-215-226	CAM ROLL
91-215-227	PIN BUSHING
91-215-237	SHEAR PIN BUSHING
91-215-242	SLOTING CAM ROLL
91-215-246-1	REVERSE LEVER CAM ROLL
91-215-247	VERT SLD OPR LVR RLL
91-215-9088	CAM ROLL
91-215-9089	CAM ROLL,TURRET SLIDE

PART #	DESCRIPTION
91-224-4	TURRET TL CLMP BSHNG
91-224-5	TURRET TL CLMP BSH
91-224-11	SLEEVE,TURRET LOCK PIN
91-224-12	TURRET LCKNG PN SLV RR
91-224-69	WASHER,ADJ. PLUNGER
91-224-73	CLAMP BUSHING, TURRET TOOL
91-224-77	TURRET LCKNG PN SLV FRN
91-224-78	TURRET LCKNG PN SLV FRN
91-224-99	TURRET LCK PN SHLL BCK
91-224-101-1	BUSHING, WITH FLAT
91-224-102	TURRET TOOL CLAMP BUSHING
91-224-103-1	TURRET TOOL CLAMP BUSH W/FLAT
91-224-103-1B	CLAMP BUSHING WITH RADIUS
91-224-146	SHEAR PIN BUSHING LNG
91-224-221	ROTATING LEVER BUSHING
91-224-239	SHEAR PIN BUSHING
91-224-253	RACK PNN SHFT BRNG BSHNG
91-225-2	TURRET BUSHING
91-225-5	TURRET BUSHING
91-225-7	TURRET BUSHING
91-234-33	CLAMP SLEEVE WASHER
91-234-36	CLUTCH SLEEVE WASHER
91-235-7	THRUST WASHER
91-235-11	THRUST WASHER
91-235-225	DRIVING SHAFT WASHER
91-235-227	WASHER
91-237-11	SPECIAL CUP LEATHER
91-238-29	WASHER
91-238-30	WASHER SP PULLEY THRUST-S
91-238-31	WASHER,SPIN.SPRK.OUTER
91-238-32	WASHER,SPIN.SPRK.INNER
91-238-36	WASHER
91-238-37	WASHER
91-238-39	WASHER-SAFETY CL SLEEVE
91-290-5	FEED PLUNGER CLAMP
91-298-10	GUARD CATCH
91-325-60	LOCK WASHER

PART #	DESCRIPTION
91-325-65	DRIVE SH NUT LOCK WASH
91-325-66	LOCK WASHER
91-325-98	LOCK WASHER
91-325-99	LOCK WASHER
91-325-99-1	LOCKWASHER
91-325-109	DRIVING SHAFT LOCKWASHER
91-325-111	SPINDLE DRV SH LCK WSHR
91-325-118	LOCK WASHER
91-325-126	SPINDLE LCK N WSHR UPPR
91-325-164	WORM SHAFT LCK WSHR
91-325-172	FEED SCREW LOCK WASHER
91-325-181	LOCKWASHER
91-325-188	TABLE FD SCR NT LCK WSHR
91-325-196	LOCKWASHER,SP. DR.SL
91-325-203	SPINDLE NUT LOCKWASHER
91-334-19	LINER
91-404-2	VALVE W/ LEVER HANDLE
91-404-32	SWING PENDANT
91-502-18	DEFLECTOR STUD
91-502-21	TURRET TONGUE SCREW
91-502-46	HANDWHEEL BOLT
91-503-11	SCREW, OIL SLINGER
91-503-19	SPINDLE HD STRP BLT
91-503-36	CHANGE GEAR ARM SCREW
91-503-52	ROTATING LEVER STUD
91-503-65	TURRET TL CLMP BLT
91-503-66	TURRET TL CLMP SCRW
91-503-67	TURRET TL CLMP BLT
91-503-102	TOOL POST CLAMP SCREW
91-503-104	OIL SLINGER BOL
91-503-108	TOOL CLAMP SCREW
91-503-115	BED BOLT
91-503-117	SWING STP SHF LNK SCRW
91-505-47	TURRET CLTCH TRP LVR SH
91-505-53	SCREW, FEED TUBE
91-505-56	SAFETY CLUTCH SCREW
91-505-60	KNURLED ADJUSTING SCREW

PART #	DESCRIPTION
91-505-61	ADJUSTING SCREW
91-505-90	CLUTCH SLEEVE SCREW
91-505-115	CLUTCH SLEEVE SCREW
91-505-117	MASTER COLLET PAD SCREW
91-505-137-1	CHUCK LEVER FULCRUM SCREW
91-507-88	CLUTCH SHIFT FORK SCREW
91-507-90	COVER STUD
91-508-14	TURRET LCKNG PN CM SCRW
91-508-15	SPINDLE OIL GUARD SCREW
91-515-19	TURRET TL CLMP SCRW
91-518-3	CLUTCH FORK SCREW LONG
91-520-9-1	CLUTCH SLEEVE SCREW
91-520-9-1ZZ	ZZ SCREW, CLUTCH
91-520-10	SCREW
91-520-11	GIB ADJUSTING SCREW
91-527-12-1	TURRET CHANGE ROLL STUD
91-527-15	TRIP LVR DG FLCRM
91-527-15A	DOG BOLT, SHORT W/NUT
91-527-18-1	BURRING SPNDL SL RLL FLCR
91-527-22	TURRET LOCKING PIN STUD
91-527-23	CROSS SLIDE STOP FRONT
91-527-24	CHUCK TRIP LEVER FULCRUM
91-527-25	TURRET TRP LV DG FLCRM
91-527-41	HANDWHEEL HANDLE STUD
91-527-48	SLIDE STOP FRONT
91-527-111	SCREW
91-527-112	HANDLE STUD
91-527-276	FULCRUM, TURRET TRIP LEVER DOG
91-527-300	TRIP LVR DG BLT LNG
91-531-12	CUSHION PLUNGER SCREW
91-535-4	SCREW, TURRET DRILL SHAFT
91-536-3	LEAD FULCRUM SCREW
91-536-12	CHUCK CAM ROLL SCREW
91-536-18	SCREW, SET (IDLER ARM)
91-536-21	SPINDLE CLTCH FRK FLCRM
91-536-25	CLUTCH FORK SCREW SHORT
91-536-30	CHUCK FORK RING SCREW

PART #	DESCRIPTION
91-536-35	CLUTCH OPERATING SCREW
91-536-35B	SCREW & NUT, CLUTCH OPERATING
91-537-11	TOOL HOLDER PIVOT
91-537-16	DOG CARRIER SET SCREW
91-542-30	TURRET RETURN STOP
91-542-31-1	CROSS SLIDE SEGMENT FUL SCREW
91-542-32	FEED GIB ADJUSTING SCREW
91-542-39	GUARD CATCH HOLDER
91-601-20	NUT
91-601-23	CHANGE GEAR CLAMP NUT
91-601-30	SLIDE ADJUSTING NUT
91-601-36	CONNECTING ROD NUT
91-601-54	SAW ARBOR NUT
91-601-57	CAM LEVER LINK NUT
91-601-118	FEED ADJUSTING SCREW NUT
91-601-120	PANEL MOUNT BLOCK NUT
91-604-5	SPINDLE NUT
91-604-15	STOCK STOP SHAFT NUT
91-604-18	TURRET RET STOP NUT
91-604-20	SP.PULLEY THRUST NUT
91-604-23	SPINDLE PLY THRST NT
91-604-26-1	NUT, SHAFT BUSHING THRUST
91-604-27	DRIVING SHAFT ADJUST NUT
91-604-28	STOCK STOP SHAFT NUT
91-604-31	LOCK NUT
91-604-71	TURRET DISC NUT
91-604-73	SWING STOP SHAFT NUT
91-607-14	FRONT CAM SHAFT LEFT NUT
91-613-1	CAM LEVER STUD NUT
91-619-1	STOP SLD CLMP BSHNG
91-619-8	STOCK STP CLMP BSHNG
91-619-8-1	CLAMP BUSHING
91-619-9	VERTICAL SLIDE WAY CLAMP
91-619-9-B	VERTICAL WAY CLAMP W/THREAD
91-619-11	STOCK STOP CLAMP BUSHING
91-619-16	VERT SLIDE CLAM
91-619-18	SLIDE CLAMP

PART #	DESCRIPTION
91-619-19	TURRET TL CLMP BSHNG
91-619-23	CLAMP, VERTICAL SLIDE
91-619-27-1	BUSSING, TURRET CLAMP
91-704-6	PINION SHFT DRVNG GR CLLR
91-793-1	GUARD CATCH
91-5051-840	SCREW MACHINE RELATED ITEM
91-5051-1236	CHEESE HEAD SCREW
92-10-1264	SCREW,SQUARE HEAD
92-20-824	T BOLT
92-20-1460	T BOLT
92-150-1448	SCREW,HEX COLLAR (7/16-14X2)
92-310-1036	SCREW,PLAIN SHOULDER
92-340-1424-12	SCREW,FILLISTER HEAD
92-351-712-5	OIL HOLE SCREW
92-361-1424-10	SCREW,HEADLESS TEATED
92-361-1832-14	TEATED SCREW
92-420-1656	SHLDR THRD STUD
92-505-53	LOCK SCREW SHOE
92-720-6	KNOB,STL (.1875HOLE) KNURLED
92-740-612-14	KNOB
92-850-1043	HANDLE
92-880-408	PLUG,C I
92-880-610	PLUG,C I
92-880-810	PLUG,C I
92-890-200	TAPER PIN
92-890-240	TAPER PIN
92-890-280	TAPER PIN
92-890-322	TAPER PIN
92-890-323	TAPER PIN
92-890-325	TAPER PIN
92-890-360	TAPER PIN
92-890-361	TAPER PIN
92-890-362	TAPER PIN
92-890-363	TAPER PIN
92-890-402	TAPER PIN
92-890-403	TAPER PIN
92-890-404	TAPER PIN

PART #	DESCRIPTION
92-890-405	TAPER PIN
92-890-443	TAPER PIN
92-890-445	TAPER PIN
92-890-482	TAPER PIN
92-890-485	TAPER PIN
92-890-486	TAPER PIN
92-890-526	TAPER PIN
92-890-527	TAPER PIN
92-890-2800	TAPER PIN
92-900-204	PLAIN PIN
92-900-206	PLAIN PIN
92-900-208	PLAIN PIN
92-900-210	PLAIN PIN
92-900-214	PLAIN PIN
92-900-220	PLAIN PIN
92-900-304	PLAIN PIN
92-900-306	PLAIN PIN
92-900-308	PLAIN PIN
92-900-312	PLAIN PIN
92-900-316	PIN,DOWEL (3/32 X 1/2)
92-900-318	PLAIN PIN
92-900-320	SHEAR PIN
92-900-322	PLAIN PIN
92-900-324	PLAIN PIN
92-900-348	PIN,PLAIN
92-900-406	PIN,DOWEL (1/8 X 3/16)
92-900-408	PIN,DOWEL (1/8 X 1/4)
92-900-410	PLAIN PIN
92-900-412	PIN,DOWEL (1/8 X 3/8)
92-900-414	PLAIN PIN
92-900-416	PLAIN PIN
92-900-418	PLAIN PIN
92-900-420	PLAIN PIN
92-900-421	PLAIN PIN
92-900-424	PIN,DOWEL (1/8 X 3/4)
92-900-426	PLAIN PIN
92-900-428	PLAIN PIN

PART #	DESCRIPTION
92-900-430	PIN,DOWEL (1/8 X 15/16)
92-900-432	PIN, DOWEL
92-900-434	PLAIN PIN
92-900-436	PIN,DOWEL (1/8 X 1 1/4)
92-900-440	PLAIN PIN
92-900-508	PLAIN PIN
92-900-510	PLAIN PIN
92-900-512	PLAIN PIN
92-900-514	PLAIN PIN
92-900-516	PIN,DOWEL (5/32 X 1/2)
92-900-520	PLAIN PIN
92-900-524	PLAIN PIN
92-900-526	PIN
92-900-532	PLAIN PIN
92-900-608	PLAIN PIN
92-900-610	PLAIN PIN
92-900-612	PLAIN PIN
92-900-614	PLAIN PIN
92-900-616	PLAIN PIN
92-900-618	PLAIN PIN
92-900-620	PLAIN PIN
92-900-624	PLAIN PIN
92-900-626	PLAIN PIN
92-900-628	PLAIN PIN
92-900-632	PIN,DOWEL (3/16 X 1)
92-900-634	PIN
92-900-636	PLAIN PIN
92-900-638	PLAIN PIN
92-900-646	PLAIN PIN
92-900-648	PLAIN PIN
92-900-806	PLAIN PIN
92-900-808	PLAIN PIN
92-900-810	PLAIN PIN
92-900-812	PIN,DOWEL (1/4 X 3/8)
92-900-814	PLAIN PIN
92-900-816	PIN,DOWEL (1/4 X 1/2)
92-900-818	PIN,DOWEL (1/4 X 9/16)

PART #	DESCRIPTION
92-900-820	PIN,DOWEL (1/4 X 5/8)
92-900-824	PIN,DOWEL (1/4 X 3/4)
92-900-828	PLAIN PIN
92-900-832	PLAIN PIN
92-900-834	PIN,DOWEL (1/4 X 1 1/8)
92-900-836	PLAIN PIN
92-900-838	PLAIN PIN
92-900-840	PLAIN PIN
92-900-842	PIN,DOWEL (1/4 X 1 5/8)
92-900-850	PIN,DOWEL (1/4 X 2 1/4)
92-900-1018	PIN,PLAIN
92-900-1020	PIN,PLAIN
92-900-1024	PIN,PLAIN
92-900-1028	PIN,PLAIN
92-900-1032	PIN,PLAIN
92-900-1036	PIN,PLAIN
92-900-1038	PIN,DOWEL (5/16 X 1 3/8)
92-900-1040	PIN,PLAIN
92-900-1044	GEAR CASE DOWEL
92-900-1052	PLAIN PIN
92-900-1216	PLAIN PIN
92-900-1220	PLAIN PIN
92-900-1224	PLAIN PIN
92-900-1228	PLAIN PIN
92-900-1232	PLAIN PIN
92-900-1234	PLAIN PIN
92-900-1236	PLAIN PIN (ASM)
92-900-1238	PLAIN PIN
92-900-1240	PLAIN PIN
92-900-1248	PLAIN PIN
92-900-1440	PLAIN PIN
92-900-1444	PLAIN PIN
92-900-1636	PLAIN PIN
92-900-2048	PLAIN PIN
92-900-2052	PLAIN PIN
92-900-2420	PLAIN PIN
92-900-2444	PLAIN PIN

PART #	DESCRIPTION
92-901-1634	PIN,PLAIN
92-902-408	PIN,SPRING (1/16 X 1/4LG)
92-902-412	PIN,SPRING (1/16 X 3/8LG)
92-902-416	PIN,SPRING (1/16 X 1/2LG)
92-902-420	PIN,SPRING (1/16 X 5/8LG)
92-902-508	SPRING PIN 5/64 X 1/4
92-902-512	PIN,SPRING (5/64 X 3/8LG)
92-902-620	PIN,SPRING (3/32 X 5/8LG)
92-902-624	PIN,SPRING (3/32 X 3/4LG)
92-902-814	PIN,SPRING (1/8 X 7/16LG)
92-902-816	PIN,SPRING (1/8 X 1/2LG)
92-902-820	PIN,SPRING (1/8 X 5/8LG)
92-902-824	PIN,SPRING (1/8 X 3/4LG)
92-902-828	PIN,SPRING (1/8 X 7/8LG)
92-902-832	PIN,SPRING (1/8 X 1LG)
92-902-834	PIN,SPRING (1/8 X 1 1/8LG)
92-902-836	PIN,SPRING (1/8 X 1 1/4LG)
92-902-1028	PIN,SPRING (5/32 X 7/8LG)
92-902-1036	ROLL PIN
92-902-1212	PIN
92-902-1216	PIN,SPRING (3/16 X 1/2LG)
92-902-1220	PIN,SPRING (3/16 X 5/8LG)
92-902-1224	PIN,SPRING (3/16 X 3/4LG)
92-902-1232	PIN,SPRING (3/16 X 1LG)
92-902-1234	PIN,SPRING (3/16 X 1 1/8LG)
92-902-1236	PIN,SPRING (3/16 X 1 1/4LG)
92-902-1240	PIN,SPRING (3/16 X 1 1/2LG)
92-902-1246	PIN,SPRING
92-902-1620	PIN,SPRING (1/4 X 5/8LG)
92-902-1628	PIN,SPRING (1/4 X 7/8LG)
92-902-1634	PIN,SPRING (1/4 X 1 1/8LG)
92-902-1636	PIN,SPRING (1/4 X 1 1/4LG)
92-902-1640	PIN,SPRING (1/4 X 1 1/2LG)
92-902-1642	PIN,SPRING (1/4 X 1 5/8LG)
92-902-1648	PIN,SPRING (1/4 X 2LG)
92-902-1650	PIN,SPRING (1/4 X 2 1/4LG)
92-902-2048	PIN,SPRING (5/16 X 2LG)

PART #	DESCRIPTION
92-902-2052	PIN,SPRING (5/16 X 2 1/2LG)
92-930-1312	SHOE,BRASS
92-930-1320	SHOE,BRASS
92-940-312	RIVET
92-940-319	RIVETS
92-940-426	RIVET
92-940-439	RIVET
92-940-616	RIVET
92-970-210	DOVETAIL KEY
92-970-216	KEY
92-970-220	KEY
92-970-224	KEY,SQUARE ENDS
92-970-406	KEY
92-970-408	HOLDER KEY
92-970-412	SQUARE PIN
92-970-416	KEY
92-970-418	KEY,SQUARE
92-970-420	KEY
92-970-424	KEY
92-970-428	KEY,SQUARE ENDS
92-970-432	SQUARE PIN
92-970-434	KEY,SQUARE ENDS
92-970-436	KEY,SQUARE ENDS
92-970-444	KEY,SQUARE ENDS
92-970-612	KEY,SQUARE ENDS
92-970-616	KEY,SQUARE ENDS
92-970-618	KEY,SQUARE ENDS
92-970-620	KEY,SQUARE ENDS
92-970-624	KEY,SQUARE ENDS
92-970-626	KEY,SQUARE ENDS
92-970-628	KEY,SQUARE ENDS
92-970-630	KEY,SQUARE ENDS
92-970-632	KEY
92-970-633	KEY,SQUARE
92-970-635	KEY,SQUARE ENDS
92-970-636	KEY,SQUARE ENDS
92-970-637	KEY,SQUARE ENDS

PART #	DESCRIPTION
92-970-638	KEY
92-970-639	KEY,SQUARE ENDS
92-970-640	KEY
92-970-644	KEY,SQUARE ENDS
92-970-645	KEY,SQUARE
92-970-648	KEY,SQUARE ENDS
92-970-649	KEY,SQUARE ENDS
92-970-668	KEY,SQUARE ENDS
92-970-814	KEY,SQUARE ENDS
92-970-816	KEY, SQUARE ENDS
92-970-818	KEY
92-970-820	KEY,SQUARE ENDS
92-970-824	KEY,SQUARE ENDS
92-970-826	KEY,SQUARE ENDS
92-970-832	KEY,SQUARE ENDS
92-970-834	KEY,SQUARE ENDS
92-970-836	KEY,SQUARE ENDS
92-970-840	KEY,SQUARE ENDS
92-970-844	KEY,SQUARE ENDS
92-970-846	KEY,SQUARE ENDS
92-970-848	KEY,SQUARE ENDS
92-970-852	KEY,SQUARE ENDS
92-970-854	KEY,SQUARE ENDS
92-970-858	KEY,SQUARE ENDS
92-970-862	KEY
92-970-1016	KEY,SQUARE ENDS
92-970-1020	KEY,SQUARE ENDS
92-970-1024	KEY,SQUARE ENDS
92-970-1026	SQUARE KEY
92-970-1032	KEY,SQUARE ENDS
92-970-1035	KEY,SQUARE ENDS
92-970-1036	KEY
92-970-1042	KEY,SQUARE ENDS
92-970-1046	KEY,SQUARE ENDS
92-970-1048	KEY,SQUARE
92-970-1049	KEY,SQUARE ENDS
92-970-1052	KEY

PART #	DESCRIPTION
92-970-1056	KEY,SQUARE ENDS
92-971-820	DOVETAIL KEY
92-971-832	DOVETAIL KEY
92-973-626	KEY
92-973-848	KEY
92-980-316	KEY,WOODRUFF
92-980-416	KEY
92-980-420	KEY,WOODRUFF
92-980-424	KEY,WOODRUFF
92-980-620	KEY,WOODRUFF
92-980-624	KEY
92-980-628	KEY,WOODRUFF
92-980-632	KEY,WOODRUFF
92-980-636	KEY,WOODRUFF
92-980-828	KEY,WOODRUFF
92-980-832	KEY,WOODRUFF
92-980-834	KEY,WOODRUFF
92-980-836	KEY,WOODRUFF
92-980-1032	KEY,WOODRUFF
92-980-1034	KEY,WOODRUFF
92-980-1036	KEY,WOODRUFF
92-980-1040	KEY
92-980-1240	KEY,WOODRUFF
92-1000-608-23	SPRING,COMP (3/16OD X 1/4LG)
92-1000-612-26	SPRING,COMP (3/16OD X 3/8LG)
92-1000-620-22	SPRING,COMP (3/16OD X 5/8LG)
92-1000-624-20	COMPRESSION SPRING
92-1000-624-22	SPRING,COMP (3/16OD X 3/4LG)
92-1000-624-23	SPRING,COMP (3/16OD X 3/4LG)
92-1000-632-20	PLUNGER SPRING
92-1000-632-23	SPRING,COMP (3/16OD X 1LG)
92-1000-636-22	SPRING,COMP (3/16OD X 1 1/4LG)
92-1000-816-20	SPRING
92-1000-816-22	SPRING,COMP (1/4OD X 1/2LG)
92-1000-820-20	SPRING
92-1000-824-19	SPRING,COMP (1/4OD X 3/4LG)
92-1000-824-20	SPRING,COMP (1/4OD X 3/4LG)

PART #	DESCRIPTION
92-1000-824-22	SPRING,COMP (1/4OD X 3/4LG)
92-1000-824-23	COMPRESSION SPRING
92-1000-828-20	SPRING,COMP (1/4OD X 7/8LG)
92-1000-832-19	SPRING
92-1000-832-20	SPRING,COMP (1/4OD X 1LG)
92-1000-836-19	SPRING
92-1000-840-19	SPRING,COMP (1/4OD X 1 1/2LG)
92-1000-844-19	SPRING,COMP (1/4OD X 1 3/4LG)
92-1000-1016-18	COMPRESSION SPRING
92-1000-1024-19	SPRING,COMP (5/16OD X 3/4LG)
92-1000-1024-20	COMPRESSION SPRING
92-1000-1032-19	SPRING,COMP (5/16OD X 1LG)
92-1000-1032-22	BODY SPRING
92-1000-1044-19	SPRING,COMP (5/16OD X 1 3/4LG)
92-1000-1048-19	SPRING,COMP (5/16OD X 2LG)
92-1000-1224-18	COMPRESSION SPRING
92-1000-1228-22	SPRING
92-1000-1240-16	SPRING
92-1000-1240-19	COMPRESSION SPRING
92-1000-1248-18	SPRING
92-1000-1248-19	SPRING,COMP (3/8OD X 2LG)
92-1000-1256-18	COMPRESSION SPRING
92-1000-1260-18	SPRING
92-1000-1444-16	SPRING
92-1000-1444-18	SPRING,COMP (7/16OD X 1 3/4LG)
92-1000-1448-16	SPRING,COMP (7/16OD X 2LG)
92-1000-1448-17	SPRING
92-1000-1628-15	COMPRESSION SPRING
92-1000-1632-18	SPRING
92-1000-1634-16	COMPRESSION SPRING
92-1000-1640-19	COMPRESSION SPRING
92-1000-1648-15	SPRING
92-1000-1648-17	SPRING
92-1000-1648-19	COMPRESSION SPRING
92-1000-1650-15	COMPRESSION SPRING
92-1000-1652-17	SPRING,COMP (1/2OD X2 1/2LG)
92-1000-1654-16	SPRING

PART #	DESCRIPTION
92-1000-1656-13	SPRING
92-1000-1660-15	COMPRESSION SPRING
92-1000-1664-16	COMPRESSION SPRING
92-1000-1688-16	SPRING
92-1000-1836-15	COMPRESSION SPRING
92-1000-1848-18	BODY SPRING
92-1000-1868-17	COMPRESSION SPRING
92-1000-1876-16	SPRING,COMP
92-1000-2032-19	SPRING
92-1000-2042-12	COMPRESSION SPRING
92-1000-2044-16	COMPRESSION SPRING
92-1000-2064-16	COMPRESSION SPRING
92-1000-2236-15	COMPRESSION SPRING
92-1000-2256-12	SPRING
92-1000-2260-12	SPRING
92-1000-2432-12	COMPRESSION SPRING
92-1000-2436-12	COMPRESSION SPRING
92-1000-2436-15	COMPRESSION SPRING
92-1000-4254-12	COMPRESSION SPRING
92-1010-806	NUT,HEX (1/4-24) 3/16 THK
92-1010-1006	NUT,HEX (5/16-20) 3/16 THK
92-1010-1210	NUT,HEX (3/8-16) 5/16 THK
92-1010-1408	NUT,HEX (7/16-14) 1/4 THK
92-1010-1810	NUT,HEX (9/16-14) 5/16 THK
92-1040-2010-34	ROUND NUT
92-1042-3214-46	ROUND NUT (ASM)
92-1043-2410-38	ROUND NUT
92-1043-2810-40	ROUND NUT
92-1043-2816-46	ROUND NUT
92-1043-2816-50	SPANNER NUT
92-1043-3410-44	SHAFT NUT
92-1043-3810-48	ROUND NUT
92-1043-4410-52	ROUND NUT
92-1043-4812-54	ROUND NUT
92-2010-602-14	WASHER,PLAIN
92-2010-802-16	WASHER,PLAIN
92-2010-804-34	WASHER

PART #	DESCRIPTION
92-2010-1002-20	WASHER,PLAIN
92-2010-1002-24	WASHER,PLAIN
92-2010-1004-20	WASHER
92-2010-1004-24	WASHER
92-2010-1004-28	WASHER,PLAIN
92-2010-1006-16	WASHER
92-2010-1202-24	WASHER,PLAIN
92-2010-1204-20	WASHER,PLAIN
92-2010-1204-22	PLAIN STEEL WASHER
92-2010-1204-24	WASHER,PLAIN
92-2010-1204-28	WASHER,PLAIN
92-2010-1204-32	WASHER
92-2010-1402-24	WASHER,PLAIN
92-2010-1402-32	PLAIN STEEL WASHER
92-2010-1403-32	PLAIN STEEL WASHER
92-2010-1404-28	WASHER,PLAIN
92-2010-1406-22	WASHER,FLAT (.438ID X 11/16OD)
92-2010-1602-28	WASHER,PLAIN
92-2010-1602-32	WASHER,PLAIN
92-2010-1602-34	WASHER,FLAT (.500ID X 1 1/8OD)
92-2010-1604-32	WASHER
92-2010-1604-34	WASHER,PLAIN
92-2010-1608-28	WASHER
92-2010-1804-32	WASHER
92-2010-1806-34	WASHER,PLAIN
92-2010-2002-34	WASHER,PLAIN
92-2010-2004-34	WASHER,PLAIN
92-2010-2004-36	WASHER
92-2010-2004-38	WASHER
92-2010-2004-42	WASHER,FLAT(.625IDX15/8ODX1/8T
92-2010-2006-46	WASHER,FLAT (.625ID X 1 7/8OD)
92-2010-2404-40	WASHER
92-2010-2406-38	WASHER
92-2010-2604-40	WASHER
92-2010-2804-36	WASHER
92-2010-3204-42	WASHER
92-2010-3206-44	WASHER

PART #	DESCRIPTION
92-2010-3504-44	WASHER
92-2010-3608-48	WASHER
92-2010-3704-46	WASHER, PLAIN
92-2010-3804-50	WASHER
92-2011-2204-40	WASHER, OIL GROVE
92-2020-1206-20	WASHER, PLAIN
92-2020-1606-24	WASHER, PLAIN
92-2030-3	SPRING
92-2030-4	LOCK WASHER
92-2030-5	SPRING LOCK WASHER
92-2030-6	LOCK WASHER
92-2030-8	LOCK WASHER
92-2030-10	LOCK WASHER
92-2030-12	WASHER
92-2030-16	WASHER SPRING LOCK
92-2030-20	WASHER SPRING LOCK
92-2031-13	LOCK WASHER
92-2031-16	LOCK WASHER
92-2031-19	LOCK WASHER
92-2031-22	LOCK WASHER
92-2031-26	LOCK WASHER
92-2031-31	LOCK WASHER
92-2031-35	LOCK WASHER
92-2031-35-1	LOCKWASHER
92-2031-38	LOCK WASHER
92-2031-42	LOCK WASHER
92-2031-45	LOCK WASHER
92-2031-48	LOCK WASHER
92-2031-50	LOCK WASHER
92-2031-51	LOCK WASHER
92-2031-54	LOCK WASHER
92-2031-58	LOCK WASHER
92-2040-402-12	WASHER
92-2040-602-12	WASHER, PLAIN
92-2040-702-12	WASHER, PLAIN
92-2040-702-16	WASHER
92-2040-802-16	WASHER, PLAIN

PART #	DESCRIPTION
92-2040-802-18	WASHER,PLAIN
92-2040-802-20	WASHER
92-2040-803-20	WASHER,PLAIN
92-2040-803-28	WASHER,PLAIN
92-2040-804-34	PLAIN STEEL WASHER
92-2040-1002-20	WASHER
92-2040-1002-24	WASHER
92-2040-1002-28	SCREW MACHINE RELATED ITEM
92-2040-1003-20	WASHER
92-2040-1004-20	WASHER,PLAIN
92-2040-1004-24	WASHER,PLAIN
92-2040-1004-32	WASHER,PLAIN
92-2040-1202-20	PLAIN WASHER
92-2040-1202-24	WASHER
92-2040-1202-28	WASHER,PLAIN
92-2040-1202-32	WASHER,PLAIN
92-2040-1203-28	WASHER,PLAIN
92-2040-1204-24	WASHER,PLAIN
92-2040-1204-28	WASHER,PLAIN
92-2040-1204-32	WASHER,PLAIN
92-2040-1204-36	WASHER,PLAIN
92-2040-1402-24	WASHER,PLAIN
92-2040-1402-28	WASHER,PLAIN
92-2040-1602-24	WASHER,PLAIN
92-2040-1602-28	WASHER,PLAIN
92-2040-1602-32	WASHER
92-2040-1604-32	WASHER,PLAIN
92-2040-1604-34	WASHER
92-2040-1604-36	WASHER
92-2040-1604-42	WASHER
92-2040-2004-32	WASHER,PLAIN
92-2040-2004-36	WASHER,PLAIN
92-2040-2004-40	WASHER
92-2040-2006-38	WASHER
92-2040-2404-40	WASHER
92-2040-2406-40	WASHER
92-2040-2408-48	PLAIN STEEL WASHER

PART #	DESCRIPTION
92-2040-2804-44	WASHER
92-2040-3204-44	WASHER
92-2040-3204-50	WASHER
92-2041-1208-24	WASHER
92-2041-1620-38	WASHER
92-2041-2012-34	PLAIN WASHER
92-2060-12	WASHER, SPHERICAL SEAT
92-2060-16	WASHER, SPHERICAL SEAT
92-2060-24	WASHER
92-2210-2018	BEARING
92-2301-34	PLUG
92-2370-1804-34	LEATHER WASHER
92-2370-3208-40	LEATHER WASHER
92-2370-4006-49	LEATHER WASHER
92-2390-5672	WASHER, RUBBER
92-2390-7288	WASHER, RUBBER
92-2440-424	NIPPLE, BLACK STEEL
92-2440-440	NIPPLE
92-2440-448	NIPPLE, STEEL
92-2440-828	NIPPLE
92-2440-832	NIPPLE
92-2440-840	NIPPLE (TOOL)
92-2440-864	NIPPLE
92-2440-1244	NIPPLE, STEEL (3/8NPT X 1 3/4LG)
92-2440-1264	NIPPLE
92-2440-1634	NIPPLE
92-2440-1648	NIPPLE
92-2440-1672	NIPPLE
92-2440-2452	NIPPLE
92-2440-3248	NIPPLE
92-2440-3264	NIPPLE
92-2450-835	TUBING
92-2490-14	WRENCH PIN
92-2490-16	PIN WRENCH
92-2510-38	WRENCH
92-2510-40	WRENCH, SPANNER
92-2520-44	WRENCH, SPANNER 1 3/4

PART #	DESCRIPTION
92-2520-48	WRENCH, SPANNER 2"
92-2520-52	WRENCH, SPANNER 2 1/2
92-3240-734	PIN
92-3610-1832-14	ROLLER SCREW
92-3901-620	SOCKET HEAD CAP SCREW
92-5010-810	SCREW MACHINE RELATED ITEM
92-5010-812	SCREW, SET(SQHD)1/4-20X3/8
92-5010-816	SCREW, SET(SQHD)1/4-20X1/2
92-5010-824	SCREW, SET(SQHD)1/4-20X3/4
92-5010-832	SCREW, SET(SQHD)1/4-20X1
92-5010-834	SET SCREW, SQUARE HEAD
92-5010-836	SCREW, SET(SQHD)1/4-20X1 1/4
92-5010-844	SCREW, SET(SQHD)1/4-20X1 3/4
92-5010-1012	SCREW, SET(SQHD)5/16-18X3/8
92-5010-1016	SCREW, SET(SQHD)5/16-18X1/2
92-5010-1020	SCREW, SET(SQHD)5/16-18X5/8
92-5010-1024	SCREW, SET(SQHD)5/16-18X3/4
92-5010-1032	SCREW, SET(SQHD)5/16-18X1
92-5010-1036	SCREW, SET(SQHD)5/16-18X1 1/4
92-5010-1040	SCREW, SET(SQHD)5/16-18X1 1/2
92-5010-1044	SCREW, SET(SQHD)5/16-18X1 3/4
92-5010-1048	SCREW, SET(SQHD)5/16-18X2
92-5010-1050	SCREW, SET(SQHD)5/16-18X2 1/4
92-5010-1056	SET SCREW, SQUARE HEAD
92-5010-1216	SCREW, SET(SQHD)3/8-16X1/2
92-5010-1224	SCREW, SET(SQHD)3/8-16X3/4
92-5010-1230	SET SCREW, SQUARE HEAD
92-5010-1232	SCREW, SET(SQHD)3/8-16X1
92-5010-1236	SCREW, SET(SQHD)3/8-16X1 1/4
92-5010-1248	SCREW, SET(SQHD)3/8-16X2
92-5010-1252	SCREW, SET(SQHD)3/8-16X2 1/2
92-5010-1632	SCREW, SET SQ HD(1/2-13X1
92-5010-1636	SCREW, SET(SQHD)1/2-13X1 1/4
92-5010-2036	SCREW, SET(SQHD)5/8-11X1 1/4
92-5012-620	SCREW, SET(SQHD)#10-32X5/8
92-5012-632	SCREW, SET(SQHD)#10-32X1
92-5012-810	SCREW, SET(SQHD)1/4-20X5/16

PART #	DESCRIPTION
92-5012-816	SCREW,SET(SQHD)1/4-20X1/2
92-5012-1020	SCREW,SET(SQHD)5/16-18X5/8
92-5012-1216	SCREW,SET(SQHD)3/8-16X1/2
92-5012-1220	SCREW,SET(SQHD)3/8-16X5/8
92-5020-820	T BOLT
92-5020-824	T BOLT
92-5020-832	T BOLT
92-5020-1028	T BOLT
92-5020-1032	T BOLT
92-5020-1232	T BOLT
92-5020-1236	T BOLT
92-5020-1240	T BOLT
92-5020-1250	T BOLT
92-5020-1252	T BOLT
92-5020-1254	T BOLT
92-5020-1258	T BOLT
92-5020-1632	T BOLT
92-5020-1640	T BOLT
92-5020-1644	T BOLT
92-5020-1648	T BOLT
92-5020-1649	T BOLT
92-5020-1650	T BOLT
92-5020-1652	T BOLT
92-5020-1658	T BOLT
92-5020-1660	T BOLT
92-5020-1662	T BOLT
92-5030-820	CAP SCREW,HEX HEAD
92-5030-836	CAP SCREW,HEX HEAD
92-5030-1028	CAP SCREW,HEX HEAD
92-5030-1032	SCREW
92-5030-1034	CAP SCREW, HEX HEAD
92-5030-1036	CAP SCREW,HEX HEAD
92-5030-1044	CAP SCREW,HEX HEAD
92-5030-1228	CAP SCREW, HEX HEAD
92-5030-1232	SCREW MACHINE RELATED ITEM
92-5030-1236	SCREW
92-5030-1628	SCREW,HHC (1/2-13 X 7/8)

PART #	DESCRIPTION
92-5030-1636	SCREW,HHC (1/2-13 X 1 1/4)
92-5030-1640	SCREW, STYLE 503
92-5030-1644	BOLT, HEX HEAD
92-5030-1648	SCREW,HHC (1/2-13 X 2)
92-5030-1676	DRAW BOLT
92-5030-2044	CAP SCREW,HEX HEAD
92-5035-816	SCREW,HHC (1/4-20 X 1/2)
92-5035-820	HEX HEAD SCREW
92-5035-824	SCREW,HHC (1/4-20 X 3/4)
92-5035-828	HEX HEAD CAP SCREW
92-5035-832	SCREW,HHC (1/4-20 X 1)
92-5035-836	SCREW,HHC (1/4-20 X 1 1/4)
92-5035-840	SCREW,HHC (1/4-20 X 1 1/2)
92-5035-850	SCREW,HHC (1/4-20 X 2 1/4)
92-5035-854	SCREW,HHC (1/4-20 X 2 3/4)
92-5035-1020	SCREW,HHC (5/16-18 X 5/8)
92-5035-1024	SCREW,HHC (5/16-18 X 3/4)
92-5035-1028	SCREW,HHC (5/16-18 X 7/8)
92-5035-1032	SCREW,HHC (5/16-18 X 1)
92-5035-1034	SCREW,HHC (5/16-18 X 1 1/8)
92-5035-1036	SCREW,HHC (5/16-18 X 1 1/4)
92-5035-1040	SCREW,HHC (5/16-18 X 1 1/2)
92-5035-1220	SCREW,HHC (3/8-16 X 5/8)
92-5035-1224	SCREW,HHC (3/8-16 X 3/4)
92-5035-1228	SCREW,HHC (3/8-16 X 7/8)
92-5035-1232	SCREW,HHC (3/8-16 X 1)
92-5035-1234	SCREW,HHC (3/8-16 X 1 1/8)
92-5035-1236	SCREW,HHC (3/8-16 X 1 1/4)
92-5035-1240	SCREW,HHC (3/8-16 X 1 1/2)
92-5035-1244	SCREW,HHC (3/8-16 X 1 3/4)
92-5035-1248	SCREW,HHC (3/8-16 X 2)
92-5035-1252	SCREW,HHC (3/8-16 X 2 1/2)
92-5035-1256	SCREW,HHC (3/8-16 X 3)
92-5035-1258	SCREW,HHC (3/8-16 X 3 1/4)
92-5035-1262	SCREW,HHC (3/8-16 X 3 3/4)
92-5035-1628	SCREW,HHC (1/2-13 X 7/8)
92-5035-1632	SCREW,HHC (1/2-13 X 1)

PART #	DESCRIPTION
92-5035-1636	SCREW,HHC (1/2-13 X 1 1/4)
92-5035-1640	SCREW,HHC (1/2-13 X 1 1/2)
92-5035-1644	SCREW,HHC (1/2-13 X 1 3/4)
92-5035-1648	SCREW,HHC (1/2-13 X 2)
92-5035-1660	SCREW,HHC (1/2-13 X 3 1/2)
92-5035-1668	SCREW,HHC (1/2-13 X 4 1/2)
92-5035-2052	SCREW,HHC (5/8-11 X 2 1/2)
92-5040-1024	SET SCREW,HEX HEAD
92-5041-1032	SCREW,SET (5/16-18X1)HEX HD
92-5041-1038	HEX HEAD SCREW
92-5041-1232	SCREW,SET (3/8-16X1)HEX HD
92-5041-1236	SCREW,SET (3/8-16X1 1/4)HEX HD
92-5041-1240	SCREW,SET (3/8-16X1 1/2)HEX HD
92-5041-1248	SCREW
92-5041-1648	SCREW,SET (1/2-13X2)HEX HD
92-5041-1652	SET SCREW (1/2-13,2 1/2")
92-5050-610	SCREW,FILLISTER HEAD
92-5050-616	SCREW,FILLISTER HEAD
92-5050-620	SCREW,FILLISTER HEAD
92-5050-628	SCREW,FILLISTER HEAD
92-5050-632	SCREW,FILLISTER HEAD
92-5050-636	SCREW,FILLISTER HEAD
92-5050-638	SCREW,FILLISTER HEAD
92-5050-644	SCREW,FILLISTER HEAD
92-5050-652	SCREW,FILLISTER HEAD
92-5050-818	SCREW,FILLISTER HEAD
92-5050-820	SCREW,FILLISTER HEAD
92-5050-824	SCREW,FILLISTER HEAD
92-5050-828	SCREW,FILLISTER HEAD
92-5050-834	SCREW,FILLISTER HEAD
92-5050-838	SCREW,FILLISTER HEAD
92-5050-840	SCREW,FILLISTER HEAD
92-5050-848	SCREW,FILLISTER HEAD
92-5050-1020	SCREW,FILLISTER HEAD
92-5050-1028	SCREW,FILLISTER HEAD
92-5050-1032	SCREW,FILLISTER HEAD
92-5050-1036	SCREW,FILLISTER HEAD

PART #	DESCRIPTION
92-5050-1038	SCREW,FILLISTER HEAD
92-5050-1040	SCREW,FILLISTER HEAD
92-5050-1044	SCREW,FILLISTER HEAD
92-5050-1224	SCREW,FILLISTER HEAD
92-5050-1232	SCREW,FILLISTER HEAD
92-5050-1234	SCREW,FILLISTER HEAD
92-5050-1236	SCREW,FILLISTER HEAD
92-5050-1240	SCREW,FILLISTER HEAD
92-5050-1248	SCREW,FILLISTER HEAD
92-5050-1250	SCREW,FILLISTER HEAD
92-5050-1640	SCREW,FILLISTER HEAD
92-5050-1644	SCREW,FILLISTER HEAD
92-5050-1656	SCREW,FILLISTER HEAD
92-5050-1660	SCREW, FILLISTER HEAD
92-5051-616	SCREW,FILL HD (#10-32 X 1/2)
92-5051-620	SCREW,FILLISTER HEAD
92-5051-624	SCREW,FILLISTER HEAD
92-5051-816	SCREW,FILLISTER HEAD
92-5051-820	SCREW,FILL HD (1/4-20 X 5/8)
92-5051-824	SCREW,FILLISTER HEAD
92-5051-828	SCREW,FILLISTER HEAD
92-5051-832	SCREW,FILLISTER HEAD
92-5051-840	SCREW,FILLISTER HEAD
92-5051-1024	SCREW,FILLISTER HEAD
92-5051-1028	SCREW,FILLISTER HEAD
92-5051-1032	SCREW,FILLISTER HEAD
92-5051-1224	SCREW,FILLISTER HEAD
92-5051-1228	SCREW,FILLISTER HEAD
92-5051-1236	SCREW,FILLISTER HEAD
92-5051-1240	SCREW,FILLISTER HEAD
92-5051-1640	SCREW,FILLISTER HEAD
92-5060-616	SCREW,SET FILL HEAD
92-5060-828	SCREW,FILLISTER HEAD
92-5070-616	SCREW,SET (HD LESS)
92-5070-812	SCREW,SET (HEADLESS)
92-5070-820	SCREW,SET (HEADLESS)
92-5070-824	SCREW,SET (HEADLESS)

PART #	DESCRIPTION
92-5070-828	SCREW,SET (HEADLESS)
92-5070-832	SCREW,SET (HEADLESS)
92-5070-836	SCREW,SET (HEADLESS)
92-5070-1024	SCREW,SET (HEADLESS)
92-5070-1032	SCREW,SET (HEADLESS)
92-5070-1228	SCREW,SET (HEADLESS)
92-5070-1620	SCREW,SET (HEADLESS)
92-5071-406	SCREW,SET (HEADLESS)
92-5071-606	SCREW,SET (HEADLESS)
92-5071-608	SCREW,SET (HEADLESS)
92-5071-612	SCREW,SET (HEADLESS)
92-5071-616	SCREW,SET (HEADLESS)
92-5071-808	SCREW,SET (HEADLESS)
92-5071-810	SCREW,SET (HEADLESS)
92-5071-812	SCREW,SET (HEADLESS)
92-5071-814	SCREW,SET (HEADLESS)
92-5071-816	SCREW,SET (HEADLESS)
92-5071-832	SCREW,SET (HEADLESS)
92-5071-840	SCREW,SET (HEADLESS)
92-5071-844	SCREW,SET (HEADLESS)
92-5071-1010	SCREW,SET (HEADLESS)
92-5071-1012	SCREW,SET (HEADLESS)
92-5071-1016	SET SCREW, HEADLESS (ASM)
92-5071-1028	SCREW,SET (HEADLESS)
92-5071-1210	SCREW,SET (HEADLESS)
92-5071-1212	SCREW,SET (HEADLESS)
92-5071-1216	SCREW,SET (HEADLESS)
92-5071-1220	SCREW,SET (HEADLESS)
92-5071-1224	SCREW,SET (HEADLESS)
92-5071-1232	SCREW,SET (HEADLESS)
92-5071-1240	SET SCREW,HEADLESS
92-5071-1248	SCREW,SET (HEADLESS)
92-5071-1250	SCREW,SET (HEADLESS)
92-5071-1254	SCREW,SET (HEADLESS)
92-5071-1612	SCREW,SET (HEADLESS)
92-5071-1644	SCREW,SET (HEADLESS)
92-5071-2020	SCREW,SET (HEADLESS)

PART #	DESCRIPTION
92-5071-2420	SCREW,SET (HEADLESS)
92-5072-640	STUD,PLAIN THREADED
92-5072-838	STUD,PLAIN THREADED
92-5072-842	STUD,PLAIN THREADED
92-5072-1046	STUD,PLAIN THREADED
92-5072-1246	STUD,PLAIN THREADED
92-5080-408	SCREW,FLAT HEAD
92-5080-416	SCREW,FLAT HEAD
92-5080-424	SCREW,FLAT HEAD
92-5080-610	SCREW,FLAT HEAD
92-5080-612	SCREW,FLAT HEAD
92-5080-616	SCREW,FLAT HEAD
92-5080-620	SCREW,FLAT HEAD
92-5080-624	SCREW,FLAT HEAD
92-5080-816	SCREW,FLAT HEAD
92-5080-820	SCREW,FLAT HEAD
92-5080-824	SCREW,FLAT HEAD
92-5080-832	SCREW,FLAT HEAD
92-5080-1032	SCREW,FLAT HEAD
92-5081-408	SCREW,FLAT HEAD
92-5081-412	SCREW,FLAT HEAD
92-5081-416	SCREW,FLAT HEAD
92-5081-420	SCREW,FLAT HEAD
92-5081-424	SCREW,FLAT HEAD
92-5081-610	SCREW,FLAT HEAD
92-5081-612	SCREW,FLAT HEAD
92-5081-616	SCREW,FLAT HEAD
92-5081-620	SCREW,FLAT HEAD
92-5081-624	SCREW,FLAT HEAD
92-5081-820	SCREW,FLAT HEAD
92-5081-824	SCREW,FLAT HD
92-5081-1032	SCREW,FLAT HEAD
92-5100-406	SCREW,SET
92-5100-606	SCREW,SET (CONE POINT)
92-5100-808	SCREW,SET (CONE POINT)
92-5120-816	KNURLED HEAD THUMB SCREW
92-5120-820	KNURLED HEAD THUMB SCREW

PART #	DESCRIPTION
92-5130-816	KNURLED HEAD SCREW
92-5130-1224	KNURLED HEAD SCREW
92-5171-1240	SCREW,SPHCRL SEATHEXHD3/8X11/2
92-5191-610	SCREW,SET(SQHD)#10-32X5/16DOGP
92-5191-612	SCREW,SET(SQHD)#10-32X3/8DOGP
92-5191-624	SCREW,SET(SQHD)#10-32X3/4DOGP
92-5191-814	SCREW,SET(SQHD)1/4-20X7/16DOGP
92-5191-818	SCREW,SET(SQHD)1/4-20X9/16DOGP
92-5191-824	SCREW,SET(SQHD)1/4-20X3/4DOGP
92-5191-1016	SCREW,SET(SQHD)5/16-18X1/2DOGP
92-5191-1028	SCREW,SET(SQHD)5/16-18X7/8DOGP
92-5191-1032	SCREW,SET(SQHD)5/16-18X1DOG PT
92-5191-1040	SCREW,SET(SQHS)5/16-18X11/2DOG
92-5191-1232	SCREW,SET(SQHD)3/8-16X1DOG PT
92-5200-616	SCREW,FILLISTER LARGEHEAD
92-5200-824	SCREW,FILLISTER LARGEHEAD
92-5200-832	SCREW,FILLISTER LARGEHEAD
92-5200-1024	SCREW,FILLISTER LARGEHEAD
92-5200-1032	SCREW,FILLISTER LARGEHEAD
92-5200-1044	SCREW,FILLISTER LARGEHEAD
92-5200-1236	SCREW,FILLISTER LARGEHEAD
92-5200-1244	SCREW,FILLISTER LARGEHEAD
92-5201-408	SCREW,RHM (#6-40 X 1/4)
92-5201-436	SCREW,RHM (#6-40 X 1 1/4)
92-5201-608	SCREW,RHM (#10-32 X 1/4)
92-5201-612	SCREW,RHM (#10-32 X 3/8)
92-5201-616	SCREW,RHM (#10-32 X 1/2)
92-5201-632	SCREW,RHM (#10-32 X 1)
92-5201-816	SCREW,RHM (1/4-20 X 1/2)
92-5201-1012	SCREW,RHM (5/16-18 X 3/8)
92-5201-1020	SCREW,RHM (5/16-18 X 5/8)
92-5201-1050	SCREW,RHM (5/16-18 X 2 1/4)
92-5270-616	SCREW,FILLISTER SHOLDER
92-5270-806	SCREW,FILLISTER SHOLDER
92-5270-816	SCREW,FILLISTER SHOLDER
92-5270-1010	SCREW,FILLISTER SHOLDER
92-5270-1028	SCREW,FILLISTER SHOLDER

PART #	DESCRIPTION
92-5270-1032	SCREW,FILLISTER SHOLDER
92-5270-1628	SCREW,FILLISTER HD. SHOULDER
92-5310-620	SCREW,PLAIN SHOULDER
92-5310-628	SCREW,PLAIN SHOULDER
92-5310-832	SCREW,PLAIN SHOULDER
92-5340-812-4	SCREW,FILLISTER TEATED
92-5340-816-8	SCREW,FILLISTER TEATED
92-5340-1012-8	SCREW,FILLISTER TEATED
92-5340-1020-8	SCREW,FILLISTER TEATED
92-5340-1224-6	SCREW,FILLISTER TEATED
92-5340-1224-12	SCREW,FILLISTER TEATED
92-5350-608-2	TEATED SCREW,FLAT HEAD
92-5361-608-2	TEATED SCREW
92-5361-608-4	TEATED SCREW
92-5361-610-2	TEATED SCREW
92-5361-610-4	TEATED SCREW (ASM)
92-5361-810-4	TEATED SCREW,HEADLESS
92-5361-816-4	TEATED SCREW,HEADLESS
92-5361-1016-4	TEATED SCREW
92-5361-1020-4	TEATED SCREW
92-5361-1020-8	TEATED SCREW
92-5361-1228-8	TEATED SCREW
92-5361-1232-8	TEATED SCREW
92-5361-1628-12	TEATED SCREW
92-5370-1224	SCREW,SET(3/8-16X3/4)CONE PT
92-5370-1238	SCREW,SET(3/8-16X1 3/8)CONE PT
92-5370-1240	SPACER SCREW
92-5380-608	SCREW,SHC (#10-32 X 1/4)
92-5380-610	SCREW,HEX SOCKET HEAD CAP
92-5380-612	SCREW
92-5380-616	SCREW,SHC (#10-32 X 1/2)
92-5380-624	SCREW, RETAINING
92-5380-632	SCREW,SHC (#10-32 X 1)
92-5380-636	SCREW,SHC (#10-32 X 1 1/4)
92-5380-808	SCREW,HEX SOCKET HEAD CAP
92-5380-816	SCREW,SHC (1/4-20 X 1/2)
92-5380-824	SCREW,SHC (1/4-20 X 3/4)

PART #	DESCRIPTION
92-5380-832	SCREW,SHC (1/4-20 X 1)
92-5380-836	SCREW,SHC (1/4-20 X 1 1/4)
92-5380-840	SCREW,SHC (1/4-20 X 1 1/2)
92-5380-844	SCREW,SHC (1/4-20 X 1 3/4)
92-5380-848	SCREW,SHC (1/4-20 X 2)
92-5380-850	SCREW,SHC (1/4-20 X 2 1/4)
92-5380-852	SCREW,SHC (1/4-20 X 2 1/2)
92-5380-1016	SCREW,SHC (5/16-18 X 1/2)
92-5380-1024	SCREW,SHC (5/16-18 X 3/4)
92-5380-1032	SCREW,SHC (5/16-18 X 1)
92-5380-1036	SCREW,SHC (5/16-18 X 1 1/4)
92-5380-1040	SCREW,SHC (5/16-18 X 1 1/2)
92-5380-1044	SCREW,SHC (5/16-18 X 1 3/4)
92-5380-1048	SCREW,SHC (5/16-18 X 2)
92-5380-1050	SCREW,SHC (5/16-18 X 2 1/4)
92-5380-1216	SCREW,SHC (3/8-16 X 1/2)
92-5380-1224	SCREW,SHC (3/8-16 X 3/4)
92-5380-1232	SCREW,SHC (3/8-16 X 1)
92-5380-1236	SCREW,SHC (3/8-16 X 1 1/4)
92-5380-1240	SCREW,SHC (3/8-16 X 1 1/2)
92-5380-1244	SCREW,SHC (3/8-16 X 1 3/4)
92-5380-1248	SCREW,SHC (3/8-16 X 2)
92-5380-1258	SCREW,SHC (3/8-16 X 3 1/4)
92-5380-1260	SCREW,SHC (3/8-16 X 3 1/2)
92-5380-1616	SCREW
92-5380-1632	SCREW,SHC (1/2-13 X 1)
92-5380-1636	SCREW,SHC (1/2-13 X 1 1/4)
92-5380-1640	SCREW,SHC (1/2-13 X 1 1/2)
92-5380-1644	SCREW,SHC (1/2-13 X 1 3/4)
92-5380-1650	SCREW,SHC (1/2-13 X 2 1/4)
92-5380-1654	SCREW,SHC (1/2-13 X 2 3/4)
92-5380-1664	BOLT
92-5380-1668	BOLT
92-5381-1016	SCREW,SHC (5/16-18 X 1/2)
92-5381-1024	SCREW,SHC (5/16-18 X 3/4)
92-5381-1028	SCREW,SHC (5/16-18 X 7/8)
92-5381-1032	SCREW,SHC (5/16-18 X 1)

PART #	DESCRIPTION
92-5381-1036	SCREW,SHC (5/16-18 X 1 1/4)
92-5381-1050	SCREW,SHC (5/16-18 X 2 1/4)
92-5385-608	SCREW MACHINE RELATED ITEM
92-5385-612	SCREW,BHC (#10-32 X 3/8)
92-5385-616	SCREW,BHC (#10-32 X 1/2)
92-5385-620	SCREW,BHC (#10-32 X 5/8)
92-5385-624	SCREW,BHC (#10-32 X 3/4)
92-5385-632	SCREW,BHC (#10-32 X 1)
92-5385-812	SCREW,BHC (1/4-20 X 3/8)
92-5385-816	SCREW,BHC (1/4-20 X 1/2)
92-5385-820	SCREW,BHC (1/4-20 X 5/8)
92-5385-824	SCREW,BHC (1/4-20 X 3/4)
92-5385-832	SCREW,BHC (1/4-20 X 1)
92-5385-1012	SCREW,BHC (5/16-18 X 3/8)
92-5385-1016	SCREW,BHC (5/16-18 X 1/2)
92-5385-1020	SCREW,BHC (5/16-18 X 5/8)
92-5385-1024	SCREW,BHC (5/16-18 X 3/4)
92-5385-1032	SCREW,BHC (5/16-18 X 1)
92-5385-1216	SCREW,BHC (3/8-16 X 1/2)
92-5385-1220	SCREW,BHC (3/8-16 X 5/8)
92-5385-1224	SCREW,BHC (3/8-16 X 3/4)
92-5385-1232	SCREW,BHC (3/8-16 X 1)
92-5385-1236	SCREW,BHC (3/8-16 X 1 1/4)
92-5385-1240	SCREW,BHC (3/8-16 X 1 1/2)
92-5385-1632	SCREW,BUTTON HD.SOCKET CAP
92-5385-1636	ASM PART
92-5386-424	SCREW,S/TAP (#6X3/4)RD HD "F"
92-5386-510	SCREW,S/TAP (#8X5/16)RD HD "F"
92-5386-516	SCREW,S/TAP (#8X1/2)RD HD "F"
92-5386-520	SCREW,S/TAP (#8X5/8)RD HD "F"
92-5386-532	SELF TAPPING SCREW
92-5386-620	SCREW,S/TAP (#10X5/8)RD HD "F"
92-5386-820	SCREW,S/TAP (1/4X5/8)RD HD "F"
92-5390-606	SCREW,SET (#10X3/16)CUP POINT
92-5390-608	SCREW,SET (#10X1/4) CUP PT
92-5390-612	SCREW,SET (#10X3/8) CUP PT
92-5390-616	SCREW,SET (#10-32X1/2)CUP PT

PART #	DESCRIPTION
92-5390-620	SCREW,SET (#10X5/8) CUP PT
92-5390-806	SCREW,SET (1/4X3/16) CUP PT
92-5390-808	SCREW,SET (1/4X1/4) CUP PT
92-5390-812	SCREW,SET (1/4X3/8) CUP PT
92-5390-816	SCREW,SET (1/4X1/2) CUP PT
92-5390-820	SCREW,SET (1/4X5/8) CUP PT
92-5390-824	SCREW,SET (1/4X3/4) CUP PT
92-5390-1008	SCREW,SET (5/16-18X1/4)CUP PT
92-5390-1012	SCREW,SET (5/16-18X3/8)CUP PT
92-5390-1016	SCREW,SET (5/16-18X1/2)CUP PT
92-5390-1020	SCREW,SET (5/16-18X5/8)CUP PT
92-5390-1212	SCREW,SET (3/8-16X3/8) CUP PT
92-5390-1216	SCREW,SET (3/8-16X1/2)CUP PT
92-5390-1220	SCREW,SET (3/8-16X5/8)CUP PT
92-5390-1224	SCREW,SET (3/8-16X3/4)CUP PT
92-5390-1440	SCREW,SET (7/16-14X1 1/2)CUPPT
92-5390-1616	SCREW,SET (1/2-13X1/2)CUP PT
92-5390-1624	SCREW,SET (1/2-13X3/4) CUP PT
92-5390-1632	SCREW,SET (1/2-13X1) CUP PT
92-5390-2020	SCREW,SET (5/8-11X5/8) CUP PT
92-5391-408	SCREW,SET (#6-40X1/4) OVAL PT
92-5391-608	SCREW,SET (#10-32X1/4)OVAL PT
92-5391-610	SCREW,SET (#10-32X5/16)OVAL PT
92-5391-808	SCREW,SET (1/4-20X1/4)OVAL PT
92-5391-810	SCREW,SET (1/4-20X5/16)OVAL PT
92-5391-812	SCREW,SET (1/4-20X3/8)OVAL PT
92-5391-816	SCREW,SET (1/4-20X1/2)OVAL PT
92-5391-824	SCREW,SET (1/4-20X3/4)OVAL PT
92-5391-832	SCREW,SET (1/4-20X1)OVAL PT
92-5391-836	SCREW,SET (1/4-20X1 1/4)OVALPT
92-5391-1010	SCREW,SET (5/16-18X5/16)OVALPT
92-5391-1012	SCREW,SET (5/16-18X3/8)OVAL PT
92-5391-1016	SCREW,SET (5/16-18X1/2)OVAL PT
92-5391-1020	SCREW,SET (5/16-18X5/8)OVAL PT
92-5391-1024	SCREW,SET (5/16-18X3/4)OVAL PT
92-5391-1032	SCREW,SET (5/16-18X1)OVAL PT
92-5391-1036	SCREW,SET (5/16-18X11/4)OVALPT

PART #	DESCRIPTION
92-5391-1210	SCREW,SET (3/8-16X5/16)OVAL PT
92-5391-1216	SCREW,SET (3/8-16X1/2)OVAL PT
92-5391-1224	SCREW,SET (3/8-16X3/4)OVAL PT
92-5391-1232	SCREW,SET (3/8-16X1) OVAL PT
92-5391-1244	SCREW,SET (3/8-16X13/4)OVAL PT
92-5391-1248	SET SCREW 3/8 UNC 2" LONG
92-5391-2024	SCREW,SET (5/8-11X3/4) OVAL PT
92-5550-6	CUP,OIL (3/16DIA X 15/32)
92-5550-8	CUP,OIL (1/4DIA X 13/32)
92-5550-14	CUP,OIL (7/16DIA X 11/16)
92-5550-16	OIL CUP
92-5550-20	CUP,OIL (5/8DIA X 13/16)
92-5550-32	OIL CUP
92-5560-6	COVER
92-5560-8	COVERS,OIL HOLE
92-5570-1336	CUP,WICK FEED OIL
92-5590-812	OIL CUP
92-5590-1032	CUP, OIL, ELBOW
92-5590-1730	OIL CUP, ELBOW
92-5660-1348	FITTING,GREASE (1/8NPFT STR)
92-5801-5	HANDLE,HANDWHEEL(.81DIA X 2.19LG
92-5801-6	HANDLE,HANDWHEEL(.94DIA X 2.44LG
92-5802-7	HANDLE, HANDWHEEL
92-5930-502	PIN,BRASS
92-5930-504	PIN,BRASS
92-5930-604	PIN,BRASS
92-5930-606	SHOE
92-5930-608	PIN,BRASS
92-5930-612	PIN,BRASS
92-5930-632	PIN,BRASS
92-5930-638	PIN,BRASS
92-5930-806	PIN,BRASS
92-5930-810	PIN,BRASS
92-5930-1004	PIN,BRASS
92-5930-1008	PIN,BRASS
92-5930-1016	PIN,BRASS
92-5990-212	PIN,COTTER (1/32DIA X 3/8LG)

PART #	DESCRIPTION
92-5990-216	PIN, COTTER
92-5990-316	PIN,COTTER (3/64DIA X 1/2LG)
92-5990-332	PIN,COTTER (3/64DIA X 1LG)
92-5990-416	PIN,COTTER (1/16DIA X 1/2LG)
92-5990-424	PIN,COTTER (1/16DIA X 3/4LG)
92-5990-432	PIN,COTTER (1/16DIA X 1LG)
92-5990-436	PIN,COTTER (1/16DIA X 1 1/4LG)
92-5990-616	PIN,COTTER (3/32DIA X 1/2LG)
92-5990-624	PIN,COTTER (3/32DIA X 3/4LG)
92-5990-632	PIN,COTTER (3/32DIA X 1LG)
92-5990-636	PIN,COTTER (3/32DIA X 1 1/4LG)
92-5990-824	COTTER PIN
92-5990-832	PIN,COTTER (1/8DIA X 1LG)
92-5990-840	PIN,COTTER (1/8DIA X 1 1/2LG)
92-5990-848	PIN,COTTER (1/8DIA X 2LG)
92-5990-856	PIN,COTTER
92-6010-611	NUT,HEX
92-6010-808	NUT,HEX
92-6010-816	NUT,HEX
92-6010-1012	NUT,TRIP LEVER ADJ. SCREW
92-6010-1017	NUT,HEX
92-6010-1216	NUT,HEX
92-6010-1224	NUT,HEX
92-6010-1620	NUT,HEX
92-6010-1632	NUT
92-6010-2432	NUT,HEX
92-6012-8	NUT,HEX SLOTTED
92-6013-8	NUT,HEX SLOTTED
92-6013-10	NUT,HEX
92-6013-12	NUT,HEX
92-6013-16	NUT,HEX
92-6015-608	NUT,HEX (#10-32)
92-6015-808	NUT
92-6015-810	NUT,HEX (1/4-20)
92-6015-814	NEX NUT
92-6015-1012	HEX NUT
92-6015-1017	NUT,HEX (5/16-18)

PART #	DESCRIPTION
92-6015-1214	NUT,HEX (3/8-16)
92-6015-1216	NUT
92-6015-1221	NUT, HEX (3/8-16)
92-6015-1620	NUT,HEX (1/2-13)
92-6015-1628	NUT,HEX (1/2-13)
92-6015-2024	NUT,HEX (5/8-11)
92-6015-2035	NUT,HEX (5/8-11)
92-6015-2427	NUT,HEX (3/4-10)
92-6042-3214-46	SPLIT ROUND NUT
92-6042-3414-48	NUT,ROUND
92-6043-13	LOCKNUT
92-6043-15	LOCKNUT
92-6043-19	LOCKNUT
92-6043-21	LOCKNUT
92-6043-25	LOCKNUT
92-6043-31	LOCKNUT
92-6043-35	LOCKNUT
92-6043-38	LOCKNUT
92-6043-41	LOCKNUT
92-6043-44	LOCKNUT
92-6043-51	LOCKNUT
92-6043-54	LOCKNUT
92-6071-1616	NUT,HEX COLLAR (1/2-13)
92-6071-2020	NUT,HEX COLLAR (5/8-11)
92-6100-10	NUT,KNURLED
92-6100-12	NUT,KNURLED
92-6150-1224	NUT,CLAMP
92-20101-818	WASHER
92-20101-1028	WASHER
92-20101-1228	WASHER
92-50351-825	BOLT,HEX HD (8MM X 25MM)
92-50351-1030	SCREW
92-50351-1040	SCREW
92-50801-516	SCREW
92-51911-520	SCREW
92-52011-412	SCREW,RHM (M4 X 12)
92-53801-512	SCREW

PART #	DESCRIPTION
92-53801-518	SET SCREW
92-53801-612	CAP SCREW
92-53801-625	SCREW
92-53801-635	SCREW
92-53801-820	SCREW
92-53801-830	SCREW
92-53801-1025	SCREW
92-53801-1280	SCREW
92-53851-612	SCREW
92-53901-44	SCREW
92-53911-640	SCREW
92-60101-43	LOCKNUT
92-60101-54	LOCK NUT
92-60101-65	LOCK NUT
92-60101-108	NUT
92-60151-53	LOCK NUT
103.151	PUMP
142-00-1-3	SPINDLE UNIT, 1/2"
142-00-1-7	SPINDLE UNIT, 1/2"
142-00-10-2-P	CIRCULAR TOOL POST, REAR
142-00-15-1	TRANSFER MECHANISM
142-00-15-2	MECHANISM
142-00-21-2	BURRING HEAD
142-00-23	SPINDLE, DRILL
142-00-48-2	TURRET ANGL GR BX UNIT
142-00-49-2	ANGLE GEAR BOX UNIT
142-00-51-1	MOTOR DRIVE BRKT UNIT
142-00-52-2	TURRET COMPLETE, 8 HOLE #00
142-00-73-1	HEAD, MILLING
142-00-80-1	SPINDLE UNIT, 3/4"
142-00-299-99	SPINDLE UNIT, HIGH SPEED
142-2-13-2	SLOTING HEAD COMPLETE
142-2-21	BURRING HEAD
142-2-26-2	DRILL SPINDLE POST COMP
142-2-49-3	CROSS DRILL GEAR BOX
142-2-51	BRACKET UNT
142-2-55-3	SPINDLE UNIT 3/4, #2

PART #	DESCRIPTION
142-2-61-1	#2 MILLING HEAD
142-2-73	HEAD,MILLING
142-2-73-ZZ	MILLING HEAD, PROTOTYPE
142-2-74	SPINDLE,DRILL
142-2-76-1	TRANSMISSION
142-2-82-DRAWING	ASSEMBLY DRAWING, 1-5/8
142-2-83-2	SPINDLE UNIT 1 1/4"
142-2-84	MECHANISM,XFR
142-2-86	TURRET COMPLETE, 8HOLE #2
142-2-87-1	SPINDLE UNIT, 2 3/8"
142-2-93-1	PLATE & GASKET ETC, 2 SPEED
142-2-95-3	ELECT. PARTS, MACH. W/ACCLRTR
142-2-98-4	CONTROL CABINET
142-2-300-99	SPINDLE UNIT
142-2-5513-1	SLOTING HEAD, UK DESIGN
142-66097-1	ELECTRICAL PART
151-134-403B	NEEDLE BEARING, REAR CAGE ASSY
151-750-403B-99	WIPER
151-87550-4070	CHUCK LEVER (TOGGLE SWITCH)
151-94177-4070	CLUTCH BODY WASHER (BOND ASSY)
151-94581-4071	CLUTCH BODY (CVA12)
151-95916-4070	NOSE CAP
201.171	FLUORESCENT LAMP
201.200	STARTERS 15-20 W
201.359	MICROSWITCH
205.499	REACTOR
205.507	EXTENSION KIS M62
205.825	SOCKET
206-188	MANCHESTER, INSERT HOLDER
206-241	MANCHESTER CUTOFF HOLDER
206-242	MANCHESTER CUTOFF TOOL HOLDER
206.218	SERIES LIMIT SWITCH
206.315	ELECTRIC CONDUCTOR
206.357	LIMIT SWITCH
206.489	ELECTRIC BRAKE
206.499	ELECTRIC CONDUCTOR
206.604	MICRO-SWITCH

PART #	DESCRIPTION
210-122	CIRCLIP WIRE TYPE
210-244-110	10 MASTER FEEDFINGER WRENCH
210-411	RUBBER INSERT #11 SPR COLLET
210-422	CIRCLIP WIRE TYPE
210-710-1	RUBBER INSERT
210-710-2	SPRING,
210-723	CIRCLIP WIRE TYPE
210-1055-99	O BURR COLLET
210-1057	BLANK COLLET 2
210-1064	INSERT
210-51020	WRENCH
210-51021	FEED FINGER WRENCH
211-6018-1	TOOL HOLDER
211-6706	RETAINER PIN (USED IN SUB)
211-6707	SPACER (USED IN SUB)
211-10520-1	CLAMP SCREW
211-18523-1	CLAMP BUSHING
211-40203	INSERT
211-60007	FEED ADJ KNOB
211-96003	CENTER DRILL
211-99990-1-1	INSTRUCTIONS
211-99990-2	INSTRUCTION SHEET
283-1-225	OPM SPINDLE INDEXING & LOCATE
283-1-320	PARTS MANUAL, OO & OOG
283-1-321	MANUAL, PARTS OG
283-1-321-1	MANUAL PARTS OG AUTO
283-1-321-2	MANUAL, ATTACHMENTS ONLY OG
283-1-322	PARTS MANUAL, 2G AUTOMATIC
283-1-324	OPM & PARTS MANUAL,PINION TURN
283-1-326	MANUAL,PARTS, SCREW THREADING
283-1-327	OPM & PARTS MANUAL, 00 AUTO
283-1-327-2	MANUAL, SUPPLEMENT , OO
283-1-331	MANUAL, PARTS OO HAND
283-1-333-1	MANUAL, OPM & PARTS,#2 HAND
283-1-336	OPERATORS MANUAL, #2 AUTOMATIC
283-1-337	PARTS MANUAL, #2 AUTOMATIC
283-1-350	OPM. & PARTS MANUAL, ROD MAG.

PART #	DESCRIPTION
283-1-350-2	MANUAL,PARTS AURO ROD MAG
283-1-351-2	MANUAL, OPM & PARTS #4
283-1-501	PARTS MANUAL, #2B ULTRA R/S
283-1-504	MANUAL,PARTS 2B AUTOMATIC
283-1-505	MANUAL, OPM 2B AUTOMATIC
283-1-506	MANUAL,PARTS #2-2G AUTO/H.SPD
283-1-507	MANUAL, PARTS & OPM #2 AUTO
283-1-507-1	MANUAL, ATTACHMENTS 2/2G
283-1-508	MANUAL,PARTS 2G AUTOMATIC
283-1-509	MANUAL, PARTS ATTACH
283-1-510	MANUAL, PARTS #2-2 AUTOMATIC
283-1-511	MANUAL,PARTS #2 AUTOMATIC
283-1-512	MANUAL, SUPPLEMENT PARTS
283-1-513	MANUAL, PARTS/ATTCH 2G
283-1-514	MANUAL, OPM / OO AUTO
283-1-516	MANUAL, PARTS OOG
283-1-517	MANUAL, PARTS OO AUTO
283-1-518	MANUAL, PARTS OO/OOG
283-1-519	MANUAL,PARTS/POLISH/FINISH
283-1-520	MANUAL,PARTS OOG AUTO
283-1-522	MANUAL, OPERATORS MODEL#8
283-1-523	MANUAL, PARTS #4 AND #6 AUTO
283-1-524	MANUAL, PARTS 00 AUTO
283-1-525	MANUAL, PARTS OOG AUTO
283-1-526	MANUAL, ATTACHMENTS 00 AUTO
283-1-527	MANUAL, PARTS OOB AUTO
283-1-529	MANUAL, PARTS 0,1,2 WIRE FEED
283-1-530	MANUAL,PARTS 0 HAND SCREW
283-1-531	MANUAL,PARTS O AUTO
283-1-532	MANUAL, OPM MINI 16 AUTO
283-1-532-1	MANUAL, PARTS MINI 16
283-1-534	CONVERSION LIST,TOOLING
283-1-535	MANUAL, PARTS AUTO CUTTING OFF
283-1-536	MANUAL, PARTS O AUTO
283-1-537	MANUAL, PARTS O AUTO
283-1-538	MANUAL, OPM OOG & 2G
283-1-539	MANUAL, #2 DYNAPACT

PART #	DESCRIPTION
283-1-540	MANUAL, OPM 2CR AUTO DYNAPACT
283-1-541	MANUAL, PARTS OO DYNAPACT
283-1-542	MANUAL, OPM OO DYNAPACT
283-1-544	PARTS MANUAL
283-1-545	MANUAL, PARTS OO/OOG
283-1-546	REPAIR PARTS CVA 12,16,20
283-1-560	MANUAL, PARTS (O & OG)
300.003	COMPRESSION SPRING
300.005	COMPRESSION SPRING
300.014	TRACTION SPRING
300.028	PIECE COUNTER, COMPLETE
300.030	COMPRESSION SPRING
300.031	COMPRESSION SPRING
300.032	ROLLER CHAIN
300.035	LINK
300.036	LINK
300.037	TRACTION SPRING
300.049	COMPRESSION SPRING
300.070	SPRING
300.080	SPRING, COMPRESSION
300.085	COMPRESSION SPRING
300.106	SPRING
300.108	SPRING
300.121	SPRING, PRESSURE
300.122	COMPRESSION SPRING
300.123	SPRING, CROSS SLIDE
300.161	COMPRESSION SPRING
300.488	FELT RING
300.539	ADJUSTING SPRING
300.541	ADJUSTING SPRING
300.600	HEXAGONAL NUT
300.721	V-BELT
300.930	SHAFT PACKING
300.974	BALL BEARING
300.983	BALL BEARING
300.986	BALL BEARING
300.989	BALL BEARING

PART #	DESCRIPTION
301.033	ROUND-HD NOTCHED NAIL
301.103	CAP SCREW
301.137	BALL
301.159	SCREW
301.160	ALLEN SCREW
301.164	ALLEN SCREW
301.177	ALLEN SCREW
301.182	CAP SCREW
301.210	ALLEN SCREW
301.230	THREADED PIN
301.240	CIRCLIP
301.242	CIRCLIP
301.254	CIRCLIP
301.280	CIRCLIP
301.281	CIRCLIP
301.282	LOCKING WASHER
301.287	CIRCLIP
301.394	AXIAL NEEDLE BEARING
301.398	NEEDLE BEARING
302.098	BALL BEARING
302.100	ALLEN SCREW
302.173	CIRCLIP
302.288	CAP SCREW
302.289	BALL
302.291	FELT RING
302.414	AXIAL NEEDLE BEARING
302.562	ANGLE JOINT CPL
302.614	BALL PIN
302.674	ROLLER CHAIN
302.754	SECURITY RING
302.821	NEEDLE BEARING
302.914	OIL SIGHT GLASS
302.936	ADJUSTING SPRING KEY
302.937	ADJUSTING SPRING KEY
302.946	OIL SIGHT GLASS 32D
302.947	PACKING RING
302.952	SPRING

PART #	DESCRIPTION
302.962	NEEDLE CAGE
302.964	WASHER
302.969	SCREW M8X16
302.993	SPRING, TURRET A25
303.254	SPACER
303.377	PRYM SPIRAL PIN
303.424	COMPRESSION SPRING
303.516	PRESSURE SPRING
305.534	PRESSURE SPRING
305.713	COLLET, DIN TD36, ROUND
305.723	COLLET, TD36 ROUND 27MM DIN
305.726	COLLET, ROUND DIN TD36,28MM
310-102	MANCHESTER SUPPORT BLADE
310-108	MANCHESTER SUPPORT BLADE
311-104	MANCHESTER SUPPORT BLADE
311.025	BALL BEARING
311.040	THREADED PIN
311.116	TAPERED PIN
311.131	PIN
311.233	CYLINDRICAL PIN
311.313	HEX SCREW
311.314	HEX SCREW
311.332	BEARING
311.391	SERRATED BELT
311.403	PRYM SPIRAL PIN
311.497	ELECTRIC CONDUCTOR ZF
311.547	ELECTRIC CONDUCTOR ZF
311.598	SLEEVE MB
311.664	BUSHING
312.135	GREASE NIPPLE
312.136	GREASE NIPPLE
312.137	GREASE NIPPLE
312.200	COMPRESSION SPRING
312.205	BALL BEARING
312.210	AXIAL ROLLER BEARING
312.217	BUSHING MB 1815 DU
312.247	PRESSURE SPRING

PART #	DESCRIPTION
312.264	THRUST WASHER
312.269	ROLLER PIN CPL
312.270	BUTOM-HEAD RIVET
312.271	COMPRESSION SPRING
312.273	PACKING RING
312.275	BUSHING
312.276	BUSHING MB 1615 DU
312.286	WASHER WC-30 DU
312.299	SPINDLE BEARING
312.302	COMPRESSION SPRING
312.303	COMPRESSION RING
312.304	CLAMPING PIN
312.318	NEEDLE BEARING
312.319	NEEDLE BEARING
312.322	COMPRESSION SPRING
312.323	COMPRESSION SPRING
312.324	COMPRESSION SPRING
312.325	COMPRESSION SPRING
312.326	COMPRESSION SPRING
312.327	COMPRESSION SPRING
312.329	STUD
312.330	AXIAL ROLLER BEARING
312.331	WASHER
312.335	SLEEVE MB
312.338	SERRATED BELT
312.355	CIRCLIP
312.358	AXIAL NEEDLE CAGE
312.359	THRUST WASHER AS-2035
312.360	HOUSING DISC
312.367	KNURLED PIN
312.369	SERRATED BELT
312.372	THRUST WASHER AS-1730
312.391	COMPRESSION SPRING
312.428	CAP SCREW
312.452	RING NUT
312.453	SNAP RING
312.714	PLATE SPRING

PART #	DESCRIPTION
312.721	COMPRESSION SPRING
312.752	COMPRESSION SPRING
312.805	SLEEVE
312.826	SHAFT PACKING
312.951	RUBBER CUT
312.952	CIRCLIP A24
313.027	GASKET
313.062	WASHER
313.203	V-BELT POLYFLEX
313.243	GROOVED BALL BEAERING
313.268	WASHER CP1830
313.433	RING
314.061	COMPRESSION SPRING
314.134	BEARING
314.136	REGULAR CONTACT BEARING
314.853	CIRCLIP A35
315.466	SCREW
315.536	PIN
316.062	WASHER
316.423	SPRING
316.517	PROFILE RUBBER
316.532	HANDLE
316.746	V-BELT
317.122	BRUSH
331-119	MANCHESTER SUPPORT BLADE
350.078	CIRCLIP
401-3	MOTOR,1/3HP
401-9	MOTOR,1/2HP
401-90	MOTOR REPLACED BY 401-215
401-102	MOTOR,
401-145	MOTOR,1/2HP (ASM)
401-153	MOTOR,CHUCK & FD
401-188-1	MOTOR,50HZ W/BRAKE
401-215	MOTOR, 1/2 H.P. 3 PHASE
401-220	BRAKE MOTOR 230V
401-221	BRAKE MOTOR 460V
401-2281	MOTOR,1/2HP

PART #	DESCRIPTION
401-2290	MOTOR,1/3HP
402-124-1	MOTOR,7 1/2HP
402-135	MOTOR, 7-1/2, 00ULTRA
403-7	TRANSFORMER (ASM)
403-47	TRANSFORMER
403-80	BRIDGE RECTIFIER
403-138	TRANSFORMER-ISOLATIN
403-2315	RECTIFIER
404-48	HEATER,RELAY
404-61	RELAY HEATER
404-64	RELAY HEATER
404-66	RELAY HEATER
404-69	RELAY HEATER
404-78	RELAY HEATER
404-79	RELAY HEATER
404-149	FUSETRON
404-177	FUSETRON,2.5A 250V BUSS TYPE
404-194	FUSE
404-198	FUSETRON
404-202	FUSE
404-248	RELAY OVERLOAD SZ 1
404-332	FUSE,6A 250V
404-341	OVERLOAD RELAY
404-2752	FUSE
404-9084	CIRCUIT BREAKER
404S5X	KEY SWITCH,PTC SEQUENCER
405-157	DIODE
405-158	CAPACITOR
405-159	RESISTOR
405-354	SUPPRESSOR
405-358	RESISTOR,OHMITE
405-367	RESISTOR (ASM)
405-492	BATTERY,ASSY
405-654	TRIPLE 3 INPUT NOR GATE
405-662	PROGRAM INTER MODULE
405-678	HALL SWITCH I
405-679	MAGNETIC ACTUATOR

PART #	DESCRIPTION
405-773	DIODE,400V 1A #IN4004
405-858	DOUBLE OPTICAL SWITCH
405-860	MAGNETIC ACTUATOR (PTC)
405-861	RELAY
405-944	THUMB WHEEL XXX BCD
405-990	ROTARY INCREMENT ENCODER
405-992-1	AMPLIFIER SERVO DRVE
405-1008-1	M092-FC-401 STEP MTR CONT
405-1055	CAPACITOR ELECTROLYT
405-1104	RELAY OPTO 22 OAC24
405-1109	POWER SUPPLY,24V
405-1124	OPTO 22 BOARD
405-1166	RELAY OPTO 22 ODC 24
405-1175	RECERTIFIED BUBBLE MEM.
405-1196	MODULE-DC OUTPUT ODC24
405-1601	DRIVE,20 AMP
405-9007	DIODE, 90V DC
405-58348	RESISTOR
409-168	MANCHESTER, CLAMP
409-169	MANCHESTER, CLAMP
411-41	COUNTER [EAGLE]
411-57	MAGNETIC CLUTCH
411-134	VALVE,SOLENOID
411-169	RELAY
411-170	RELAY (ASM)
411-189	RELAY
411-213-1	CLUTCH,ELECTROMAGNETIC
411-219	CLUTCH,ELECTROMAGNETIC
411-219-ZZ	CLUTCH, SECOND QUALITY
411-233	RELAY
411-234	RELAY
411-244	RELAY
411-288	SOLENOID,ROTARY
411-297	RELAY
411-298-1	CLUTCH ELECTRIC
411-298-1-ZZ	CLUTCH
411-299	RELAY

PART #	DESCRIPTION
411-304	SOLENOID
411-382	VALVE,SOLENOID
411-385-ZZ	CONTROLLER
411-388	STARTER,SIZE 0
411-422-1	VALVE,SOL. CNTR. PILOT OP
411-424	VALVE,SOLENOID
411-466	SOLENOID
411-468	SOLENOID PULL TYPE 8 LBS
411-475	ELECT CLUTCH
411-491	SOLENOID, PULL TYPE
411-494	SOLENOID,120V 50 HZ
411-495	STARTER, 50 HR COIL
411-498	VALVE SOL
411-508	STARTER (ASM)
411-510	VALVE-SOLENOID
411-539	RELAY
411-541	RELAY SOCKET
411-542	COUNTER, ELECTRONIC
411-542-1	COUNTER, ELECTRONIC
411-542-ZZ	COUNTER, OLD STYLE
411-9021-1	MAGNETIC BRAKE
411-9037	RELAY
411-9064	CONNECTOR
411-9078	CONTACTOR
412-48	SWITCH
412-85	ROTO PUSH OPERATOR
412-86	BLOCK
412-89	SWITCH
412-91	PUSHBUTTON
412-92	PUSHBUTTON
412-93	SWITCH, PUSHBUTTON
412-104	MICRO SWITCH
412-114	PUSHBUTTON
412-124	SWITCH
412-137	SWITCH
412-146	SWITCH
412-203	PUSHBUTTON

PART #	DESCRIPTION
412-209	SWITCH
412-210	ACTUATOR
412-225	SWITCH
412-226	AUXILIARY CONTACT
412-320	SWITCH
412-336	AUXILIARY CONTACT UNIT
412-366	AUX CONTACT UNIT KIT
412-377	SWITCH
412-381	PUSHBUTTON GR FULL GUARD
412-396	BLOCK,CONTACT
412-397	LIMIT SWITCH
412-415	L.S. SOLENOID STL MAGNET
412-428	SELSEN SWITCH RED
412-431	MINI ENCLOSED SWITCH CE
412-437	DOOR INTERLOCK MICRO SW
412-445	SWITCH,PROXIMITY
412-446	SWITCH,PRESSURE
412-449	LIMIT SWITCH AU-6-04-2
412-516	SWITCH SELECTOR 2POS.KEY
412-527	PBUTTON RED NC LONG
412-544	SWITCH,MUL LIM 3PLGR
412-545-1	MULT LIM SW 4 PLUNGER
412-550	SWITCH,PROXIMITY
412-559-1	DRUM SWITCH
412-604	AUX CONTACT
412-610	LIMIT SWITCH
412-618	CONTACT BLOCK
412-2726	PUSHBUTTON RED MUSHROOM
412-2729	SWITCH (ASM)
412-2741	SWITCH
412-2781	INTERLOCK
412-2797	PUSHBUTTON
412-2798	SWITCH
412-2799	SWITCH COVER
412-9029	SWITCH
412-9032	SWITCH
412-57649	SWITCH

PART #	DESCRIPTION
413-61	CONNECTOR
413-62	CONNECTOR
413-75	CONDUIT
413-91	CONNECTOR OILTIGHT
413-310	GRIP,PORTABLE CORD 1/8
413-412	CONDUIT WASHER
413-444	GRIP,CABLE
413-497	CONDUIT,1" STR-STR
413-2046	CLAMP, DIAMOND
413-2107	CONNECTOR,1/2 OILTIGHT CONDUIT
413-2117	LOCKNUT,1/2" CONDUIT
413-2119	LOCKNUT 1" GALV
413-2123	BUSHING
413-2126	BUSHING
413-2128	GASKET,3/4 CONDUIT #772
413-2149	CONDUIT
413-2155	GASKET
413-2165	COUPLING,1/2 CONDUIT GALV
413-2178	CONNECTOR
413-2195	COMPONENT PART
413-9009	WASHER
413-9016	CONDUIT WASHER
413-9078	SCREW MACHINE RELATED ITEM
414-24	THERMO. PROTECTOR (ASM)
414-25	BLOCK END
414-26	BLOCK SECTION
414-60	LUG, TERMINAL
414-88	PILOT LIGHT
414-113	NEON BULB,NE-51H
414-127	SOCKET,8 PIN
414-181	LAMP 6-WATT
414-205	PILOT LIGHT-WHITE
414-213-LENS-C	GLOBE, CLEAR PLASTIC
414-213-LENS-R	LENS, RED
414-220	FUSE HOLDER
414-260	BLOCK,FUSE (2 POLE 30A 250V)
414-299	TERM BLOCK

PART #	DESCRIPTION
414-341	KQI LAMP
414-393	CABLE
414-421	CABLE BELDEN #9873 3PR SH
414-423	PLUG,25 CONTACT (AMP)
414-425	PIN,CRIMP (24-20AWG AMP PLUGS)
414-453	TERMINALS NYLON INSULATED
414-484	LIGHT,INDICATING DIALCO
414-508	LAMP 14 VOLT .08A
414-632	LIGHT,WORK
414-640	CONNECTOR
414-650	RECEPTACLE,5 CONTACT
414-651	DUST CAP & CHAIN
414-723	COVER KIT,37 PIN
414-731	WIRE JOINT 2# 12
414-739	PLUG, 3 POLE FEMALE
414-776	TERMINAL BLOCK MARKER (9)
414-879	HOUSING 12POS (SOCKET)
414-898	CABLE CLAMP WATERPROOF
414-939	SOCKET,AMP PLUG ON REEL
414-2024	CLIP
414-2309	PLUG TERMINAL LUG
414-2311	TERMINAL BLOCK
414-2320	SOCKET,ELECTRIC (FEMALE)
414-2321	PLUG, ELECTRIC (MALE)
414-2324	FUSE CUT-OUT
414-2356	RECEPTACLE,3 WIRE MIDGET
414-2357	PLUG,MIDGET
414-2382	RECEPTACLE
414-2383	PLUG
414-2762	NO FUSE STRAPS
414-9018	SCREW MACHINE RELATED ITEM
414-9026	SCREW MACHINE RELATED ITEM
414-9033	WIRE 4SQ MM BLACK
414-9046	BULB
414-9051	TERMINAL END
414-28463	GLASS, FROSTED
414-28464	BULB, BAYONET-TYPE

PART #	DESCRIPTION
414-28887	TERMINAL END
414-59220	PLUG
415-60	CONNECTOR, ELECT. CORD
415-68	PANEL CHANNEL
415-230	COVER
415-231	GASKET
415-238	NAME PLATE
415-239	NAMEPLATE CUTLER-HAMMER
415-240	NAMEPLATE MINIATURE
415-540	CABLE CLAMP PLASTIC
415-596-F	FILTER FOR HEAT EXCHANGER
415-598	NAMEPLATE,WORKLIGHT
415-2010	TUBING,PLASTIC
415-2358	RUBBER COVER, MIDGET PLUG
415-2384	MIDGET PLUG
415-2405	GROMMET
415-2702	DISCONNECT SWITCH HANDLE
415-9031	BLANK LEGEND
415-9035	MARKER,CABLE
415-9037	MARKER,CABLE
415-9038	MARKER,CABLE
415-9040	MARKER,CABLE
415-9044	CABLE MARKER NO. A
415-9045	CABLE MARKER NO. B
415-9046	CABLE MARKER NO. C
415-9050	CABLE MARKER NO. L
419-112	PWMC CONTROL ASSBY BD
419-112-55	G.E.BOARD/PWMC3/PWMC4,REBUILT
419-116	PWM REGEN LOAD PANEL
419-117	FAN
419-120	RESOLVER
419-126	SPINDLE MOTOR BLOWER ASSY
419-133	BOARD,+24VDC INPUT
419-174	LAMP,B1-PIN 12-14V
419-183	FILTER,DISPOSABLE PPR
419-184-55	G.E.BOARD/PWMP/REBUILT
419-225	SWITCH,V3 GOLD

PART #	DESCRIPTION
419-241	RESOLVER,"A/D,B/C" AXES,COMPL.
419-242	RESOLVER,"W" AXIS, COMPLETE
419-260	BRUSH,SERVO MOTOR
421-11	BRG,POROUS BRONZE
421-28	BRG,BRONZE
421-40	BUSHING, OILITE
421-57	BUSHING,TEFLON-LINED
421-58	BUSHING,TEFLON-LINED
421-60	TEFLON BUSHING
421-75	BUSHING,SELF OIL BRONZE
421-76	BUSHING,SELF OIL BRONZE
421-77-1	BUSHING,SELF OIL BRONZE
421-80	BRG,NYLON SNAP IN
421-82	BUSHING
421-91	BRG,POROUS BRONZE
421-137	BRG,BRONZE
421-140	BRG,BRONZE
421-802	BRG,POROUS BRONZE
421-808	BRG,POROUS BRONZE
421-816	BRG,POROUS BRONZE
421-819	BRG,POROUS BRONZE
421-828	BRG,POROUS BRONZE
421-828-A	BEARING, BRONZE BUSHING
421-842	BRG,POROUS BRONZE
421-858	BRG,POROUS BRONZE
421-9003	FUCLRUM BUSHING
421-9010	BUSHING
421-9016	BUSHING
421-9021	BUSH
421-53257	BRUSH
421-53404	BRG,PLAIN
421-53622	GLACIER BUSH
421-53623	THRUST WASHER
422-5	BEARING,NEEDLE
422-9	BEARING,NEEDLE
422-10	BEARING,NEEDLE
422-16	BEARING,NEEDLE

PART #	DESCRIPTION
422-26	NEEDLE BEARING
422-28	BEARING, NEEDLE
422-29	BEARING, NEEDLE
422-31	BEARING, NEEDLE
422-32	BEARING, NEEDLE
422-34	BEARING, NEEDLE
422-49-1	BEARING, PRECISION NEEDLE
422-50	BEARING, NEEDLE
422-51	BEARING, NEEDLE
422-52	BEARING, NEEDLE
422-54	BEARING, NEEDLE ROLLER
422-55	NEEDLE BEARING, EXTRA PREC
422-56	BEARING, NEEDLE ROLLER
422-57	BEARING, NEEDLE
422-58	BEARING, NEEDLE
422-59	BEARING RACE
422-60	BEARING, ROLLER
422-61	BEARING, NEEDLE
422-62	BEARING, NEEDLE ROLLER (ASM)
422-63	NEEDLE BEARING
422-77	BEARING, NEEDLE
422-78	BEARING, NEEDLE
422-79	BEARING, NEEDLE
422-80	BEARING, NEEDLE
422-81	BEARING, NEEDLE
422-82	NEEDLE BEARING
422-84-1	BEARING, NEEDLE
422-85	BEARING, NEEDLE
422-91	BEARING, NEEDLE, 17MM ID
422-104-1	NEEDLE BEARING
422-1507	BEARING, NEEDLE
422-1508	BEARING, NEEDLE
422-1511	BEARING, NEEDLE
422-1512	BEARING, NEEDLE
422-1517	BEARING, NEEDLE
422-1518	BEARING, NEEDLE
422-3000	NEEDLE BEARING

PART #	DESCRIPTION
422-3001	NEEDLE BEARING
422-3002	NEEDLE BEARING (ASM)
422-3004	BEARING, NEEDLE
422-9005	BEARING
422-9006	NEEDLE BEARING
422-9422	BEARING
423-3	TURRET REAR ROLLER BEARING
423-4	RING, BEARING
423-5	RING, BEARING
423-16	TURRET FRONT ROLLER BEARING
423-26-1	ROLLER FOLLOWER
423-28	ROLLER FOLLOWER
423-34-1	THRUST RADIAL BRG.
423-1605	BEARING, ROLLER
423-1608	ROLLER ASSEMBLY
423-1610	ROLLER ASSEMBLY
423-1615	ROLLER ASSEMBLY
423-1623	ROLLER ASSEMBLY
423-1632	ROLLER ASSEMBLY
423-1661	NEEDLE BEARING, HEAVY DUTY
423-1662	BEARING, OUTER RING & ROLLER
423-1663	BEARING, OUTER RING & ROLLER
423-9001	BEARING
424-5	BEARING, TAPERED ROLLER
425-8	BEARING, ROLLER
425-9	BEARING, ROLLER
425-10	BEARING, ROLLER
425-11	BEARING, ROLLER
425-18	BEARING, ROLLER
425-19	BEARING, ROLLER
425-23	BEARING, TAPERED ROLLER
425-9086	ROLLER
429-10	RING, RETAINING
429-13	5/8 CAM FOLLOWER
429-14	RING, RETAIN (EXT .250OD SHAFT)
429-16	RING, RETAIN (EXT
429-17	RING, RETAINING

PART #	DESCRIPTION
429-20	RING,RETAIN (EXT
429-21	RING,RETAIN (INTERNAL)
429-22	RING,BEVELED EXTERNAL RETAIN
429-23	RING,RETAIN (3.543 INTERNAL)
429-24	RING,RETAIN EXT BEVELED
429-25	RING,RETAIN EXT BEVELED
429-26	RING,RETAIN (3.149 INTERNAL)
429-29	RING,RETAIN EXTERNAL
429-30	RING,RETAIN
429-31	RING,RETAIN
429-32-1	RING,RETAIN
429-33	RING,RETAIN (EXT
429-34	RING,RETAIN (INTERNAL)
429-43	RING,RETAINING
429-55	RING,RETAIN (INTERNAL)
429-60	RING,RETAIN (EXT
429-69	RING,RETAINING
429-82	RING,RETAIN 5/16 EXTERN
429-87	WASHER
429-92	RING
429-96	BALL,ST STL
429-97	RING,RETAIN INTER
429-99	WASHER (ASM)
429-134	WASHER
429-137	RING
429-145	RING,RETAIN (EXT
429-146	RING
429-153	RING
429-161	RING,RETAINING
429-162	RING,RETAINING
429-171	RING
429-183	RING
429-188	RING,RETAINING
429-189	RING,RETAINING
429-190	RING,RETAIN EXTERN.
429-218	RING, RETAINING
429-225	RING,RETAIN (EXT

PART #	DESCRIPTION
429-241	RING,RETAIN (EXT
429-247	KLIPRING,EXTERNAL
429-258	RING,RETAIN
429-263	RING,RETAIN (INTERNAL)
429-264	RING,RETAIN (INTERNAL)
429-267	RING,RETAIN PUSHO INT
429-268	KLIPRING
429-270	RING,RETAIN (EXT 10OD SHAFT)
429-285	RETAINER RING
429-288	RING,RETAIN (EXT 3 5/32DIA)
429-290	RING,RETAIN (EXT 20MM)
429-302	EXT. RTNG RING HD.669
429-309	BALL RETAINER
429-313	SET OF 5/16 DIA BALLS
429-321	RING, RETAIN (ASM)
429-1141	FRICITION SEAL WASHER
429-1145	WASHER
429-1146	WASHER (ASM)
429-1217	RETAINER
429-1283	CAM FOLLOWER
429-1284	CAM FOLLOWER
429-1290	BALL, STEEL 5/8 DIAM.
429-1293	BALL
429-1295	BALL,STEEL
429-1297	BALL, STEEL 5/16
429-1298	BALL, STEEL 3/8 DIAM.
429-1299	BALL,STEEL 1/2DIA #3 GRADE
429-1475	RETAINER
429-1476	RING,RETAIN (EXT
429-1479	RING
429-1485	RING,RETAIN (EXT .984OD SHAFT)
429-1486	RING,RETAIN (EXT
429-1491	RING,RETAINING
429-1493	RING
429-1494	RING
429-1495	RING
429-1496	RING

PART #	DESCRIPTION
429-4485	RING
429-4487	RING
429-4488	RING,RETAINING
429-4489	RING
429-4495	RING
429-4496	RING
429-9004	EXTERNAL CIRCLIP
429-9016	CIRCLIP
429-9025	STEEL BALL, 7/16 DIA.
429-9419	CIRCLIP
429-9420	CIRCLIP
429-54229	STEEL BALL 3/16" DIA.
429-200378	CHROME STEEL BALL 7/16 +.003
429-200379	CHROME STEEL BALL 7/16 +.004
429-200381	CHROSE STEEL BALL 7/16 +.0006
431-5	BEARING
431-6-1	BEARING,BALL
431-7	BEARING
431-8	BEARING
431-9	BEARING
431-10	BEARING
431-11	BEARING
431-12	BEARING
431-13	BEARING (MATCHED PAIR)
431-13-1	BALL BEARING (FAFNIR ONLY)
431-14	BEARING, PAIR
431-15	BEARING
431-17-1	BEARING, SPINDLE (GRIND.)
431-58	BEARING
431-59	BEARING
431-60	BEARING
431-61	BEARING
431-62	BEARING
431-63	BEARING
431-64	BEARING
431-66	BEARING,PAIR
431-67	BEARING

PART #	DESCRIPTION
431-67-1	BEARING (FAFNIR ONLY)
431-68	BEARING
431-76-1	BRG,BALL (ANGULAR CONTACT)
431-91	BEARING
431-93	BEARING
431-93-ZZ	SCREW MACHINE RELATED ITEM
431-94	BEARING
431-96	BALL BEARING,ANGULAR CONT
431-100	BALL BEARING,PAIR
431-101	BALL BEARING
431-104	BALL BEARING
431-109	BEARING,MINI 16
431-111	BEARING BALL
431-1052	BEARING,PAIR
431-1053	BEARING
431-1054	BALL BEARING
431-1055	BALL BEARING
431-1085	BALL BEARING
431-1087	BALL BEARING
431-1093	BALL BEARING
431-1094	BALL BEARING
431-4051	BEARING
431-4055	BALL BEARING
431-4056-1	BALL BEARING
431-4057	BALL BEARING
431-4058	BALL BEARING
431-9002	BALL BEARING
431-51324	BEARING
431-54089	MINI 16 BALL JOURNAL
432-9	BALL BEARING
432-10	CHUCK FORK SLEEVE, OUTER
432-11	CHUCK FORK SLEEVE, OUTER
432-12	BALL BEARING
432-13	BALL BEARING
432-14	BALL BEARING
432-24	BALL BEARING
432-26	BALL BEARING

PART #	DESCRIPTION
432-28	BALL BEARING
432-1009	BALL BEARING
432-1012	BALL BEARING
432-1014	BEARING, BALL
432-1021	BEARING
432-1024	BEARING
432-1036	BEARING
432-1046	BEARING
432-1300-1	CHUCK FORK SLEEVE, OUTER
432-1302-1	CHUCK FORK SLEEVE, OUTER
432-1302-1-ZZ	CHUCK FORK SLEEVE OUTER
432-1304-1	CHUCK FORK SLEEVE, OUTER
432-9000	BEARING
432-9007	BEARING
432-9421	BEARING
433-3	BALL BEARING,SPIN. POST
433-5	BEARING
433-9	BEARING
433-1101	BEARING
433-1104	BEARING
433-1105	BEARING
433-1106	BEARING
433-1107	BEARING
433-1113	BALL BEARING
433-1129	BALL BEARING
434-2	BALL BEARING
434-3	BALL BEARING
434-6	BRG, BALL (D/SEAL)
434-9	BALL BEARING
434-14	BRG,BALL (S/ROW SEALED CLASS 1
434-27	BALL BEARING
434-1150	BALL BEARING,FEED TUBE,2B
434-1151	BALL BEARING
434-1152	BALL BEARING
434-1160	BALL BEARING
434-1165	BALL BEARING
434-1168	BALL BEARING

PART #	DESCRIPTION
434-1170	BALL BEARING
434-1172	BALL BEARING
434-1173	BALL BEARING
434-1175	BALL BEARING
434-1177	BALL BEARING
435-13	BALL BEARING,DBL SHIELD
435-17	BEARING,BALL
435-18	BALL BEARING
435-101	MANCHESTER, CLAMP
435-102	MANCHESTER, CLAMP
435-1353	BALL BEARING
435-1360	BALL BEARING
435-1363	BALL BRG
435-1370	BALL BEARING
435-1463	BEARING,ROLLER
435-1466	BALL BEARING
435-1469	BALL BEARING
435-1803	BALL BEARING
436-6	BALL BEARING
436-17	BALL BEARING,ANGULAR CONT
436-1005	BALL BEARING (PR.)
436-1303	BALL BEARING
436-1312	BALL BEARING
436-1400	BALL BEARING
436-1407	BEARING
437-5	BALL BEARING
437-6	BALL BEARING (ASM)
437-7	BALL BEARING
437-8	BALL BEARING
437-13	BALL BEARING
437-14	BALL BEARING ABEC-1
437-17	BALL BEARING
437-20	BALL BEARING
437-22	BALL BEARING
437-26	BALL BEARING
437-27	BALL BEARING
437-31	BALL BEARING

PART #	DESCRIPTION
437-32	BALL BEARING
437-37	BALL BEARING
437-38	BEARING,BALL
437-39	BALL BEARING
437-42	BEARING,DOUBLE ROW
437-43	BALL BEARING,SNAP RING
437-44	BALL BEARING (PTC)
437-46	BALL BEARING (PTC)
437-1451	BALL BEARING
437-1452	BALL BEARING
437-1453	BALL BEARING
437-1473	BALL BEARING
437-4450	BALL BEARING
437-9000	SCREW MACHINE RELATED ITEM
438-4	BEARING,NEEDLE
438-7	BEARING,THRUST
438-10	BEARING,THRUST
438-16	BEARING,THRUST
438-20	THRUST BEARING
438-21	THRUST BEARING (ASM)
438-22	BEARING,THRUST
438-23	BEARING, THRUST (ASM)
438-29	THRUST RACE
438-32	BEARING RACE
438-33	BEARING RACE
438-34	BEARING RACE
438-38	BEARING, THRUST (ASM)
438-39	BEARING,THRUST
438-51	BEARING RACE
438-74	BEARING,THRUST
438-82	BEARING,NEEDLE THRUST
438-83	THRUST BEARING RACE
438-84	BALL THRUST BEARING
438-85	BALL THRUST BEARING
438-86	BEARING,NEEDLE THRUST
438-87	THRUST BEARING WASHER
438-88	THRUST WASHER

PART #	DESCRIPTION
438-89	BEARING, NEEDLE THRUST
438-90	THRUST WASHER
438-92	THRUST WASHER
438-93	THRUST WASHER
438-94	THRUST WASHER
438-95	BEARING, NEEDLE THRUST
438-97	THRUST WASHER
438-1206	BEARING
438-1212	BEARING, THRUST
438-1215	BEARING, THRUST
438-9002	BALL BEARING
438-53502	MINI 16 THRUST BEARING
441-10-1	BELT, 55 TEETH
441-12-1	4L270 V-LASTIC BELT
441-21	BELT
441-44	BELT
441-209	BELT
441-211	V BELT
441-53597	MINI 16 BELT
441-53764	BELT
441-53765	BELT
441-53810	MOTOR DRIVE BELT
441-54016	MINI 16 BELT
441-54177	MINI 16 BELT
441-54366	MINI 16 BELT
442-76	BELT, TABLE DRIVE
442-92	TIMING BELT
442-95	TIMING BELT
442-117	TIMING BELT, 63 TEETH
442-129	BELT, TIMING 92T
442-130	BELT, TIMING (HTD)
442-275	BELT, ENDLESS
442-277	BELT, ENDLESS
442-294	LEATHER BELT 1-1/4" WIDE
442-298	BELTING, 1 1/2" WIDE
451-6-99	CHAIN
451-9	LINK

PART #	DESCRIPTION
451-10-99	LINK
451-11-99	LINK
451-12	CONNECTING LINK
451-13	LINK
451-15	LINK, CONNECTING
451-16-99	LINK, 35-2 OFF-SET DOUBLE
451-17	LINK, OFF-SET
451-18	LINK
451-20	CLIP, SPRING
451-21-99	CHAIN
451-22	CHAIN
451-23	CHAIN
451-25	CHAIN
451-26	CHAIN
451-27-99	CHAIN
451-29-99	CHAIN
451-36	CHAIN
451-37	CHAIN
451-40	LINK
451-42	CHAIN
451-43	CHAIN
451-44	CHAIN
451-44-ZZ	CHAIN, NOT FIRST QUALITY
451-45	CHAIN
451-46	CHAIN
451-47	CHAIN
451-48	LINK
451-50	CHAIN
451-51	CHAIN
451-52	CHAIN
451-53	CHAIN
451-54	CHAIN,#35 ROLLERLESS
451-57	CHAIN
451-58	CONNECTING LINK
451-59	CHAIN
451-65	CHAIN
451-300	CHAIN

PART #	DESCRIPTION
451-301	CHAIN
451-302	CHAIN
451-304-99	CHAIN
451-306-99	CHAIN
451-307-99	CHAIN (A.S.M.)
451-308-99	CHAIN
451-311	LINK
451-312	CHAIN
451-313	CHAIN
451-314	CHAIN
451-315	CHAIN
451-320-99	CHAIN
451-321-99	CHAIN
451-322	CHAIN
451-328	CHAIN
451-337	CHAIN, LOW SPEED
451-338	CHAIN, HIGH SPEED
451-339-99	CHAIN
451-342-99	CHAIN
451-343-99	CHAIN
451-344-99	CHAIN
451-345	CLIP
451-347	CLIP
451-375-99	CHAIN
451-377	LINK
451-3300-99	CHAIN
451-3301-99	CHAIN
451-3302-99	CHAIN
451-3303	CHAIN
451-9001	CHAIN
451-9002	CHAIN
451-9003	CHAIN
451-9007	CHAIN
451-9012	CHAIN, SPINDLE MOTOR
451-9027	CHAIN
451-9029	SPINDLE CHAIN LEFT
451-9037	CHAIN

PART #	DESCRIPTION
451-9040	SPROCKET, 17T
451-9051	SPROCKET
451-9184	LINK W/ CLIPS
451-50246	CHAIN, (1/2"CAP)
451-51607	CHAIN,COOLANT PUMP
451-57250	CONN. LINK
452-6-1	CHAIN,SILENT 3/16P-1W
452-15	CHAIN
452-20	LINK
452-29-99	SEAT,PIN
452-36-99	CHAIN
452-37-99	CHAIN
452-39	CHAIN
452-40	CHAIN
452-41	HUNTING LINK
452-43	JOINT PIN, SILENT CHAIN
452-350	CHAIN
452-351-C	LINK FOR 452-351
452-352	CHAIN
461-21	METER UNIT
461-22	LUBRO CONTROL UNIT
461-30-1	JUNCTION,5 WAY
461-38	JUNCTION 8 WAY SINGLE
461-44	METER UNIT
461-65	METER UNIT (SPECIAL)
461-69	ACCUMITE INSERT VALVE
461-71	VALVE,LUBG
461-77	SLEEVE,COMPRESSION(1/8OD TUBE)
461-78	NUT,COMPRES(5/16-24X1/8OD TUBE
461-84	ELBOW ADAPTER
461-86	CARTRIDGE,OIL FILTER
461-90	FILTER,OIL
461-102	REGULATOR,AIR PRESSURE
461-103	NUT,COMPRES(3/8-24X3/16OD TUBE
461-104	SLEEVE,COMPRESSION(3/16OD TUBE
461-105	METER UNIT, R/B 461-125
461-106	METER UNIT R/B 461-126

PART #	DESCRIPTION
461-123	FILTER ELEMENT (ASM)
461-125	METER UNIT (SPECIAL)
461-126	METER UNIT (SPECIAL)
461-155	FILTER UNIT,SUCTION
461-178	FILTER ELEMENT (ASM)
461-184	UNIT,METER
461-186	CHECK VALVE
461-187	FILTER BAG
461-190	ACCUMITE INSERT VALVE
461-208	METER UNIT
461-209	VALVE
461-210	TERMINAL, VALVE
461-227	FILTER ELEMENT
461-228	UNIT,FILTER
461-263	LUBRICATOR AUTO CYCLE
461-263-1	LUBRICATOR PUMP
461-274	ADAPTER, 1/4 STRAIGHT
461-297	CYLINDER CAP
461-918	NUT,COMPRES(5/16-24X3/32ODTUBE
461-919	SLEEVE,COMPRESSION(3/32OD TUBE
461-922	TUBING CLIP
461-926	METER UNIT
461-927	NUT,COMPRES(1/4-28X3/32OD TUBE
461-928	BUSHING,STRAIGHT DRIVE
461-950	NUT,COMPRES(5/16-24X5/32ODTUBE
461-951	SLEEVE,COMPRESSION(5/32OD TUBE
461-953	BUSHING
461-954	TUBING CLIP
461-961	ELBOW ADAPTER
461-971	BUSHING,STRAIGHT DRIVE
461-974	PLUG
461-977-2	OIL LEVEL GAGE (FLOAT TYPE)
461-977-2-ZZ	OIL LEVEL GAGE
461-981	SPECIAL HOSE ASSEMBLY
461-988	METER UNIT
461-989	METER UNIT
461-990	METER UNIT

PART #	DESCRIPTION
461-3158	FULFLO FILTER TUBE
461-3935	ADAPTER
461-3942	NUT,COMPRES(5/16-24X1/8OD TUBE
461-3944	SLEEVE,COMPRESSION(1/8OD TUBE)
461-3952	METER UNIT
461-3957	WASHER
461-3964	METER UNIT
461-3974	METER UNIT
461-6900	BUSHING
461-6901-1	JUNCTION,7 WAY
461-6904	CLIP
461-6906	TUBING CLIP
461-6908-1	JUNCTION,4 WAY
461-9021	SCREW MACHINE RELATED ITEM
461-9042	METER UNIT
461-9053	LUBE FITTING
461-9054	METER UNIT
461-56290	METER UNIT
461-56291	METER UNIT
461-56292	METER UNIT
462-25	FITTING,GREASE (1/8NPFT RELIEF
463-22	1/2 BRASS SWING JOINT
463-25	LEVER HANDLE STOP
463-31	ELBOW
463-73	NIPPLE
463-115	STREET ELBOW
463-147	ELBOW,STREET (1/8NPT) BRASS
463-185	VALVE,FLOW CONTROL
463-236	PROTECTOR FOR THREADS
463-241	PROTECTOR FOR THREADS
463-255	PLUG,PLASTIC
463-326	BRASS NIPPLE
463-327	NIPPLE,BRASS
463-356	NON-THREADED PLASTIC CAP
463-359	REDUCING TEE
463-360	FEMALE DROP ELBOW
463-385	VALVE,1/4" SHUTOFF

PART #	DESCRIPTION
463-387	150 LB MI FEMALE UNION
463-394	HOSE ASSEMBLY
463-395	VALVE, SHUTOFF (ASM)
463-437	BEADED HOSE INSERT
463-439	VALVE, 2-WAY SHUT-OFF
463-600	VERTICAL CHECK VALVE
463-601	VERTICAL CHECK VALVE
463-652-1	HOSE, FLEX
463-681	SCREW MACHINE RELATED ITEM
463-694	PLUG, PIPE (3/8)
463-696	PLUG, PIPE 1/4NPT
463-697	PLUG, PIPE
463-698	PLUG, PIPE (1/4 NPT)
463-751	ELBOW
463-753	ELBOW
463-764	TEE, 1/4 MI STRAIGHT BLACK
463-765	UNION, 1/4 BRASS FEMALE
463-787	BUSHING, 1/2 X 1/4 MI HEX
463-791	BUSHING
463-804	SCREW MACHINE RELATED ITEM
463-818	CARTRIDGE CHECK VALVE
463-821	VALVE, PRESSURE REDUCING
463-826	CARTRIDGE CHECK VALVE
463-854	PILOT OPER DIRECTION VALV
463-855	SUBPLATE, SIDE ENTRY (QXA)
463-857	DIAPHRAGM
463-862	CONNECTOR, PIPE
463-869	SNUBBER, GUAGE
463-874	HOSE ASSEM 1/2 ID X 53
463-877	PILOT CHECK VALVE
463-885	FITTING, SWIVEL
463-982-1	RELIEF VALVE 1/2"
463-982-1-S	SPRING
463-987	VALVE-QUICK EXHAUST
463-3723	REDUCER, 3/4 X 1/2 MI
463-3752	BUSHING, 1/2 X 3/8 FACE
463-3788	BUSHING, 1/4 X 1/8 HEX

PART #	DESCRIPTION
463-3793	UNION, 1/2 MI FEMALE BLACK
463-9030	SCREW MACHINE RELATED ITEM
463-9433	VALVE
464-39	ELBOW, MALE 1/4" O.D. X 1/8NPT
464-40	POLY TUBING 1/4" O.D.
464-49	NEEDLE VALVE BRASS
464-51	DOUBLE TUBE CLIP 1/4
464-54	CONNECTOR
464-69-1	AIR CYLINDER
464-70	AIR CYLINDER
464-71	AIR CYLINDER
464-73	TUBE ELBOW
464-122	TUBING, ALUM. 3/32 OD
464-123	TUBING, ALUM (1/8OD X .032WALL
464-124	TUBING, ALUM 5/32OD
464-125	TUBIND, ALUM 3/16 OD
464-131	TUBING, ALUM 3/4OD 12FT PIECE
464-132	TUBING, ALUM 1"OD 10FT PIECE
464-146	TUBING, NYLON (3/16OD)
464-169	CONNECTOR
464-234	TUBING, PLASTIC (1"OD X 1/8WALL
464-258	CONN, MALE POLY FLO
464-312	FEMALE FLARE SWIVEL
464-313	CONNECTOR, MALE
464-351	ELBOW
464-359	TUBING, TYGON (7/16OD X 1/16WAL
464-374	CONNECTOR
464-422	CYLINDER AIR
464-423	CYLINDER, AIR (ASM)
464-424	CYLINDER, AIR PPVT MTG
464-425	BRACKET, CYL PIVOT
464-628	STEEL SLEEVE 1/4 OD TUBE
464-629	STEEL NUT 1/4 OD TUBE
464-650	CONNECTOR
464-674	SLEEVE
464-678	COUPLING NUT
464-683	STEEL SLEEVE, 1 OD TUBE

PART #	DESCRIPTION
464-684	1" OD TUBE STEEL NUT
464-3689	CONNECTOR
464-3697	STEEL ELBOW
464-50702	SLEEVE, 3/16 IN TUBE
465-4	45 DEGREE ELBOW
465-6	CONNECTOR, COMPRESSION
465-7	COMPRESSION ELBOW
465-9	CONNECTOR, MALE 1/4NPT-3/8T BRS
465-11	TEE, MALE RUN
465-12	TEE, MALE BRANCH
465-13	TEE, COMPRESSION UNION
465-20	CONNECTOR, BRASS COMP. MALE
465-24	UNION-BRASS COMPRESS
465-700	COMPRESSION CONNECTOR
465-707	COMPRESSION SLEEVE
465-708	ELBOW
465-713	CONNECTOR (ASM)
465-716	COMPRESSION CONNECTOR
465-722	COMPRESSION CONNECTOR
465-725	COMPRESSION NUT
465-726	COMPRESSION SLEEVE
465-729	ELBOW, COMPRESSION
465-733	ELBOW, BRASS COMPRESSION
465-741	ELBOW, MALE 1/4NPT-3/8T
465-744	VALVE, SHUTOFF
465-50747	1/4-5/16T MALE STUD ELBOW
465-53527	PIPE
465-53545	SMALL CONT.
465-54090	ADAPTOR, MALE
466-17	FELT WASHER
466-18	WICKING
466-22	FELT
466-25	O-RING
466-63	CUP PACKING (ASM)
466-64-1	O-RING
466-66	O-RING
466-67-1	O-RING

PART #	DESCRIPTION
466-73	UNEEPAC RING
466-80	O-RING
466-87	O-RING
466-90	O-RING
466-109	O-RING
466-119	O-RING
466-124	O-RING
466-141	O-RING
466-145	O-RING (ASM)
466-162	O-RING
466-163	VICTOPRENE OIL SEAL
466-170	WICKING, COTTON (ASM)
466-171	COTTON WICKING
466-172	FELT, 3/16 DIAM.
466-175	FELT WICKING
466-190	O-RING
466-191	WASHER, SOFT STEEL
466-195	O-RING
466-219	O-RING
466-238	O-RING, 13/16 X 1 X 3/32
466-244	O-RING
466-251	O-RING PRP-568-126
466-254	SHAFT ROD WIPER
466-261	O-RING
466-271	O-RING
466-281	O-RING
466-293-1	NEOPRENE DISC.
466-307	WASHER, NEOPRENE
466-310	O-RING (ASM)
466-350	O-RING
466-352	O-RING
466-377	"O" RING
466-381	UNEEPAC RING PACKING SET
466-387	UNEEPAC RING SET
466-398	O-RING #2-123
466-402	O-RING
466-411	PACKING, CUP (HOUGHTON)

PART #	DESCRIPTION
466-414	RING,X SEALING 1 1/2 X
466-419	GLYD RING
466-422	O-RING
466-423	GLYD RING
466-425	O-RING 4 X 4 1/8 X 1/16
466-426	GLYD RING
466-427	SEAL,OIL (12MM SHAFT)
466-428	O-RING URETHANE7/8X1X1/16
466-430	O-RING 3 1/2X3 7/8X3/16"
466-431	O-RING 5 X 5 1/2 X 1/16
466-432	O-RING (ASM)
466-434	OIL SEAL
466-435-2	OIL SEAL (ASM)
466-438	O RING,POLYURE 1/4X3/8X1/16
466-462	KIT, PISTON SEAL
466-463	KIT, PISTON SEAL
466-466	ROD SEAL KIT
466-473	SEAL,ROLLER BEARING
466-609	O-RING,9/16 X 3/4 X 3/32
466-610	O-RING (ASM)
466-614	O-RING
466-615	O-RING
466-616	O-RING
466-618	O-RING
466-619	O-RING
466-948	OIL SEAL
466-3601	O-RING
466-3603	O-RING
466-3616	O-RING
466-3621	O-RING,11/16 X 7/8 X 3/32
466-3623	O-RING
466-3945	OIL SEAL TYPE K4 #66051
466-3985	GASKET
466-3990	RING GASKET
466-9003	SEAL
466-9012	SEAL
466-9013	FILTER

PART #	DESCRIPTION
466-53774	O-RING
467-11	TUBING,URETHANE (3/16ODX1/32WA
467-41	FITTING,10-32 1/8 HOSE(BARBED)
467-49	TUBING
471-1	WRENCH,3/16 HEX T HANDLE
471-32	WRENCH, 1-1/2" SPANER
471-46	EXTENSION 5" LONG 3/8
471-54	3/4 SOCKET 3/8 DRIVE
471-407	WRENCH, BOX, 3/8 & 7/16
471-409	WRENCH
471-423	WRENCH,3/16 HEX KEY
471-425	WRENCH,1/4 HEX KEY
471-430	WRENCH
471-431	WRENCH, COMBO OPEN & BOX,13/16
471-436	WRENCH
472-28	SCREW,ADJUSTING
472-40	SCREW,SET (5/16-18X7/8)CUP PT
472-47	TAPER PIN
472-52	NUT,WELD (#10-32)LONG PILOT
472-56	SCREW,DR (#6X1/4) TYPE U
472-57	NUT,WELD (1/4-20)LONG PILOT
472-58	NUT,WELD (5/16-18)LONG PILOT
472-59	NUT,WELD (3/8-16) LONG PILOT
472-62	WASHER
472-72	SCREW,SHC (#10-32 X 1 1/2)
472-92	LOCK WASHER
472-102	SCREW,SEEL
472-111	SCREW,SHC (3/8-16 X 2 1/4)
472-112	LOCKWASHER
472-115	ALLEN NUT
472-116	WASHER
472-118	RIVET
472-126	SCREW,SET (#8-32X1/8)FLAT NYLK
472-134	SCREW,SET (3/8-16X1/2)FLAT PT
472-138	SCREW,SET (1/4X3/4)OVAL/NYLOK
472-145	NUT,ELASTIC STOP (1/4-20)
472-146	SCREW,SHC (3/8-16 X 3)

PART #	DESCRIPTION
472-150	SCREW,SHC (5/16-18 X 2 1/2)
472-151	TAPPING SCREW
472-153	FLEX LOCK NUT
472-156	FLEX LOCK NUT, THICK
472-156-1	ELASTIC STOP NUT, THIN
472-168	SCREW,SHC (#6-40 X 5/8)
472-170	SCREW,SHC (3/8-16 X 5 1/2)
472-171	LOCKWASHER
472-173	SCREW,SET (1/4X5/16)CUPPT NYLK
472-174	LOCKWASHER
472-175	SCREW,SHC (5/16-18 X 5/8)NYLOK
472-178	SCREW
472-180	SCREW,FHSC(3/8-16 X 1 1/4)NYLK
472-181	SCREW
472-187	SCREW,SET (#10-32X1/4)FLAT PT
472-190	SCREW,SET (1/4-20X1/4)FLAT PT
472-192	SCREW,SHC (#8-32 X 3/8)
472-193	SCREW
472-198	HAIRPIN COTTER
472-199	PIN,COTTER
472-201	SCREW,FHSC (#10-32 X 1/2)
472-207	SCREW,BHC (#10-32 X 1/4)
472-217	SET SCREW
472-219-1	SCREW
472-222	SOC HD CAP SCREW
472-229	SET SCREW, CUP PT.
472-231	SCREW,SHC (#10-24 X 1/2)
472-238	SCREW,SET (1/4-20X3/8)FLATNYLK
472-240	SCREW,SHC (1/4-20 X 3/4)NYLOK
472-241	SCREW,SHC (#4-40 X 1/4)
472-246	NUT,HEX (3/4-16)
472-254	SCREW,SET (#10X1/4)CUP PT NYLK
472-273	SCREW,SET (3/8-16X1/4)FLAT PT
472-280	SCREW,BHC (5/16-18X3/4) NYLOK
472-282	SCREW,SET
472-284	SCREW,SHC (1/4-20 X 5/8)NYLOK
472-286	SCREW,SET (1/2-13X2 1/2)CUP PT

PART #	DESCRIPTION
472-303	SCREW,SHC (#6-32 X 7/8)
472-307	SCREW,SHC(#8-32 X 1/4)
472-311	SCREW,SET (5/16-18X1/2)CUPNYLK
472-321	SCREW,BHC (#8-32 X 1/4)
472-334	SCREW,SET (5/16-18X1/2)FLATNYLK
472-335	SCREW,RHM (4-40 X 7/8)
472-347	SCREW,SET (#10X3/8)CUP PT NYLK
472-355	LOCKNUT,BALL BRG (.969-32)
472-360	SCREW,BHC (#10-32 X 3/8) NYLOK
472-363	PIN,DOWEL (GROUND)
472-370	SCREW,FHSC (#8-32 X 3/8)
472-371	PIN,DOWEL (GROUND)
472-413	SCREW,BHC (3/6-16 X 2 1/2)
472-414	SCREW,BHC (#10-32X1/2) NYLOK
472-415	SCREW,SHC (5/8-11 X 5)
472-424	SCREW,SET (1/4X5/8)CUP PT NYLK
472-427	SCREW,SHC (1/4-28 X 1)
472-433	SCREW,SHLDR (3/8DX3/8)LG 5/1618
472-437	SCREW,SHC (5/16-18 X 3/4)NYLOK
472-438	SCREW,RHM (#6-32 X 1 1/4)
472-461	SCREW,SHC (#6-40 X 1/4)
472-493	SCREW,SHC (#10-32 X 5/8)NYLOK
472-496	SCREW,SHC (1/4-20 X 3/8)
472-497	NUT,HEX (5/16-18)
472-502	SCREW,S/TAP (#6X3/8)RD HD "Z"
472-503	SCREW,S/TAP (#6X3/16)RD HD "B"
472-504	SCREW,S/TAP (#6X1/4)RD HD "B"
472-514	SCREW,DR (#2X1/4)RD HD "U"
472-515	ROUND HEAD DRIVE SCREW
472-519	SCREW,BIND HD (#10-32 X 1/4)
472-526	SCREW,RHM (#8-32 X 1/2)
472-527	SCREW,RHM (#8-32 X 1/4)
472-530	SCREW,RHM (#8-32 X 5/8)
472-531	SCREW,RHM (#10-24 X 1/4)
472-540	SCREW,SHC (1/4-20 X 5/8)
472-549	SCREW,SET (3/8-16X3/8)FLAT PT
472-568	NUT,HEX (3/8-24)

PART #	DESCRIPTION
472-569	SCREW MACHINE RELATED ITEM
472-577	NUT,HEX (#8-32) CAD PLT
472-578	NUT,HEX (#6-32) CAD PLT
472-582	NUT,ELASTIC STOP (3/8-16)
472-583	STOP NUT (ASM)
472-586	NUT,ELASTIC STOP
472-587	NUT,ELASTIC STOP (5/16-18)
472-589	STOP NUT
472-592	NUT, NYLON STOP
472-593	STOP NUT
472-594	NUT,ELASTIC STOP (3/8-24)
472-596	NUT,STOP
472-600	SCREW,SHC (#4-40 X 3/8)
472-611	NUT,HEX (1/4-28)
472-624	SCREW,S/TAP (#4X3/8)RD HD "F"
472-633	NUT,HEX 1/4-20 NYLOK
472-642	SCREW,BHC (#6-32 X 3/8)
472-643	SCREW,BHC (1/4-20X3/8) NYLOK
472-644	SCREW,SET (3/8-16X7/16)NYLONTP
472-647	SCREW,SET (5/16-18X3/4)CUPNYLK
472-659	SCREW,SET (1/4-20X1/4)NYLONFLT
472-661	SCREW,SET (3/8-16X1/2)CUP PT
472-662	SCREW,SET (3/8-16X3/4)CUP NYLK
472-690	SCREW,SHC (1/4-20 X 1 1/2)NYLK
472-695	SCREW,SHC (3/8-16 X 3/4)NYLOK
472-696	SCREW,LOCK INSERT
472-698	NUT,WELD (1/4-20)SHORT PILOT
472-703	SCREW,BHC (1/4-20 X 1/2) NYLOK
472-704	SCREW,SHLDR (1/2DX21/4LG3/8-16
472-706	SCREW,SHC (#10-32 X 1/2)NYLOK
472-708	SCREW,HHC (1/2-13 X 10)
472-709	SCREW,SET (1/2-13X1/2)CUP NYLK
472-724	SCREW,SHC (#8-32 X 5/8)
472-729	PIN
472-730	DYNASEAL WASHER
472-735	NUT,HEX (5/16-24)
472-752	SCREW,HHC (1/4-20 X 3/4)NYLOK

PART #	DESCRIPTION
472-755	SCREW, RETAINING
472-756	SCREW,SPEC SHC(#12-32 X 1 1/8)
472-786	PALNUT
472-830	SCREW,SET(SQHD)5/8-11X5
472-833	SCREW, HEX SOCKET SHOULDER
472-847	SCREW,BHC (1/4-20 X 5/8) NYLOK
472-856	SCREW,RD HD SELF-TAPPING
472-860	THREAD SEALING WASHER
472-957	SCREW,RHM (#4-40 X 1/2)BRASS
472-1028	KEY
472-1029	THREADED STEEL INSERT
472-1039	SCREW,SHC (#8-32 X 3/8)NYLOK
472-1043	SCREW,BHC (#8-32 X 3/8)
472-1048	SCREW,SET 10-32 1/2 DOG POINT
472-1050	SCREW, SHOLDER
472-1060	SCREW,SET (1/4-20X1/4)FLATNYLK
472-1063	SCREW,SHLDR (1/4DX3/4LG #10-32
472-1065	RIVET,3/16X3/8LG (OVAL HD)
472-1066	SCREW,HEX HD (1/2-20 X 1 3/4)
472-1067	SCREW
472-1076	SCREW,SET (#10-32X3/16)CONE PT
472-1080	SCREW,SHLDR (1/4DX3/8LG #10-32
472-1099	INSERT,HELI-COIL
472-1105	BUSHING
472-1114	NUT,HEX (7/16-20)
472-1120	SCREW,DR (#2X3/8) TYPE U
472-1129	PIN, DOWEL (ASM)
472-1134	SCREW,SET (M8 X 10) BRASS TIP
472-1237	SCREW,SHC LO-HEAD
472-1256	SCREW,S/TAP (#6X1/2)RD HD "B"
472-1280	LOCKNUT,BALL BRG (M30X1.5)SPLT
472-1284	SCREW,SET (3/8-24X2 1/4)FLATPT
472-1307	WASHER-STEEL
472-1401	NUT,ELASTIC STOP
472-1876	LOCK NUT
472-1877	WASHER
472-1878	LOCK NUT

PART #	DESCRIPTION
472-1879	LOCK WASHER
472-3168	COTTER PIN
472-3504	ROUND HEAD SCREW
472-3505	SCREW,FHM (#6-32 X 3/8)
472-3529	SCREW,SHC (5/16-18 X 5/8)
472-3535	SCREW,SET(SQHD)3/8-16X11/4CUP
472-3540	SCREW,SET (3/8-24X3/8)CUP PT
472-3541	SCREW,SET (#10X1) CUP PT
472-3543	SCREW,SET (#10-32X1/4)DOG FULL
472-3545	SCREW,SET (1/4-20X1)FLAT PT
472-3552	SCREW,SHC (#10-32 X 1 3/4)
472-3555	SCREW,SHC (#10-32 X 5/8)
472-3579	SCREW,RHM (#4-40 X 1/4)
472-3582	SCREW,RHM (#8-32 X 7/8)
472-9064	RETAINING RING
472-9077	SCREW
472-9078	SCREW,C'SINK
472-9089	SCREW
472-9120	LOCKNUT
472-50207	SOCKET CAP SCREW
472-53849	NUT,NYLOK
472-54124	SCREW,SHLDR 8MM
472-56508	SCREW MACHINE RELATED ITEM
472-57165	SCREW
472-57815	SCREW,GIB (1/4UNC X 1 1/2LG)
472-200404	SET SCREW 1/4- 28 X 3/8
473-1	HALF COUPLING
473-11	CHUCK (ASM)
473-12	COUPLING
473-75	CLUTCH PARTS (ASM)
473-81-1	LIMITER
473-82	LIMITER PARTS
473-112	BOLT
473-113	BOLT
473-139	COUPLING
473-154	GEAR SPIDER
473-163	TORQUE LIMITER

PART #	DESCRIPTION
473-163-A	BUSHING
473-164	FRICTION DISCS SET,TORQLIMTR.
473-174	FACING,TORQUE LIMITER
473-180	TIMING BELT PULLEY
473-253	HYDRAULIC CLUTCH ASSEMBLY
473-254	HYDRAULIC CLUTCH ASSEMBLY
473-258	FLEXIBLE COUPLING 7/8" BOR
473-259	FLEXIBLE COUPLING
473-261	INNER CLUTCH DISC
473-262	FLEX COUPLING 3/8" SHAFT
473-263	COUPLING,FLEXIBLE
473-287	FLEX COUPLING 3/8" SHAFT
473-288	COUPLING FLEX ELEM
473-294	COUPLING,FLEX DISC
473-299	COUPLING,FLEXIBLE
473-313	FLEXIBLE COUPLING
473-324	FLEX HALF COUPLING
473-3135	COUPLING,HALF
473-3136-1	COUPLING
473-9002	PULLEY POWERGRIP FLANGED
473-50818	SERVICE UNIT
479-72	COUNTER
479-82	PLUG
479-83-1	NEOPRENE
479-90	PLUG BUTTON (3/4 DIA) PLAIN FINH
479-111	ROD, THREADED (5/16-18X36")
479-151	HOSE CLAMP
479-206	PLUG BUTTON (1 1/2)
479-218	TUBING
479-232	KEY
479-242	MUFFLER, EXHAUST AIR
479-248	PLUG BUTTON (1 DIA)
479-308	CLAMP
479-323	COUNTER, 6 FIGURE VEEDEROOT
479-329-99	DISC
479-360	LATCH
479-393	ROD, THREADED (1/4-20X36")

PART #	DESCRIPTION
479-404	GEAR,BRASS SPUR
479-413	LATCH
479-431	GAUGE,PRESSURE (0-300PSI)
479-431-1	GAUGE, PRESSURE (0-200PSI)
479-440	LATCH
479-441	FASTENER
479-442	KNOB (ASM)
479-458	TUBING
479-509	KNOB
479-522	PLUG BUTTON (1 3/4DIA)
479-532	SPRING
479-553	SPRING, PLUNGER
479-554	PLUNGER,SPRING (3/8X.625LGNYLK
479-585	CABLE,PUSH-PULL
479-591	GROMMET,RUBBER (1 1/2ID)BUNA N
479-639	GASKET,16 GAUGE EXTRUDED
479-646	SPRING,WAVE (2.42ID X 3.118OD)
479-689	SPRING
479-727	PLUG BUTTON
479-747	FLEXANE PRIMER
479-772	BALL BUSHING
479-780	CATCH
479-816	FASTENER,ADJ PAWL
479-818	WEAR STRIP
479-819	BUSHING,22ID X 25OD X25
479-833	SPRING,COMP (5/8OD X 2 1/2LG)
479-841	CONNECTOR,FLARED
479-851	ROUND END KEY
479-854	SPRING,DISC (25.4MM ID)
479-861	SPRING,WAVE (.719ID X .925OD)
479-865	SPRING,DISC (30.5MM ID)
479-874	COVER (ASM)
479-875	SPRING,COMP (3/16OD X 5/8LG)
479-876	MAGNET CYLINDRICAL
479-882	ROD,THREADED (M10 X 1METER)
479-898	BUMPER,VINYL CABINET
479-901	STUD,SELF-CLINCH (5/16-18X3/4)

PART #	DESCRIPTION
479-908	GAUGE,PRESSURE (0-600PSI)
479-919	CYLINDER
479-921	SPRING,COMP (7/16OD X 1 1/2LG)
479-922	SPRING,EXT (.44ODX1.75LG).055W
479-923	FILTER
479-960	HYDRAULIC CYLINDER
479-1026	COMPRESSION SPRING
479-1053	COMPRESSION SPRING,.240ID X2
479-1067	SPRING,COMP (7/16OD X 7/8LG)
479-1082	SPRING,COMP (1/2OD X 2 1/4LG)
479-1089	ROD,THREADED (1/2-20X36")
479-1090	KNOB,BLK PLST (FOR #10 CAP SCR
479-1104	GAGE,PRESSURE (0-100)
479-1112	SPECIAL ALTERED BEARING
479-1112-C	BEARING
479-1115	SPRING,DISC (1"ID)
479-1133	SPRING,COMP (5/16OD X 2LG)
479-1155	HANDLE,ALUM (SATIN FINISH)
479-1157	SPRING,COMP (5/16OD X 1LG)
479-1187	LOCKING ELEMENT
479-1188	LOCKING ELEMENT
479-1189	LOCKING ELEMENT
479-1190	LOCKING ASSY
479-1191	SPEED REDUCTION
479-1193	COUPLING,SHAFT
479-1195	LOCKING ELEMENT
479-1196	LOCKING ELEMENT
479-1219	PLUG,3/16"DIA
479-1250	COLLAR,3/4 ID
479-1272	COLLAR,SPLIT
479-1421	TOLERANCE RING 1/2 DIAM
479-3108	ACORN DIE HOLDER CAP
479-3169	GASKET, SOLD BY THE FOOT
479-3177	GASKET
479-9015	V-BELT SHEAVE
479-9036	PRESSURE GAGE
507-227-34	MANCHESTER, INSERT

PART #	DESCRIPTION
599-7903	METROLOGY PART
599-7907-1	METROLOGY PART
600.056	HINGE - TB
600.057	HINGE
600.058	BOLT
600.323	SCREW SQ HEAD
600.354	SEGMENT CPL
600.436	GIB
600.734	PIN
600.747	GIB, TAPER
601.541	SCREW SQ HEAD
601.545	SCREW SQ HEAD
601.548	SCREW SQ HEAD
601.771	WEIGHT
602.622	TAIL STOCK
606-103	MANCHESTER, PIN
606-171	MANCHESTER, SCREW
606-205	MANCHESTER, SCREW
610.013	SHAFT CPL
610.060	TOOL HOLDER
610.094	SQUARE SOCKET WRENCH
610.095	SQ TUB. WRENCH 6
610.099	TOOL HOLDER FRONT
610.100	TOOL HOLDER BACK
610.111	CHUCKING CAM DRUM
610.126	CAM SETTING ATTACHMT
610.227	VALVE CPL
610.231	SUCTION HOSE
610.281	TOOL HOLDER CPL
611.095	FAUDI JOINT CPL
611.473	FRONT TOOL HOLDER
611.474	REAR TOOL HOLDER
611.515	TUBE CPL
611.647	LEVER, COMPLETE
611.943	SUPPORT SLIDE CPL
612.004	CHAIN TIGHTENER
612.454	SETTING ANGLE CPL

PART #	DESCRIPTION
612.462	FRONT SLIDE CPL
612.501	CAM HOLDER CPL
614.110	STOP LEVER
614.130	REAR TOOL HOLDER CPL
614.837	SERRATED WORM GEAR CPL
614.839	SERRATED WORM GEAR
614.977	SPINDLE
615.152	TRIP DOG
615.153	ROLLER PIN CPL
615.427	ROLLER PIN CPL
615.766	SEGMENT 40DEGREES CPL
615.809	CROSS SLIDE
616.148	QUILL CPL
616.179	MICROMET. SCREW CPL
616.624	PROTECTIVE COVER
620.009	COLLET SLEEVE
620.010	COLLET SLEEVE
620.018	PIN
620.027	LOCKING NUT
620.030	SPACER
620.032	SPACER
620.040	WORM
620.042	ADJUSTING RING
620.045	PIN
620.050	SETSCREW
620.066	GEAR WHEEL Z-34 M1.50MM
620.067	SPACER
620.070	COVER PLATE
620.071	COVER PLATE
620.075	COPYING PIN
620.077	PRESSURE PAD
620.078	SETSCREW
620.079	SETSCREW
620.116	ROLLER
620.117	ROLLER PIN
620.134	PIN
620.136	STOP CAM

PART #	DESCRIPTION
620.196	GUIDING PIN
620.289	NUT, T BOLT SLOT
620.306	SPACER, T-SLOT
620.314	HEX NUT
620.320	SLOTTED NUT
620.321	STUD
620.388	BOLT
620.391	WASHER
620.395	BUSHING CPL
620.396	BUSHING CPL
620.398	GEAR WHEEL Z-25 M1.25MM
620.399	GEAR WHEEL Z-35 M1.25MM
620.400	GEAR WHEEL Z-40 M1.25MM
620.401	GEAR WHEEL Z-45 M1.25MM
620.402	GEAR WHEEL Z-50 M1.25MM
620.408	WASHER
620.436	SETSCREW
620.873	COVER PLATE
620.893	ROUND PIN
620.894	TOOL HOLDER
620.896	SCREW SQ HEAD
620.907	BUSHING
620.908	SCREWING SLEEVE
620.909	STUD
620.951	SPACER
620.955	COLLET SLEEVE, FOR DIN COLLETS
620.956	SLEEVE, 21 COLLET
620.960	SPACER
620.961	SPACER
620.962	SPACER
620.963	SPACER
620.979	LOCKING NUT
621.142	GUIDING PIN
621.205	WORM
621.209	ADJUSTING RING
621.234	CAM PIN
621.242	SHOULDER STUD

PART #	DESCRIPTION
621.243	DEGREED BUSHING
621.390	ROLLER
621.397	COMPRESSION PIECE
621.430	SLOTTED NUT
621.431	STUD BOLT
621.432	HEXAGONAL NUT
621.482	BOLT
621.574	SLOTTED NUT
621.716	CHUCKING SLEEVE
622.376	GEAR WHEEL Z-9 M3.00MM
622.377	MAJOR AXIS
622.378	MINOR AXIS
622.380	GEAR WHEEL Z9 M3
622.564	KNURLED NUT
623.295	CLUTCH LEVER
623.381	GEAR WHEEL Z-75
623.682	SPINDLE NOSE CAP
623.858	SCREW SQ HEAD
623.867	SQUARE HEAD SCREW
623.870	SCREW SQ HEAD
623.874	SCREW SQ HEAD
623.914	SCREW SQ HEAD
623.921	SQUARE HEAD SCREW
624.068	THREADED PIN
624.072	THREADED PIN
624.102	THREADED PIN
624.103	THREADED PIN
624.112	THREADED PIN
624.161	SCREW
624.182	COUNTERSUNK SCREW
624.206	WASHER
624.216	WASHER
624.221	BRASS PLATEN
624.222	PRESSURE PAD
624.232	BEVEL PIN
624.284	HEXAGONAL SCREW
624.286	HEXAGONAL SCREW

PART #	DESCRIPTION
624.333	SCREW
624.386	HEX NUT
624.387	HEX NUT
624.388	HEX NUT
624.393	HEXAGONAL NUT
624.399	HEXAGONAL NUT
624.401	HEXAGONAL NUT
624.404	HEXAGONAL NUT
624.458	CLUTCH SLEEVE
624.940	CHUCKING TUBES
625.067	PIN
625.189	WASHER
625.299	ECCENTRIC THRENDEN PIN
625.763	WASHER
625.886	GEAR WHEEL Z-27
626.152	HEX NUT
626.287	BUSHING CPL
626.342	GIB, REAR CROSS SLIDE A42
626.351	GUIDE GIB
626.352	TAPER GIB
626.353	GUIDE GIB
626.399	PIN
626.493	HEXAGONAL NUT
626.702	ROD
626.770	BUSHING CPL
626.881	BOLT
626.890	STOP PIN
627.148	ROUND NUT
627.492	HOLLOW SHAFT
627.933	STUD
628.080	ADJUSTING NUT
628.083	BOLT
628.118	RING
628.179	GEAR WHEEL
628.223	TIMING BELT PULLEY
628.310	LEVER SRV-TB
628.368	SLEEVE

PART #	DESCRIPTION
628.450	RING
628.552	ROD
628.553	HOLLOW SHAFT
628.578	BUSHING
628.579	BUSHING CPL
628.591	LEVER
629.012	BUSHING
630.012	BEARING HOUSING
630.015	SLOTTED NUT
630.021	BEARING SLEEVE
630.048	GEAR
630.049	GEAR WHEEL Z-34 M1.50MM
630.051	BEARING SLEEVE
630.057	BACK SLIDE
630.058	CAM LEVER
630.073	PINCH COCK
630.078	LEVER
630.080	GUIDE BUSHING
630.130	LEVER
630.184	CAM
630.185	CAM
630.216	CAM
630.217	DRILLING CAM
630.259	HUB
630.260	HUB
630.261	SPROCKET
630.263	SERRATED WORM GEAR
630.265	GEAR WHEEL Z-80 M1.25MM
630.266	GEAR WHEEL Z-90 M1.25MM
630.267	GEAR WHEEL Z-100 M1.25MM
630.484	SUPPORT SLIDE
630.517	SLOTTED NUT
630.519	SPINDLE NOSE CAP, #21
630.520	CHUCK LEVER BEARING
630.522	NUT, COVER
630.524	PROTECTIVE COVER
630.696	NUT, SLOTTED

PART #	DESCRIPTION
630.950	CHUCK LEVER
631.611	CHUCK FORK
631.623	PICK-UP ATTACHMENT
632.431	SLIDE GUIDE
632.435	CLUTCH SLEEVE
632.562	CLUTCH CONE
632.652	CLUTCH DISC
632.742	COVER CPL
632.744	ROPE WHEEL
633.104	MOTOR MOUNTING PLATE
633.112	CHUCK LEVER BEARING
633.126	SUPPORT BODY
633.449	CLUTCH CONE
633.454	BEARING FLANER
635.007	PROTECTIVE COVER
635.008	PROTECTIVE COVER
635.011	WORM GEAR
635.018	PULLEY
635.022	SUPPORT
635.080	RING NUT
635.083	CHUCK LEVER BEARING
635.129	CHUTE
635.130	BEARING SUPPORT
635.131	CAM LEVER
635.524	SPINDLE PROTECTIVE COVER
635.560	MAIN SPINDLE
635.561	SLEEVE, CHUCK LEVER
635.562	BEARING HOUSING
635.563	SCREW COVER
635.564	CHUCK LEVER SLEEVE
635.565	CAP NUT
635.566	SPINDLE (BARE)
635.808	CLUTCH DISC
640.032	PROTECTIVE COVER FRONT
640.033	PROTECTIVE COVER, BACK, A15/25
640.052	COVER, FRONT A60
640.053	COVER, REAR A60

PART #	DESCRIPTION
640.061	TIP
640.068	SEALING
641.013	RIGHT PARTITION
641.014	LEFT PARTITION
641.035	PROTECTIVE COVER RIGHT
642-8-00	VERTICAL SLIDE ATTCH.
642-9-00-2	LONGITUDINAL TURN
642-9-28-2	LONGITUDINAL TURNING ATTCH
642-12-00-5	SLOT/SLAB ATT.
642-14-00	SLABBING HOLDER
642-24-00-13	SCREW MACHINE RELATED ITEM
642-48-00-1	TURRET MILLING
642-49-00	RAPID PULL-OUT ATT.
642-50-00	SPINDLE BRAKE-NEUTRAL
642-54-00-1	COUNTING ATTACHMENT
642-54-2-2	PRODUCT COUNT ATTACH
642-56-2	#2 CRSS SLD MLLNG ATT
642-64-2	SPDL LOCATING, STYLE 1 OR 2
642-65-2	SPINDLE LOCATING ATTACHMENT
642-79-00	2ND OPERATION
642-81-2	SOUND ENCLOSURE
642-81-800-1-E	STUD
642-82-00	MIST COLLECTOR
642-85-001	MISTDFIER
642-110-2-1	PRODUCT COUNTER
642-117-2-3	FRONT ATTCH MOTOR BRACKET 2B
642.511	INSTRUCTION MANUAL A25
642.546	PARTS BOOK, TD16,26,36-TDF26
650.127	CHUCKING TUBE
650.128	PRESSURE SLEEVE
650.139	SLEEVE
650.142	COLLET SLEEVE
650.143	COMPRESSION SPRING
650.167	BOLT
650.169	JOINT BOLT
650.171	KEY
650.265	CHAIN

PART #	DESCRIPTION
650.267	TRACTION SPRING
650.816	PRESSURE SPRING
650.824	GEAR WHEEL Z-45
650.951	COLLET SLEEVE
650.955	CAP NUT
650.959	COMPRESSION SPRING
651.034	GEAR WHEEL Z-17
651.348	SHAFT
651.349	SHAFT
651.370	WASHER
651.371	TRACING
651.400	GUIDING PIN
651.497	BUSHING
651.619	RING
651.620	COMPRESSION SPRING
651.621	COLLET SLEEVE
651.623	INTERM. RING
651.624	INTERM. SLEEVE
651.625	TUBE
651.628	COLLET SLEEVE
651.633	SPINDLE NOSE CAP
651.640	MICROMETER BUSH
651.641	COLLAR SCREW
651.685	PIN
651.686	PIN
651.687	PIN
652.131	COMPRESSION SPRING
652.234	NUT
653.114	BUSHING
653.115	COMPRESSION SPRING
653.228	WORM
653.661	SLEEVE
653.662	CLUTCH DOG
653.721	SEGMENT 9DEGREES CPL
653.723	SEGMENT 30DEGREES CPL
653.724	SEGMENT 60DEGREES CPL
654.050	COMPRESSION SPRING

PART #	DESCRIPTION
654.055	PIN
654.056	BINDING PIECE
654.061	PLATE
655.156	ECCENTRIC SCREW
655.159	CHUCKING ROLLER CPL
655.353	CLUTCH LEVER
655.354	CLUTCH SLEEVE
655.355	BEARING HOUSING
655.441	PIN
655.571	COVER, WORM SHAFT BACK
656.063	CRANK
656.118	GRUB SCREW
656.194	SCREW SQ HEAD
656.454	INDEX PIN CPL
656.493	PINION CPL M.2.0 Z22
656.495	PIN
656.496	CAM
656.529	GEAR SHAFT
656.546	SHAFT Z-16 M1.00
656.562	BOLT
656.566	THREDED PIN
656.574	SPRING *
656.578	ECCENTRIC PIN
656.579	CAM PIN
656.669	STUB BOLT
656.752	PIN
656.753	CLUTCH DISC
656.755	BOLT
656.906	CAM SHAFT
657.012	SCREW SQ HEAD
657.013	SCREW SQ HEAD
657.014	SCREW SQ HEAD
657.015	SCREW SQ HEAD
657.016	SCREW SQ HEAD
657.018	SCREW SQ HEAD
657.068	CLUTCH DISC
657.069	CLUTCH DISC

PART #	DESCRIPTION
657.070	GEAR WHEEL Z-45
657.071	COVER
657.072	RELEASE DISC
657.073	LOCK NUT
657.074	BOLT
657.079	CYLINDRICAL PIN
658.545	CLUTCH CONE CPL
658.746	TAPER GIB
659.094	BUSHING, MICRO
659.254	DOUBLE INDEX MECHANISM
659.274	SETSCREW
659.276	WEDGE
659.400	PIN
659.401	COVER
659.402	GUIDE SHAFT
659.403	DRIVE SHAFT
661.435	CHUCK LEVER - M125NAR
670.032	SCREW, SQ HD
670.131	SCREW SQ HEAD
670.140	SCREW SQ HEAD
670.493	SCREW SQ HEAD
670.786	PIN
670.796	SLIDING BLOCK
671.295	NUT, HEX
671.688	SCREW SQ HEAD
672.390	COLLET NUT
675.897	WELDED BASE PIN
682.335	BOLT
691.053	BUSHING TD
691.054	BUSHING
691.056	PIN
691.057	PIN
691.061	SHAFT
691.086	GEAR WHEEL Z-31 M1.25MM
691.088	GEAR WHEEL Z-33 M1.25MM
691.090	GEAR WHEEL Z-36 M1.25MM
691.092	GEAR WHEEL Z-42 M1.25MM

PART #	DESCRIPTION
691.094	GEAR WHEEL Z-48 M1.25MM
691.096	GEAR WHEEL Z-60 M1.25MM
691.098	GEAR WHEEL Z-66 M1.25MM
691.100	GEAR WHEEL Z-72 M1.25MM
691.104	GEAR WHEEL
691.111	GEAR WHEEL Z-39 M1.25MM
691.115	FLANGE
691.123	PROTECTIVE COVER
691.124	FLANGE
691.162	BACK CAMSHAFT
691.237	PRESSURE SLEEVE
691.243	COMPRESSION SPRING
691.267	CHUCK LEVER BEARING
691.273	SPINDLE BUSHING TD-26
691.279	COMPRESSION SPRING
691.281	ADJUSTING NUT
691.283	NUT
691.285	PROTECTIVE COVER
691.320	COMPRESSION SPRING
691.325	CHUCK LEVER TD
691.362	COLLET SLEEVE TD26
691.431	SERRATED PULLEY Z-28 CPL
691.599	LEVER
691.612	HOLED COVER
691.621	CAM DRUM
691.630	PIN
691.631	PIN
691.677	CAM
691.684	CAM
691.688	DRUM
691.689	PIN
691.973	HOOK
691.977	PIN
692.016	FLAG
692.161	SERRATED BELT PULLEY
692.163	INTERM. PULLEY Z-31
692.166	BACK WORM GEAR CPL

PART #	DESCRIPTION
692.167	FRONT WORM GEAR CPL
692.362	SEGMENT CPL
692.363	SEGMENT
692.364	SCALE
692.365	SCREW
692.456	PIN
692.518	GASKET
692.520	PACKING
692.521	SHAFT I
692.601	GEAR DRIVE PULLEY
692.602	GEAR DRIVE PULLEY
692.637	RING
692.681	DRIVE WHEEL
692.741	BELT PULLEY
692.774	CAM DRUM
692.791	DISC
692.804	HOUSING
692.808	BUSHING
692.811	PIN
692.818	ECCENTRIC PIN
692.828	ROLLER
692.829	PIN
692.830	PIN
692.834	DOWEL PIN
692.838	FLANGE
692.845	COVER
692.848	CAM PINION
692.862	COVER
692.876	DISC
692.877	WHITE FELTER DISC
692.884	PIN
692.887	PIN
692.891	ECCENTRIC SCREW
692.893	PIN
692.894	SCREWING SLEEVE
692.897	SHAFT
692.902	SEGMENT

PART #	DESCRIPTION
692.903	PIN
692.907	CLAMPING PIECE
692.914	DEGREED SCALE
692.925	ROD
693.030	
693.070	DAMPING ELEMENT
693.075	LEVER
693.162	NUT FOR COLLET TD/F-36
693.170	
693.181	CAP NUT
693.849	INDEXING LEVER CPL
693.885	RING
693.887	BEARING HOUSING
693.888	BEVEL GEAR SHAFT
693.901	SLIDE BODY
693.925	BUSHING
693.926	SCREW
693.930	TAPER GIB
693.931	PIN
693.935	TAPER GIB
693.945	CAM HOLDER CPL
693.991	LEVER CPL
693.992	LEVER
693.993	SETSCREW CPL
693.995	GRADUATED DRUM
694.002	PIN
694.003	PIN
694.006	NUT
694.180	PIECE SORTING ATTACHMT CPL
694.181	PARTS DEFLECTOR CPL
694.211	CHUCKING LEVER
694.220	CLAMPING PIECE
694.279	CHUCKING LEVER
694.437	SLEEVE
694.444	FRONT CAMSHAFT
694.529	WASHER
694.594	LEVER CPL

PART #	DESCRIPTION
694.640	SUPPORT LEVER
694.642	SLIDE LEVER
694.648	SETSCREW
694.724	VERTICAL SLIDE SS
694.727	PLATE
694.739	PLATE
694.808	SHAFT
694.913	SEGMENT 5DEGREES CPL
694.915	SEGMENT 9DEGREES
694.917	SEGMENT 16DEGREES
694.919	SEGMENT 30DEGREES CPL
694.921	SEGMENT 60DEGREES CPL
694.925	SEGMENT 60DEGREES CPL
694.941	HOLDER
694.945	ALU LABEL TD-CX MICR
695.040	FRONT PROTECTION
695.101	CRANK CPL
695.129	TOOL HOLDER
695.150	FRONT SUPPORT CPL
695.154	SLOTT SCREW
695.155	BACK SUPPORT CPL
700-121	SCREW MACHINE RELATED ITEM
700.855	TRAY
705-622-20	SCREW MACHINE RELATED ITEM
710-1002-110	10 COLLET 1/32" RD
710-1003-110	10 COLLET 3/64" RD
710-1004-100	00 COLLET 1/16 RD
710-1004-107	107 COLLET 1/16 RD
710-1004-110	10 COLLET 1/16 RD
710-1004-111	11 COLLET 1/16 RD
710-1004-211	11C COLLET 1/16 RD
710-1004-710	10 STUB COLLET 1/16 RD
710-1004-711	11 STUB COLLET 1/16" RD
710-1005-100	00 COLLET 5/64 RD
710-1005-110	10 COLLET 5/64 RD
710-1005-110-M	10 COLLET 5.0MM RD
710-1005-111	11 COLLET 5/64 RD

PART #	DESCRIPTION
710-1005-711	11 STUB COLLET 5/64 RD
710-1006-100	00 COLLET 3/32 RD
710-1006-110	10 COLLET 3/32 RD
710-1006-111	11 COLLET 3/32 RD
710-1006-211	11C COLLET 3/32 RD
710-1006-710	10 STUB COLLET 3/32 RD
710-1006-711	11 STUB COLLET 3/32 RD
710-1007-110	10 COLLET 7/64 RD
710-1007-111	11 COLLET 7/64 RD
710-1007-211	11C COLLET 7/64 RD
710-1007-711	11 STUB COLLET 7/64 RD
710-1008-100	00 COLLET 1/8 RD
710-1008-110	10 COLLET 1/8 RD
710-1008-111	11 COLLET 1/8 RD
710-1008-121	21 COLLET 1/8 RD
710-1008-122	22 COLLET 1/8 RD
710-1008-211	11C COLLET 1/8 RD
710-1008-722	22 STUB COLLET 1/8 RD
710-1009-110	10 COLLET 9/64 RD
710-1009-111	11 COLLET 9/64 RD
710-1009-111-M	11 COLLET 03.50 MM RD
710-1009-211	11C COLLET 9/64 RD
710-1009-710	10 STUB COLLET 9/64 RD
710-1009-711	11 STUB COLLET 9/64 RD
710-1010-100	00 COLLET 5/32 RD
710-1010-110	10 COLLET 5/32 RD
710-1010-111	11 COLLET 5/32 RD
710-1010-122	22 COLLET 5/32 RD
710-1010-211	11C COLLET 5/32 RD
710-1010-722	22 STUB COLLET 5/32 RD
710-1011-110	10 COLLET 11/64 RD
710-1011-111	11 COLLET 11/64 RD
710-1011-211	11C COLLET 11/64 RD
710-1011-710	10 STUB COLLET 11/64 RD
710-1011-711	11 STUB COLLET 11/64 RD
710-1011-722	22 STUB COLLET 11/64 RD
710-1012-100	00 COLLET 3/16 RD

PART #	DESCRIPTION
710-1012-110	10 COLLET 3/16 RD
710-1012-111	11 COLLET 3/16 RD
710-1012-122	22 COLLET 3/16 RD
710-1012-211	11C COLLET 3/16 RD
710-1012-722	22 STUB COLLET 3/16 RD
710-1013-100	00 COLLET 13/64 RD
710-1013-107	107 COLLET 13/64 RD
710-1013-110	10 COLLET 13/64 RD
710-1013-111	11 COLLET 13/64 RD
710-1013-211	11C COLLET 13/64 RD
710-1013-710	10 STUB COLLET 13/64 RD
710-1013-722	22 STUB COLLET 13/64 RD
710-1014-100	00 COLLET 7/32 RD
710-1014-107	107 COLLET 7/32 RD
710-1014-110	10 COLLET 7/32 RD
710-1014-111	11 COLLET 7/32 RD
710-1014-121	21 COLLET 7/32 RD
710-1014-122	22 COLLET 7/32 RD
710-1014-211	11C COLLET 7/32 RD
710-1014-710	10 STUB COLLET 7/32 RD
710-1014-711	11 STUB COLLET 7/32 RD
710-1014-722	22 STUB COLLET 7/32 RD
710-1015-100	00 COLLET 15/64 RD
710-1015-108	108 COLLET 15/64 RD
710-1015-110	10 COLLET 15/64 RD
710-1015-111	11 COLLET 15/64 RD
710-1015-211	11C COLLET 15/64 RD
710-1015-711	11 STUB COLLET 15/64 RD
710-1016-100	00 COLLET 1/4 RD
710-1016-107	107 COLLET 1/4 RD
710-1016-108	108 COLLET 1/4 RD
710-1016-110	10 COLLET 1/4 RD
710-1016-111	11 COLLET 1/4 RD
710-1016-122	22 COLLET 1/4 RD
710-1016-211	11C COLLET 1/4 RD
710-1016-710	10 STUB COLLET 1/4 RD
710-1016-711	11 STUB COLLET 1/4 RD

PART #	DESCRIPTION
710-1017-100	00 COLLET 17/64 RD
710-1017-110	10 COLLET 17/64 RD
710-1017-111	11 COLLET 17/64 RD
710-1017-211	11C COLLET 17/64 RD
710-1017-710	10 STUB COLLET 17/64 RD
710-1017-711	11 STUB COLLET 17/64 RD
710-1017-722	22 STUB COLLET 17/64 RD
710-1018-100	00 COLLET 9/32 RD
710-1018-110	10 COLLET 9/32 RD
710-1018-111	11 COLLET 9/32 RD
710-1018-122	22 COLLET 9/32 RD
710-1018-211	11C COLLET 9/32 RD
710-1018-710	10 STUB COLLET 9/32 RD
710-1018-722	22 STUB COLLET 9/32 RD
710-1019-110	10 COLLET 19/64 RD
710-1019-111	11 COLLET 19/64 RD
710-1019-211	11C COLLET 19/64 RD
710-1019-710	10 STUB COLLET 19/64 RD
710-1019-722	22 STUB COLLET 19/64 RD
710-1020-110	10 COLLET 5/16 RD
710-1020-111	11 COLLET 5/16 RD
710-1020-122	22 COLLET 5/16 RD
710-1020-211	11C COLLET 5/16 RD
710-1020-710	10 STUB COLLET 5/16 RD
710-1020-711	11 STUB COLLET 5/16 RD
710-1021-100	00 COLLET 21/64 RD
710-1021-110	10 COLLET 21/64 RD
710-1021-111	11 COLLET 21/64 RD
710-1021-122	22 COLLET 21/64 RD
710-1021-211	11C COLLET 21/64 RD
710-1021-710	10 STUB COLLET 21/64 RD
710-1021-711	11 STUB COLLET 21/64 RD
710-1021-722	22 STUB COLLET 21/64 RD
710-1022-100	00 COLLET 11/32 RD
710-1022-110	10 COLLET 11/32 RD
710-1022-111	11 COLLET 11/32 RD
710-1022-122	22 COLLET 11/32 RD

PART #	DESCRIPTION
710-1022-211	11C COLLET 11/32 RD
710-1022-710	10 STUB COLLET 11/32 RD
710-1022-722	22 STUB COLLET 11/32 RD
710-1023-110	10 COLLET 23/64 RD
710-1023-111	11 COLLET 23/64 RD
710-1023-122	22 COLLET 23/64 RD
710-1023-211	11C COLLET 23/64 RD
710-1023-710	10 STUB COLLET 23/64 RD
710-1023-711	11 STUB COLLET 23/64 RD
710-1024-100	00 COLLET 3/8 RD
710-1024-108	108 COLLET 3/8 RD
710-1024-110	10 COLLET 3/8 RD
710-1024-111	11 COLLET 3/8 RD
710-1024-122	22 COLLET 3/8 RD
710-1024-211	11C COLLET 3/8 RD
710-1024-710	10 STUB COLLET 3/8 RD
710-1024-711	11 STUB COLLET 3/8 RD
710-1025-100	00 COLLET 25/64 RD
710-1025-110	10 COLLET 25/64 RD
710-1025-111	11 COLLET 25/64 RD
710-1025-122	22 COLLET 25/64 RD
710-1025-211	11C COLLET 25/64 RD
710-1025-710	10 STUB COLLET 25/64 RD
710-1026-110	10 COLLET 13/32 RD
710-1026-111	11 COLLET 13/32 RD
710-1026-121	21 COLLET 13/32 RD
710-1026-122	22 COLLET 13/32 RD
710-1026-211	11C COLLET 13/32 RD
710-1026-710	10 STUB COLLET 13/32 RD
710-1027-110	10 COLLET 27/64 RD
710-1027-111	11 COLLET 27/64 RD
710-1027-122	22 COLLET 27/64 RD
710-1027-211	11C COLLET 27/64 RD
710-1027-710	10 STUB COLLET 27/64 RD
710-1027-711	11 STUB COLLET 27/64 RD
710-1027-722	22 STUB COLLET 27/64 RD
710-1028-100	00 COLLET 7/16 RD

PART #	DESCRIPTION
710-1028-108	108 COLLET 7/16 RD
710-1028-109	109 COLLET 7/16 RD
710-1028-110	10 COLLET 7/16 RD
710-1028-110-M	10 COLLET 2.8 MM RD
710-1028-111	11 COLLET 7/16 RD
710-1028-121	21 COLLET 7/16 RD
710-1028-122	22 COLLET 7/16 RD
710-1028-211	11C COLLET 7/16 RD
710-1028-710	10 STUB COLLET 7/16 RD
710-1028-722	22 STUB COLLET 7/16 RD
710-1029-100	00 COLLET 29/64 RD
710-1029-110	10 COLLET 29/64 RD
710-1029-111	11 COLLET 29/64 RD
710-1029-122	22 COLLET 29/64 RD
710-1029-211	11C COLLET 29/64 RD
710-1029-710	10 STUB COLLET 29/64 RD
710-1030-100	00 COLLET 15/32 RD
710-1030-100-M	00 COLLET 3.0 MM RD
710-1030-110	10 COLLET 15/32 RD
710-1030-111	11 COLLET 15/32 RD
710-1030-121	21 COLLET 15/32 RD
710-1030-122	22 COLLET 15/32 RD
710-1030-211	11C COLLET 15/32 RD
710-1030-710	10 STUB COLLET 15/32 RD
710-1030-711	11 STUB COLLET 15/32 RD
710-1031-110	10 COLLET 31/64 RD
710-1031-111	11 COLLET 31/64 RD
710-1031-122	22 COLLET 31/64 RD
710-1031-211	11C COLLET 31/64 RD
710-1031-710	10 STUB COLLET 31/64 RD
710-1031-711	11 STUB COLLET 31/64 RD
710-1031-722	22 STUB COLLET 31/64 RD
710-1032-100	00 COLLET 1/2 RD
710-1032-109	109 COLLET 1/2 RD
710-1032-110	10 COLLET 1/2 RD
710-1032-111	11 COLLET 1/2 RD
710-1032-122	22 COLLET 1/2 RD

PART #	DESCRIPTION
710-1032-211	11C COLLET 1/2" RD
710-1032-710	10 STUB COLLET 1/2 RD
710-1033-110	10 COLLET 33/64 RD
710-1033-110-M	10 COLLET 3.3 RD
710-1033-111	11 COLLET 33/64 RD
710-1033-122	22 COLLET 33/64 RD
710-1033-211	11C COLLET 33/64 RD
710-1033-710	10 STUB COLLET 33/64 RD
710-1033-711	11 STUB COLLET 33/64 RD
710-1034-110	10 COLLET 17/32 RD
710-1034-110-M	10 COLLET 3.4 MM RD
710-1034-111	11 COLLET 17/32 RD
710-1034-122	22 COLLET 17/32 RD
710-1034-211	11C COLLET 17/32 RD
710-1034-711	11 STUB COLLET 17/32 RD
710-1034-722	22 STUB COLLET 17/32 RD
710-1035-110	10 COLLET 35/64 RD
710-1035-110-M	10 COLLET 3.5 MM RD
710-1035-111	11 COLLET 35/64 RD
710-1035-122	22 COLLET 35/64 RD
710-1035-211	11C COLLET 35/64 RD
710-1035-711	11 STUB COLLET 35/64 RD
710-1036-108	108 COLLET 9/16 RD
710-1036-110	10 COLLET 9/16 RD
710-1036-111	11 COLLET 9/16 RD
710-1036-122	22 COLLET 9/16 RD
710-1036-211	11C COLLET 9/16 RD
710-1036-710	10 STUB COLLET 9/16 RD.
710-1036-711	11 STUB COLLET 9/16 RD
710-1036-722	22 STUB COLLET 9/16 RD
710-1037-110	10 COLLET 37/64 RD
710-1037-111	11 COLLET 37/64 RD
710-1037-122	22 COLLET 37/64 RD
710-1037-211	11C COLLET 37/64 RD
710-1037-711	11 STUB COLLET 37/64 RD
710-1037-722	22 STUB COLLET 37/64 RD
710-1038-110	10 COLLET 19/32 RD

PART #	DESCRIPTION
710-1038-111	11 COLLET 19/32 RD
710-1038-121	21 COLLET 19/32 RD
710-1038-122	22 COLLET 19/32 RD
710-1038-211	11C COLLET 19/32 RD
710-1038-722	22 STUB COLLET 19/32 RD
710-1039-110	10 COLLET 39/64 RD
710-1039-111	11 COLLET 39/64 RD
710-1039-122	22 COLLET 39/64 RD
710-1039-211	11C COLLET 39/64 RD
710-1039-722	22 STUB COLLET 39/64 RD
710-1040-110	10 COLLET 5/8 RD
710-1040-111	11 COLLET 5/8 RD
710-1040-111-M	11 COLLET 4.0MM RD
710-1040-122	22 COLLET 5/8 RD
710-1040-211	11C COLLET 5/8 RD
710-1041-110	10 COLLET 41/64 RD
710-1041-111	11 COLLET 41/64 RD
710-1041-122	22 COLLET 41/64 RD
710-1041-211	11C COLLET 41/64 RD
710-1042-111	11 COLLET 21/32 RD
710-1042-122	22 COLLET 21/32 RD
710-1042-211	11C COLLET 21/32 RD
710-1042-722	22 STUB COLLET 21/32 RD
710-1043-111	11 COLLET 43/64 RD
710-1043-122	22 COLLET 43/64 RD
710-1043-211	11C COLLET 43/64 RD
710-1043-722	22 STUB COLLET 43/64 RD
710-1044-109	109 COLLET 11/16 RD
710-1044-111	11 COLLET 11/16 RD
710-1044-121	21 COLLET 11/16 RD
710-1044-122	22 COLLET 11/16 RD
710-1044-211	11C COLLET 11/16 RD
710-1044-711	11 STUB COLLET 11/16 RD
710-1045-111	11 COLLET 45/64 RD
710-1045-122	22 COLLET 45/64 RD
710-1045-211	11C COLLET 45/64 RD
710-1045-722	22 STUB COLLET 45/64 RD

PART #	DESCRIPTION
710-1046-111	11 COLLET 23/32 RD
710-1046-122	22 COLLET 23/32 RD
710-1046-211	11C COLLET 23/32 RD
710-1046-711	11 STUB COLLET 23/32 RD
710-1046-722	22 STUB COLLET 23/32 RD
710-1047-111	11 COLLET 47/64 RD
710-1047-122	22 COLLET 47/64 RD
710-1047-211	11C COLLET 47/64 RD
710-1047-722	22 STUB COLLET 47/64 RD
710-1048-109	109 COLLET 3/4 RD
710-1048-110	10 COLLET 3/4 RD
710-1048-111	11 COLLET 3/4 RD
710-1048-122	22 COLLET 3/4 RD
710-1048-211	11C COLLET 3/4 RD
710-1049-111	11 COLLET 49/64 RD
710-1049-122	22 COLLET 49/64 RD
710-1049-211	11C COLLET 49/64 RD
710-1049-722	22 STUB COLLET 49/64 RD
710-1050-100-M	00 COLLET 5.0 MM RD
710-1050-111	11 COLLET 25/32 RD
710-1050-111-M	11 COLLET 5.0MM RD
710-1050-122	22 COLLET 25/32 RD
710-1050-211	11C COLLET 25/32 RD
710-1050-722	22 STUB COLLET 25/32 RD
710-1051-111	11 COLLET 51/64 RD
710-1051-122	22 COLLET 51/64 RD
710-1051-211	11C COLLET 51/64 RD
710-1051-722	22 STUB COLLET 51/64 RD
710-1052-111	11 COLLET 13/16 RD
710-1052-122	22 COLLET 13/16 RD
710-1052-211	11C COLLET 13/16 RD
710-1052-711	11 STUB COLLET 13/16 RD
710-1052-722	22 STUB COLLET 13/16 RD
710-1053-111	11 COLLET 53/64 RD
710-1053-122	22 COLLET 53/64 RD
710-1053-211	11C COLLET 53/64 RD
710-1053-722	22 STUB COLLET 53/64 RD

PART #	DESCRIPTION
710-1054-111	11 COLLET 27/32 RD
710-1054-122	22 COLLET 27/32 RD
710-1054-211	11C COLLET 27/32 RD
710-1054-722	22 STUB COLLET 27/32 RD
710-1055-111	11 COLLET 55/64 RD
710-1055-122	22 COLLET 55/64 RD
710-1055-211	11C COLLET 55/64 RD
710-1055-722	22 STUB COLLET 55/64 RD
710-1056-111	11 COLLET 7/8 RD
710-1056-122	22 COLLET 7/8 RD
710-1056-211	11C COLLET 7/8 RD
710-1057-122	22 COLLET 57/64 RD
710-1057-211	11C COLLET 57/61 RD
710-1057-722	22 STUB COLLET 57/64 RD
710-1058-122	22 COLLET 29/32 RD
710-1058-211	11C COLLET 29/32 RD
710-1059-122	22 COLLET 59/64 RD
710-1059-211	11C COLLET 59/64 RD
710-1059-722	22 STUB COLLET 59/64 RD
710-1060-111-M	11 COLLET 6.0MM RD
710-1060-121	21 COLLET 15/16 RD
710-1060-122	22 COLLET 15/16 RD
710-1060-211	11C COLLET 15/16 RD
710-1060-211-M	11C COLLET 6.0MM RD
710-1060-722	22 STUB COLLET 15/16 RD
710-1061-122	22 COLLET 61/64 RD
710-1061-211	11C COLLET 61/64 RD
710-1062-122	22 COLLET 31/32 RD
710-1062-211	11C COLLET 31/32 RD
710-1062-722	22 STUB COLLET 31/32 RD
710-1063-122	22 COLLET 63/64 RD
710-1063-211	11C COLLET 63/64 RD
710-1063-722	22 STUB COLLET 63/64 RD
710-1064-122	22 COLLET 1 RD
710-1064-211	11C COLLET 1 RD
710-1064-322-S	COLLET, 22C SPECIAL
710-1070-110-M	10 COLLET 7.0 MM RD

PART #	DESCRIPTION
710-1077-110-M	10 COLLET 7.7 MM RD
710-1080-111-M	11 COLLET 8.0MM RD
710-1100-111-M	11 COLLET 10.0MM RD
710-1102-722	22 STUB COLLET 1 1/32 RD
710-1104-722	22 STUB COLLET 1 1/16 RD
710-1104-922	22C STUB COLLET 1 1/16 RD
710-1106-722	22 STUB COLLET 1 3/32RD
710-1108-822	22D STUB COLLET 1 1/8 RD
710-1110-111-M	11 COLLET 11.0 MM RD
710-1110-122-M	22 COLLET 11 HX
710-1110-722	22 STUB COLLET 1 5/32 RD
710-1111-211-M	11C COLLET 12.0MM RD
710-1112-722	22 STUB COLLET 1 3/16 RD
710-1114-111-D	11 COLLET .114 RD
710-1114-722	22 STUB COLLET 1 7/32 RD
710-1116-126	26 COLLET 1/4 RD
710-1116-922	22C STUB COLLET 1 1/4" RD
710-1120-111-D	11 COLLET .120" RD
710-1120-111-M	11 COLLET 11.0MM RD
710-1120-211-M	11C COLLET 12.0MM RD
710-1120-322-M	22C COLLET 12 RD
710-1120-723	23 STUB COLLET 1 5/16 RD
710-1120-822	22D STUB COLLET 1 5/16RD
710-1124-122-M	22 COLLET 12.4 RD
710-1124-723	23 STUB COLLET 1 3/8 RD
710-1124-822	22D STUB COLLET 1-3/8R
710-1128-822	22D STUB COLLET 1-7/16R
710-1130-110-M	10 COLLET 13MM RD
710-1130-211-M	11C COLLET 13.0MM RD
710-1132-723	23 STUB COLLET 1 1/2 RD
710-1132-822	22D STUB COLLET 1-1/2 RD
710-1136-723	23 STUB COLLET 1 9/16 RD
710-1136-822	22D STUB COLLET 1-9/16R
710-1140-723	23 STUB COLLET 1 5/8 RD
710-1140-822	22D STUB COLLET 1 5/8 RD
710-1145-111-M	11 COLLET 14.5MM RD
710-1148-223	B52 COLLET 1-3/4 RD

PART #	DESCRIPTION
710-1148-723	23 STUB COLLET 1 3/4 RD
710-1156-723	23 STUB COLLET 1 7/8 RD
710-1160-111-M	11 COLLET 16.0MM RD
710-1160-122-M	22 COLLET 16 RD
710-1160-211-M	11C COLLET 16.0MM RD
710-1160-723	23 STUB COLLET 1 15/16RD
710-1164-723	23 STUB COLLET 2 RD
710-1165-111-D	11 COLLET .165 IN RD
710-1170-111-M	11 COLLET 17.0 MM RD
710-1170-211-M	11C COLLET 17.0MM RD
710-1176-111-M	11 COLLET 17.6 RD
710-1180-211-M	11C COLLET 18.0MM RD
710-1190-122-M	22 COLLET 19 RD
710-1192-111-M	11 COLLET 19.2MM RD
710-1192-122-M	22 COLLET 19.2 MM RD
710-1192-211-M	11C COLLET 19.2MM RD
710-1195-121-M	21 COLLET 19.5 RD
710-1204-723	23 STUB COLLET 2 1/16 RD
710-1208-723	23 STUB COLLET 2 1/8 RD
710-1210-122-M	21 COLLET 21 RD
710-1212-723	23 STUB COLLET 2 3/16 RD
710-1216-723	23 STUB COLLET 2 1/4 RD
710-1224-723	23 STUB COLLET 2 3/8 RD
710-1382-111-D	11 COLLET .382
" RD	40.250 0
710-1597-711-D	11 STUB COLLET (SPECIAL)
710-2004-110	10 COLLET 1/16 SQ
710-2005-110	10 COLLET 5/64 SQ
710-2006-110	10 COLLET 3/32 SQ
710-2006-111	11 COLLET 3/32 SQ
710-2007-110	10 COLLET 7/64 SQ
710-2008-100	00 COLLET 1/8 SQ
710-2008-110	10 COLLET 1/8 SQ
710-2008-111	11 COLLET 1/8 SQ
710-2008-211	11C COLLET 1/8 SQ
710-2008-710	10 STUB COLLET 1/8 SQ
710-2009-110	10 COLLET 9/64 SQ

PART #	DESCRIPTION
710-2010-110	10 COLLET 5/32 SQ
710-2010-111	11 COLLET 5/32 SQ
710-2010-211	11C COLLET 5/32 SQ
710-2011-110	10 COLLET 11/64 SQ
710-2012-100	00 COLLET 3/16 SQ
710-2012-110	10 COLLET 3/16 SQ
710-2012-111	11 COLLET 3/16 SQ
710-2012-211	11C COLLET 3/16 SQ
710-2012-722	22 STUB COLLET 3/16 SQ
710-2013-110	10 COLLET 13/64 SQ
710-2014-100	00 COLLET 7/32 SQ
710-2014-110	10 COLLET 7/32 SQ
710-2014-111	11 COLLET 7/32 SQ
710-2014-211	11C COLLET 7/32 SQ
710-2015-110	10 COLLET 15/64 SQ
710-2016-100	00 COLLET 1/4 SQ
710-2016-110	10 COLLET 1/4 SQ
710-2016-111	11 COLLET 1/4 SQ
710-2016-121	21 COLLET 1/4 SQ
710-2016-122	22 COLLET 1/4 SQ
710-2016-211	11C COLLET 1/4 SQ
710-2016-711	11 STUB COLLET 1/4 SQ
710-2016-722	22 STUB COLLET 1/4 SQ
710-2017-110	10 COLLET 17/64 SQ
710-2018-110	10 COLLET 9/32 SQ
710-2018-111	11 COLLET 9/32 SQ
710-2018-211	11C COLLET 9/32 SQ
710-2019-110	10 COLLET 19/64 SQ
710-2020-110	10 COLLET 5/16 SQ
710-2020-111	11 COLLET 5/16 SQ
710-2020-121	21 COLLET 5/16 SQ
710-2020-122	22 COLLET 5/16 SQ
710-2020-211	11C COLLET 5/16 SQ
710-2020-710	10 STUB COLLET 5/16 SQ
710-2021-110	10 COLLET 21/64 SQ
710-2022-110	10 COLLET 11/32 SQ
710-2022-111	11 COLLET 11/32 SQ

PART #	DESCRIPTION
710-2022-211	11C COLLET 11/32 SQ
710-2023-110	10 COLLET 23/64 SQ
710-2024-110	10 COLLET 3/8 SQ
710-2024-111	11 COLLET 3/8 SQ
710-2024-121	21 COLLET 3/8 SQ
710-2024-122	22 COLLET 3/8 SQ
710-2024-211	11C COLLET 3/8 SQ
710-2024-722	22 STUB COLLET 3/8 SQ
710-2026-111	11 COLLET 13/32 SQ
710-2026-211	11C COLLET 13/32 SQ
710-2028-110	10 COLLET 7/16 SQ
710-2028-111	11 COLLET 7/16 SQ
710-2028-121	21 COLLET 7/16 SQ
710-2028-122	22 COLLET 7/16 SQ
710-2028-211	11C COLLET 7/16 SQ
710-2030-211	11C COLLET 15/32 SQ
710-2032-111	11 COLLET 1/2 SQ
710-2032-121	21 COLLET 1/2 SQ
710-2032-122	22 COLLET 1/2 SQ
710-2032-211	11C COLLET 1/2 SQ
710-2032-711	11 STUB COLLET 1/2 SQ
710-2032-722	22 STUB COLLET 1/2 SQ
710-2036-111	11 COLLET 9/16 SQ
710-2036-122	22 COLLET 9/16 SQ
710-2036-211	11C COLLET 9/16 SQ
710-2040-111	11 COLLET 5/8 SQ
710-2040-122	22 COLLET 5/8 SQ
710-2040-211	11C COLLET 5/8 SQ
710-2044-122	22 COLLET 11/16 SQ
710-2044-722	22 STUB COLLET 11/16 SQ
710-2048-722	22 STUB COLLET 3/4 SQ
710-2050-110-M	10 COLLET 5.0 MM SQ
710-2056-722	22 STUB COLLET 7/8 SQ
710-2064-723	23 STUB COLLET 1 SQ
710-2064-822	22D STUB COLLET 1 SQ
710-2108-723	23 STUB COLLET 1 1/8 SQ
710-2108-822	22D STUB COLLET 1 1/8 SQ

PART #	DESCRIPTION
710-2124-723	23 STUB COLLET 1 3/8 SQ
710-2676-123	23M MASTER COLLET
710-3006-100	00 COLLET 3/32 HX
710-3006-110	10 COLLET 3/32 HX
710-3007-110	10 COLLET 7/64 HX
710-3008-110	10 COLLET 1/8 HX
710-3008-111	11 COLLET 1/8 HX
710-3009-110	10 COLLET 9/64 HX
710-3010-100	00 COLLET 5/32 HX
710-3010-110	10 COLLET 5/32 HX
710-3010-111	11 COLLET 5/32 HX
710-3010-211	11C COLLET 5/32 HX
710-3010-710	10 STUB COLLET 5/32 HX
710-3011-110	10 COLLET 11/64 HX
710-3012-100	00 COLLET 3/16 HX
710-3012-110	10 COLLET 3/16 HX
710-3012-111	11 COLLET 3/16 HX
710-3012-211	11C COLLET 3/16 HX
710-3013-110	10 COLLET 13/64 HX
710-3014-110	10 COLLET 7/32 HX
710-3014-111	11 COLLET 7/32 HX
710-3014-211	11C COLLET 7/32 HX
710-3014-710	10 STUB COLLET 7/32 HX
710-3014-711	11 STUB COLLET 7/32 HX
710-3015-110	10 COLLET 15/64 HX
710-3016-100	00 COLLET 1/4 HX
710-3016-110	10 COLLET 1/4 HX
710-3016-111	11 COLLET 1/4 HX
710-3016-122	22 COLLET 1/4 HX
710-3016-710	10 STUB COLLET 1/4 HX
710-3016-711	11 STUB COLLET 1/4 HX
710-3016-722	22 STUB COLLET 1/4 HX
710-3018-110	10 COLLET 9/32 HX
710-3018-111	11 COLLET 9/32 HX
710-3018-211	11C COLLET 9/32 HX
710-3020-100	00 COLLET 5/16 HX
710-3020-110	10 COLLET 5/16 HX

PART #	DESCRIPTION
710-3020-111	11 COLLET 5/16 HX
710-3020-121	21 COLLET 5/16 HX
710-3020-122	22 COLLET 5/16 HX
710-3020-211	11C COLLET 15/16 HX
710-3020-710	10 STUB COLLET 5/16 HX
710-3020-711	11 STUB COLLET 5/16 HX
710-3020-722	22 STUB COLLET 5/16 HX
710-3022-110	10 COLLET 11/32 HX
710-3022-111	11 COLLET 11/32 HX
710-3022-211	11C COLLET 11/32 HX
710-3024-110	10 COLLET 3/8 HX
710-3024-111	11 COLLET 3/8 HX
710-3024-121	21 COLLET 3/8 HX
710-3024-122	22 COLLET 3/8 HX
710-3024-211	11C COLLET 3/8 HX
710-3024-711	11 STUB COLLET 3/8 HX
710-3026-110	10 COLLET 13/32 HX
710-3026-111	11 COLLET 13/32 HX
710-3026-211	11C COLLET 13/32 HX
710-3028-110	10 COLLET 7/16 HX
710-3028-111	11 COLLET 7/16 HX
710-3028-121	21 COLLET 7/16 HX
710-3028-122	22 COLLET 7/16 HX
710-3028-211	11C COLLET 7/16 HX
710-3028-710	10 STUB COLLET 7/16 HX
710-3028-711	11 STUB COLLET 7/16 HX
710-3028-722	22 STUB COLLET 7/16 HX
710-3030-110	10 COLLET 15/32 HX
710-3030-111	11 COLLET 15/32 HX
710-3030-211	11C COLLET 15/32 HX
710-3032-110	10 COLLET 1/2 HX
710-3032-111	11 COLLET 1/2 HX
710-3032-121	21 COLLET 1/2 HX
710-3032-122	22 COLLET 1/2 HX
710-3032-211	11C COLLET 1/2 HX
710-3034-110	10 COLLET 17/32 HX
710-3034-111	11 COLLET 17/32 HX

PART #	DESCRIPTION
710-3036-110	10 COLLET 9/16 HX
710-3036-111	11 COLLET 9/16 HX
710-3036-122	22 COLLET 9/16 HX
710-3036-211	11C COLLET 9/16 HX
710-3036-711	11 STUB COLLET 9/16 HX
710-3040-111	11 COLLET 5/8 HX
710-3040-122	22 COLLET 5/8 HX
710-3040-211	11C COLLET 5/8 HX
710-3044-111	11 COLLET 11/16 HX
710-3044-122	22 COLLET 11/16 HX
710-3044-211	11C COLLET 11/16 HX
710-3044-722	22 STUB COLLET 11/16 HX
710-3048-111	11 COLLET 3/4 HX
710-3048-121	21 COLLET 3/4 HX
710-3048-122	22 COLLET 3/4 HX
710-3048-211	11C COLLET 3/4 HX
710-3052-122	22 COLLET 13/16 HX
710-3052-211	11C COLLET 13/16 HX
710-3052-722	22 STUB COLLET 13/16 HX
710-3055-110-M	10 COLLET 5.5 MM HX
710-3056-122	22 COLLET 7/8 HX
710-3056-722	22 STUB COLLET 7/8 HX
710-3060-722	22 STUB COLLET 15/16 HX
710-3080-110-M	10 COLLET 8.0MM HEX
710-3090-110-M	10 COLLET 9.0 HX
710-3104-722	22 STUB COLL 1-1/16 HEX
710-3108-822	22D STUB COLLET 1 1/8HX
710-3114-211-M	11C COLLET 14.0MM HX
710-3116-822	22D STUB COLLET 1 1/4HX
710-3120-822	22D STUB COLLET 1 5/16H
710-3124-723	23 STUB COLLET 1 3/8 HX
710-3124-822	22D STUB COLLET 1 3/8HX
710-3130-111-M	11 COLLET 13.0MM HX
710-3135-211-M	11C COLLET 13.5MM HX
710-3135-221-M	11C COLLET 13.5 HEX
710-3144-723	23 STUB COLLET 1 11/16HX
710-3152-211-M	11C COLLET 15.2MM HX

PART #	DESCRIPTION
710-3156-723	23 STUB COLLET 1 7/8 HX
710-3160-211-M	11C COLLET 16.0MM HEX
710-3170-122-M	22 COLLET 17.0MM HEX
710-3170-211-M	11C COLLET 17.0 MM HX
710-3170-221-M	21A FEEDFNGER 17 HEX
710-3193-110-D	10 COLLET .193 HX
710-3208-122-D	22 COLLET .820 HX
710-6028-322	22C COLLET 7/16 RD
710-6040-322	22C COLLET 5/8 RD
710-6048-722	22 STUB COLLET 3/4" RD
710-6058-722	22 STUB COLLET 29/32" RD
710-6061-422	22D COLLET 61/64 RD
710-6102-422	22D COLLET 1 1/32 RD
710-6110-322	22C COLLET 1 5/32 RD
710-6110-422	22D COLLET 1 5/32 RD
710-6114-322	22C COLLET 1 7/32 RD
710-6114-422	22D COLLET 1 7/32 RD
710-6116-722	22DS STUB COLLET 1-1/4 RD
710-6116-822	22D STUB COLLET 1 1/4" RD
710-6120-322	22C COLLET 1 5/16 RD
710-6128-422	22D COLLET 1 7/16 RD
710-6128-422-M	22D COLLET 36.15 MM RD
710-6132-822	22D STUB COLLET 1 1/2"RD
710-6140-323	B52 FEEDFNGR 1-5/8 RD
710-6140-422	22D COLLET 1 5/8 RD
710-6140-822	22D STUB COLLET 1 5/8" RD
710-6156-223	B52 COLLET 1-7/8 RD
710-6195-322-M	22C COLLET 19.5 RD
710-6200-120-M	20 COLLET 20.0 MM RD
710-6208-223	23A COLLET 2 1/8 RD
710-6208-723	23 STUB COLLET 2 1/8" RD
710-6216-223	23A COLLET 2 1/4 RD
710-6234-322-D	22C COLLET .920 RD
710-6250-722-M	22 STUB COLLET 25.0 MM RD
710-6260-322-M	22C COLLET 26 RD
710-6300-322-M	22C COLLET 30 RD
710-6300-722-M	22 STUB COLLET 30.0 MM RD

PART #	DESCRIPTION
710-8064-322	22C COLLET 1 HX
710-8104-322	22C COLLET 1 1/16 HX
710-8108-422	22D COLLET 1 1/8 HX
710-8112-422	22D COLLET 1 3/16 HX
710-8152-223	23A COLLET 1 13/16 HX
710-8256-722-M	22 STUB COLLET 25.6 MM HX
710-8270-322-M	22C COLLET 27 HEX
710-8280-422-M	22D COLLET 28 HX
710-8300-422-M	22D COLLET 30 HX
710-9005-60-25	COLLET, TOOL HOLD 6-5MM ER25
710-9005-120-25	COLLET, TOOL HOLD 12-11MM ER25
710-11224-223	23A MASTER COLLET
710-16002-110	10 FEEDFINGER 1/32 RD
710-16003-110	10 FEEDFINGER 3/64 RD
710-16004-100	00 FEEDFINGER 1/16 RD
710-16004-110	10 FEEDFINGER 1/16 RD
710-16004-111	11 FEEDFNDR 1/16 RD
710-16005-110	10 FEEDFINGER 5/64 RD
710-16005-111	11 FEEDFNDR 5/64 RD
710-16006-100	00 FEEDFINGER 3/32 RD
710-16006-110	10 FEEDFINGER 3/32 RD
710-16007-100	00 FEEDFINGER 7/64 RD
710-16007-110	10 FEEDFINGER 7/64 RD
710-16008-100	00 FEEDFINGER 1/8 RD
710-16008-110	10 FEEDFINGER 1/8 RD
710-16008-221	21A FEEDFINGER 7/64 R
710-16009-110	10 FEEDFINGER 9/64 RD
710-16009-111	11 FEEDFNDR 9/64 RD
710-16010-100	00 FEEDFINGER 5/32 RD
710-16010-108-M	108 FEEDFNDR 10.0 MM RD
710-16010-110	10 FEEDFINGER 5/32 RD
710-16011-100	00 FEEDFINGER 11/64 RD
710-16011-110	10 FEEDFINGER 11/64 RD
710-16011-111	11 FEEDFNDR 11/64 RD
710-16012-110	10 FEEDFINGER 3/16 RD
710-16012-122	22 FEEDFNDR 3/16 RD
710-16012-221	21A FEEDFNDR, 3/16 R

PART #	DESCRIPTION
710-16013-110	10 FEEDFINGER 13/64 RD
710-16013-111	11 FEEDFNGR 13/64 RD
710-16014-100	00 FEEDFINGER 7/32 RD
710-16014-108	108 FEEDFINGER 7/32" RD
710-16014-110	10 FEEDFINGER 7/32 RD
710-16015-100	00 FEEDFINGER 15/64 RD
710-16015-110	10 FEEDFINGER 15/64 RD
710-16015-111	11 FEEDFNGR 15/64 RD
710-16016-100	00 FEEDFINGER 1/4 RD
710-16016-108	108 FEEDFNGR 1/4 RD
710-16016-110	10 FEEDFINGER 1/4 RD
710-16016-122	22 FEEDFNGR 1/4 RD
710-16016-200	00A FEEDFNGR 1/4 RD
710-16017-100	00 FEEDFINGER 17/64 RD
710-16017-110	10 FEEDFINGER 17/64 RD
710-16017-111	11 FEEDFNGR 17/64 RD
710-16018-108	108 FEEDFNGR 9/32 RD
710-16018-110	10 FEEDFINGER 9/32 RD
710-16019-110	10 FEEDFINGER 19/64 RD
710-16020-100	00 FEEDFINGER 5/16 RD
710-16020-108	108 FEEDFINGER 5/16" RD
710-16020-110	10 FEEDFINGER 5/16 RD
710-16021-110	10 FEEDFINGER 21/64 RD
710-16021-111	11 FEEDFNGR 21/64 RD
710-16021-122	22 FEEDFNGR 21/64 RD
710-16022-108	108 FEEDFNGR 11/32 RD
710-16022-110	10 FEEDFINGER 11/32 RD
710-16023-110	10 FEEDFINGER 23/64 RD
710-16024-110	10 FEEDFINGER 3/8 RD
710-16024-200	00A FEEDFINGER 3/8 RD
710-16024-210	10A FEEDFNGR 3/8 RD
710-16024-221	21A FEEDFNGR 3/8 R
710-16025-110	10 FEEDFINGER 25/64 RD
710-16025-111	11 FEEDFNGR 25/64 RD
710-16025-411	11AA FEEDFNGR 25/64 RD
710-16026-111	11 FEEDFNGR 13/32 RD
710-16026-122	22 FEEDFNGR 13/32 RD

PART #	DESCRIPTION
710-16026-411	11AA FEEDFNGR 13/32 RD
710-16027-111	11 FEEDFNGR 27/64 RD
710-16027-210	10A FEEDFNGR 27/64 RD
710-16027-411	11AA FEEDFNGR 27/64 RD
710-16028-108	108 FEEDFNGR 7/16 RD
710-16028-122	22 FEEDFNGR 7/16" RD
710-16028-210	10A FEEDFNGR 7/16 RD
710-16028-211	21A FEEDFNGR 7/16 RD
710-16028-221	21A FEEDFNGR 7/16 R
710-16028-411	11AA FEEDFNGR 7/16 RD
710-16029-111	11 FEEDFNGR 29/64 RD
710-16029-210	10A FEEDFNGR 29/64 RD
710-16030-108	108 FEEDFNGR 15/32 R
710-16030-108-M	108 FEEDFNGR 3.0MM RD -CVA 8
710-16030-110-M	10 FEEDFINGER 3.0MM RD
710-16030-111	11 FEEDFNGR 15/32 RD
710-16030-210-M	10A FEEDFNGR 3.0 MM RD
710-16030-411	11AA FEEDFNGR 15/32 RD
710-16031-111	11 FEEDFNGR 31/64 RD
710-16031-210	10A FEEDFNGR 31/64 RD
710-16031-411	11AA FEEDFNGR 31/64 RD
710-16032-111	11 FEEDFNGR 1/2 RD
710-16032-122	22 FEEDFINGER 1/2" RD
710-16032-422	22H FEEDFNGR 1/2 R
710-16033-110-M	10 FEEDFNGR 3.3MM RD
710-16034-122	22 FEEDFNGR 17/32 RD
710-16034-211	11A FEEDFNGR 17/32 RD
710-16034-310	10AA FEEDFNGR 17/32 RD
710-16034-411	11AA FEEDFNGR 17/32 RD
710-16035-411	11AA FEEDFNGR 35/64 RD
710-16037-211	11A FEEDFNGR 37/64 RD
710-16038-211	11A FEEDFNGR 19/32 RD
710-16038-310	10AA FEEDFNGR 19/32 RD
710-16038-411	11AA FEEDFNGR 19/32 RD
710-16039-211	11A FEEDFNGR 39/64 RD
710-16039-310	10AA FEEDFNGR 39/64 RD
710-16039-411	11AA FEEDFNGR 39/64 RD

PART #	DESCRIPTION
710-16040-108-M	108 FEEDFINGER 4.0 MM RD
710-16040-110-M	10 FEEDFINGER 4.0MM RD
710-16040-122	22 FEEDFINGER 5/8 RD
710-16040-211	11A FEEDFNGR 5/8 RD
710-16040-221	21A FEEDFNGR 5/8 RD
710-16041-122	22 FEEDFNGR 41/64 RD
710-16042-122	22 FEEDFNGR 21/32 RD
710-16042-221	21A FEEDFNGR 21/32 RD
710-16042-411	11AA FEEDFINGER 21/32 RD
710-16043-122	22 FEEDFNGR 43/64 RD
710-16044-122	22 FEEDFNGR 11/16 RD
710-16044-221	21A FEEDFNGR 11/16 RD
710-16045-122	22 FEEDFNGR 45/64 RD
710-16045-221	21A FEEDFNGR 45/64 RD
710-16046-122	22 FEEDFNGR 23/32 RD
710-16046-221	21A FEEDFNGR 23/32 RD
710-16046-310	10AA FEEDFNGR 23/32 RD
710-16047-122	22 FEEDFNGR 47/64 RD
710-16048-122	22 FEEDFNGR 3/4 RD
710-16049-122	22 FEEDFNGR 49/64 RD
710-16050-108-M	108 FEEDFINGER 5.0 MM
710-16050-122	22 FEEDFNGR 25/32 RD
710-16050-210-M	10A FEEDFINGER 5.0 MM RD
710-16051-122	22 FEEDFNGR 51/64 RD
710-16052-122	22 FEEDFNGR 13/16 RD
710-16053-122	22 FEEDFNGR 53/64 RD
710-16054-116	16 FEEDFINGER 27/32/RD (CVA)
710-16054-122	22 FEEDFNGR 27/32 RD
710-16055-110-M	10 FEEDFINGER 5.5MM RD
710-16055-122	22 FEEDFNGR 55/64 RD
710-16056-122	22 FEEDFNGR 7/8 RD
710-16057-122	22 FEEDFNGR 57/64 RD
710-16058-122	22 FEEDFNGR 29/32 RD
710-16059-122	22 FEEDFNGR 59/64 RD
710-16060-122	22 FEEDFNGR 15/16 RD
710-16060-122-M	22 FEEDFNGR 6.0 RD
710-16061-122	22 FEEDFNGR 61/64 RD

PART #	DESCRIPTION
710-16062-122	22 FEEDFNGR 31/32 RD
710-16063-122	22 FEEDFNGR 63/64 RD
710-16064-122	22 FEEDFNGR 1 RD
710-16070-108-M	108 FEEDFNGER 7.0 MM RD
710-16070-210-M	10A FEEDFNGER 7.0 MM RD
710-16080-108-M	108 FEEDFNGER 8.0 MM RD
710-16080-210-M	10A FEEDFNGER 8.0 RD
710-16085-210-M	10A FEEDFNGER 8.5 MM RD
710-16090-108-M	108 FEEDFNGER 9.0 MM RD
710-16100-122-M	22 FEEDFNGR 10 RD
710-16100-221-M	21A FEEDFNGR 10.0 RD
710-16102-422	22H FEEDFNGR 1 1/32 RD
710-16104-422	22H FEEDFNGR 1 1/16 RD
710-16106-422	22H FEEDFNGR 1 3/32 RD
710-16108-422	22H FEEDFNGER 1 1/8" RD
710-16110-411-M	11AA FEEDFNGER 11.0 MM RD
710-16110-422	22H FEEDFNGR 1 5/32 RD
710-16112-422	22H FEEDFNGR 1 3/16 RD
710-16114-422	22H FEEDFNGR 1 7/32 RD
710-16116-108	108 FEEDFNGER 1 1/4 RD
710-16116-422	22H FEEDFNGR 1 1/4 RD
710-16120-112-M	22 FEEDFNGER 12.0 RD
710-16120-211-M	11A FEEDFNGER 12.0 MM RD
710-16130-111-M	11 FEEDFNGER 13.0 RD
710-16130-210-M	10A FEEDFNGR 13.0 RD
710-16136-123	23 FEEDFNGR 1 9/16 RD
710-16136-322	22D FEEDFNGER 1 9/16 RD
710-16140-110-M	10 FEEDFINGER 14.0 RD
710-16140-123	23 FEEDFNGR 1 5/8 RD
710-16145-111-M	11 FEEDFNGR 14.5 RD
710-16148-123	23 FEEDFNGR 1 3/4 RD
710-16150-122-M	22 FEEDFNGR 15 RD
710-16150-221-M	21A FEEDFNGR, 15.0 R
710-16156-123	23 FEEDFNGR 1 7/8 RD
710-16160-100-M	00 FEEDFNGR 16.0 RD
710-16160-122-M	22 FEEDFNGR 16 RD
710-16160-123	23 FEEDFNGR 1 15/16 RD

PART #	DESCRIPTION
710-16170-221-M	21A FEEDFNGR 17.0 RD
710-16180-221-M	21A FEEDFNGR 18.0 RD
710-16190-122-M	22 FEEDFNGR 19 RD
710-16192-221-M	21A FEEDFNGR 19.2 RD
710-16195-221-M	21A FEEDFNGR 19.5 MM RD
710-16204-127	27 FINGER 2 1/16 RD
710-16204-223	23 INVERT FF 2 1/16RD
710-16208-127	27 FINGER 2 1/8 RD
710-16212-127	27 FINGER 2 3/16RD
710-16216-127	27 FINGER 2 1/4 RD
710-16220-122-M	22 FEEDFNGR 22.0 RD
710-16220-223	23 INVERT FF 2 5/16RD
710-16220-322-M	22D FEEDFNGR 22.0 RD
710-16220-422-M	22H FEEDFNGR 22.0 HEX
710-16224-127	27 FINGER 2 3/8 RD
710-16305-322-M	22D FEEDFNGR 30.5 MM HX
710-16310-422-M	22H FEEDFINGER 31.0MM
710-16330-322-M	22D FEEDFNGR 33.0 MM RD
710-16360-322-M	22D FEEDFNGR 36.0 MM RD
710-16361-322-M	22D FEEDFNGR 36.15 MM RD
710-16500-123-M	23 FEEDFNGR 50.0 RD
710-16820-122-D	22 FEEDFNGR .820 HX
710-17004-110	10 FEEDFINGER 1/16 SQ
710-17006-110	10 FEEDFINGER 3/32 SQ
710-17008-100	00 FEEDFINGER 3/32 1/8 SQ
710-17008-110	10 FEEDFINGER 3/32 1/8 SQ
710-17008-111	11 FEEDFNGR 1/8 SQ
710-17008-211	11A FEEDFNGR 1/8 SQ.
710-17012-110	10 FEEDFINGER 5/32 3/16 SQ
710-17012-111	11 FEEDFNGR 3/16 SQ
710-17012-210	10A FEEDFNGR 3/16 SQ
710-17014-110	10 FEEDFINGER 7/32 SQ
710-17016-108	108 FEEDFNGR 1/4" SQ
710-17016-110	10 FEEDFINGER 7/32 1/4 SQ
710-17016-200	00A FDFINGER.7/32 1/4 SQ
710-17020-111	11 FEEDFNGR 9/32 5/16 SQ
710-17020-411	11AA FEEDFNGR 5/16 SQ
710-17024-111	11 FEEDFNGR 11/32 3/8 SQ

PART #	DESCRIPTION
710-17024-310	10AA FEEDFNGR 11/32 3/8SQ
710-17024-411	11AA FEEDFNGR 3/8 SQ
710-17028-310	10AA FEEDFNGR 7/16 SQ
710-17032-122	22 FEEDFNGR 1/2 SQ
710-17032-310	10AA FEEDFNGR 1/2 SQ
710-17036-122	22 FEEDFNGR 9/16 SQ
710-17038-110-M	10 FEEDFNGER 3.8M X 4.8M RECT
710-17040-122	22 FEEDFNGR 5/8 SQ
710-17044-122	22 FEEDFNGR 11/16 SQ
710-17048-422	22H FEEDFNGR 3/4 SQ
710-17052-422	22H FEEDFNGR 13/16 SQ
710-17056-422	22H FEEDFNGR 7/8 SQ
710-17060-110-M	10 FEEDFINGER 6.0MM SQ
710-17070-110-M	10 FEEDFINGER 7.0MM SQ
710-17132-127	27 FINGER 1 1/2 SQ
710-17132-223	23 INVERT FF 1 1/2SQ
710-17140-223	23 INVERT FF 1 5/8SQ
710-18004-110	10 FEEDFINGER 1/16 HX
710-18006-110	10 FEEDFINGER 3/32 HX
710-18007-110	10 FEEDFINGER 7/64 HX
710-18008-108	108 FEEDFINGER 1/8 HX
710-18008-110	10 FEEDFINGER 1/8 HX
710-18009-110	10 FEEDFINGER 9/64 HX
710-18010-100	00 FEEDFNGR 5/32 HEX
710-18010-110	10 FEEDFINGER 5/32 HX
710-18011-110	10 FEEDFINGER 11/64 HX
710-18012-100	00 FEEDFINGER 5/32 3/16 H
710-18012-110	10 FEEDFINGER 3/16 HX
710-18012-111	11 FEEDFNGR 3/16 HX
710-18013-110	10 FEEDFINGER 13/64 HX
710-18015-110	10 FEEDFINGER 15/64 HX
710-18016-110	10 FEEDFINGER 1/4 HX
710-18016-111	11 FEEDFNGR 1/4 HX
710-18018-108	108 FEEDFNGER 1/2" HX
710-18020-110	10 FEEDFINGER 9/32 5/16 HX
710-18020-210	10A FEEDFNGER 5/16 RD
710-18020-221	21A FEEDFNGR 5/16 HEX

PART #	DESCRIPTION
710-18022-110	10 FEEDFNGR .343 11/32" HX
710-18024-111	11 FEEDFNGR 11/32 3/8 HX
710-18024-411	11AA FEEDFNGR 11/32 3/8HX
710-18026-122	22 FEEDFNGR 13/32 HX
710-18028-108-D	108 FEEDFNGER .437" RD
710-18028-122	22 FEEDFNGR .437 7/16 HX
710-18028-211	11A FEEDFNGER 19/32 RD
710-18028-411	11AA FEEDFNGR13/32 7/16HX
710-18030-310	10AA FEEDFNGR 15/32 HEX
710-18036-122	22 FEEDFNGR 17/32 9/16 HX
710-18036-411	11AA FEED FINGER 9/16 HEX
710-18040-122	22 FEEDFNGR 19/32 5/8 HX
710-18042-122	22 FEEDFINGER 21/32" HEX
710-18044-122	22 FEEDFNGR 21/32 11/16H
710-18048-122	22 FEEDFNGR 23/32 3/4 HX
710-18052-122	22 FEEDFNGR 25/32 13/16H
710-18056-122	22 FEEDFNGR 27/32 7/8 HX
710-18056-422	22H FEEDFNGR 7/8" HX
710-18060-108-M	108 FEEDFNGER 6.0 MM HX
710-18060-110-M	10 FEEDFINGER 6.0MM HX
710-18060-422	22H FEEDFNGR 7/8 15/16HX
710-18064-422	22H FEEDFNGER 1" HX
710-18100-122-M	22 FEEDFNGR 10 RD
710-18104-422	22H FEEDFINGER 1-1/16 HX
710-18110-211-M	11A FEEDFNGER 14.0 MM HX
710-18110-422-D	22H FEEDFNGR 1.10 HX
710-18120-322	22D FEEDFNGER 1 5/16 HX
710-18120-522	22DD FEEDFNGER 1 5/16 HX
710-18130-211-M	11A FEEDFNGER 13.0 HEX
710-18140-221-M	21A FEEDFNGR 14.0 HX
710-18140-310-M	10AA FEEDFNGR 14.0 HX
710-18152-223	23 INVERT FF 1 13/16HX
710-18156-127	27 FINGER 1 7/8 HX
710-18156-223	23 INVERT FF 1 7/8HX
710-18160-223	23 INVERT FF 1 15/16HX
710-18160-310-M	10AA FEEDFNGR 16.0 HX
710-18200-127	27 FINGER 2 HX

PART #	DESCRIPTION
710-18220-422-M	22H FEEDFNGER 22.0 MM RD
710-18234-422-M	22H FEEDFNGR 23.4 HX
710-18248-108-D	108 FEEDFNGR .248 HX
710-18270-322-M	22D FEEDFNGER 27.0 MM HX
710-18279-422	22H FEEDFNGR 1.1 HX
710-18280-422-M	22H FEEDFINGER 28.0MM HEX
710-18290-322-M	22D FEEDFNGER 29.0 MM HX
710-18324-108-D	108 FEEDFNGER .324" HX
710-18445-210-D	10A FEEDFNGER .445 HX
710-18500-221-D	21A FEEDFNGR .50 HX
710-18525-211-M	11A FEEDFNGR 13.3 HEX
710-18920-320-D	20 FEEDFNGER 3920" HX
710-18920-422-D	22H FEEDFNGR .920 HEX
710-26028-210	10AM MASTER FEEDFINGER
710-26032-111	11M MASTER FEEDFINGER
710-26036-211	11AM MASTER FEEDFINGER
710-31124-226	26M COLLET PAD 1 3/8 RD
710-31128-226	26M COLLET PAD 1 7/16 RD
710-33128-226	26M COLLET PAD 1 7/16 HX
710-33148-226	26M COLLET PAD 1 3/4 HX
710-36224-226	26MD F-FINGER PAD 2 3/8 R
710-56004-100	00M NYLON PAD 1/16 RD
710-56004-110	10M NYLON PAD 1/16 RD
710-56005-100	00M NYLON PAD 5/64 RD
710-56005-110	10M NYLON PAD 5/64 RD
710-56006-100	00M NYLON PAD 3/32 RD
710-56006-110	10M NYLON PAD 3/32 RD
710-56007-100	00M NYLON PAD 7/64 RD
710-56007-110	10M NYLON PAD 7/64 RD
710-56008-100	00M NYLON PAD 1/8 RD
710-56008-110	10M NYLON PAD 1/8 RD
710-56009-100	00M NYLON PAD 9/64 RD
710-56009-110	10M NYLON PAD 9/64 RD
710-56010-100	00M NYLON PAD 5/32 RD
710-56010-110	10M NYLON PAD 5/32 RD
710-56011-100	00M NYLON PAD 11/64 RD
710-56011-110	10M NYLON PAD 11/64 RD

PART #	DESCRIPTION
710-56012-100	00M NYLON PAD 3/16 RD
710-56012-110	10M NYLON PAD 3/16 RD
710-56013-100	00M NYLON PAD 13/64 RD
710-56013-110	10M NYLON PAD 13/64 RD
710-56014-100	00M NYLON PAD 7/32 RD
710-56014-110	10M NYLON PAD 7/32 RD
710-56015-100	00M NYLON PAD 15/64 RD
710-56015-110	10M NYLON PAD 15/64 RD
710-56016-100	00M NYLON PAD 1/4 RD
710-56017-100	00M NYLON PAD 17/64 RD
710-56017-110	10M NYLON PAD 17/64 RD
710-56018-100	00M NYLON PAD 9/32 RD
710-56018-110	10M NYLON PAD 9/32 RD
710-56019-110	10M NYLON PAD 19/64 RD
710-56021-110	10M NYLON PAD 21/64 RD
710-56022-110	10M NYLON PAD 11/32 RD
710-56023-110	10M NYLON PAD 23/64 RD
710-56024-110	10M NYLON PAD 3/8 RD
710-56025-111	11M NYLON PAD 25/64 RD
710-56026-111	11M NYLON PAD 13/32 RD
710-56027-111	11M NYLON PAD 27/64 RD
710-56028-111	11M NYLON PAD 7/16 RD
710-56029-111	11M NYLON PAD 29/64 RD
710-56030-111	11M NYLON PAD 15/32 RD
710-56031-111	11M NYLON PAD 31/64 RD
710-56032-111	11M NYLON PAD 1/2 RD
710-56034-122	22M NYLON PAD 17/32 RD
710-56036-122	22M NYLON PAD 9/16 RD
710-56038-122	22M NYLON PAD 19/32 RD
710-56042-122	22M NYLON PAD 21/32 RD
710-56044-122	22M NYLON PAD 11/16 RD
710-56046-122	22M NYLON PAD 23/32 RD
710-57008-100	00M NYLON PAD 1/8 SQ
710-57008-110	10M NYLON PAD 1/8 SQ
710-57010-110	10M NYLON PAD 5/32 SQ
710-57012-100	00M NYLON PAD 3/16 SQ
710-57012-110	10M NYLON PAD 3/16 SQ

PART #	DESCRIPTION
710-57014-110	10M NYLON PAD 7/32 SQ
710-57016-110	10M NYLON PAD 1/4 SQ
710-57020-111	11M NYLON PAD 5/16 SQ
710-57024-122	22M NYLON PAD 3/8 SQ
710-57028-122	22M NYLON PAD 7/16 SQ
710-57032-122	22M NYLON PAD 1/2 SQ
710-58008-100	00M NYLON PAD 1/8 HX
710-58008-110	10M NYLON PAD 1/8 HX
710-58010-110	10M NYLON PAD 5/32 HX
710-58012-100	00M NYLON PAD 3/16 HX
710-58012-110	10M NYLON PAD 3/16 HX
710-58014-110	10M NYLON PAD 7/32 HX
710-58016-110	10M NYLON PAD 1/4 HX
710-58018-110	10M NYLON PAD 9/32 HX
710-58020-110	10M NYLON PAD 5/16 HX
710-58024-111	11M NYLON PAD 3/8 HX
710-58028-122	22M NYLON PAD 7/16 HX
710-58032-122	22M NYLON PAD 1/2 HX
710-58036-122	22M NYLON PAD 9/16 HX
710-58040-122	22M NYLON PAD 5/8 HX
710-91012-110	10 COLLET BLANK RD & HX
710-91017-111	11 COLLET BLANK RD & HX
710-91020-1	11C STUB COLLET 3-4" HX
710-91020-211	11C COLLET BLANK RD & HX
710-91028-122	22 COLLET BLANK RD & HX
710-92007-110	10 COLLET BLANK SQ
710-92011-111	11 COLLET BLANK SQ
710-92019-1	22 COLLET BLANK SQ
711-5-100	ADAPTER 00
711-5-110	ADAPTER 10A
711-5-111	ADAPTER 11-10
711-5-120	ADAPTER 20A-10
711-5-121	ADAPTER 21A-10
711-5-122	ADAPTER 22-10
711-5-123	ADAPTER 23-22
711-5-210	ADAPTER 10A-00
711-5-211	ADAPTER 11-11A-11AA

PART #	DESCRIPTION
711-5-221	ADAPTER 21A-11A-11AA
711-5-222	ADAPTER 22-11A-11AA
711-5-223	ADAPTER 23-22H
711-5-227	ADAPTER 27-23
711-5-310	ADAPTER 10A-10
711-5-320	ADAPTER 20-11
711-5-321	ADAPTER 21A-11
711-5-322	ADAPTER 22D-22
711-5-323	ADAPTER 23-22D
711-5-410	ADAPTER 10AA-10
711-5-420	ADAPTER 20-11A-11AA
711-5-422	ADAPTER 22D-22H
711-5-423	ADAPTER 23
711-5-427	ADAPTER 27-22H
711-5-510	ADAPTER 10AA-10A
711-5-522	ADAPTER 22H
711-5-523	ADAPTER 23-22DD
711-5-527	ADAPTER 27-22
711-5-622	ADAPTER 22H-10
711-5-627	ADAPTER 27-22DD
711-5-722	ADAPTER 22H-11A-11AA
711-5-727	ADAPTER 27-10
711-5-822	ADAPTER 22H 22
711-5-827	ADAPTER 27-11A OR 11AA
711-5-922	ADAPTER 22D-10
711-5-1022	ADAPTER 22D-11A-11AA
711-5-1222	ADAPTER 22-11
711-5-1322	ADAPTER 22H-11
711-5-1422	ADAPTER 22DD-10
711-5-1522	ADAPTER 22DD-11AA
711-5-1622	ADAPTER 22DD-22
711-5-1822	ADAPTER 22DD-22D
711-5-9000	ADAPTER
711-1008-100	FEEDTUBE BUSH 00 1/2
711-1010-120	FEEDTUBE BUSH 20 5/8
711-1012-120	FEEDTUBE BUSH 20 3/4
711-1016-122	FEEDTUBE BUSH 22 1

PART #	DESCRIPTION
711-1016-222	FEEDTUBE BUSH 22A 1
711-1020-122	FEEDTUBE BUSH 22 1-1/4
711-1024-222	FEEDTUBE BUSH 22A 1-1/2
711-1026-322	FEEDTUBE BUSH 22B 1-5/8
711-1032-126	FEEDTUBE BUSH 26 2
713-3-7	ROTARY GEAR PUMP
713-19-2	PUMP, (WAS 142-2-92)
713-20-160-2	PUMP ADAPTER BRACKET
713-920-7	PUMP
713-930-2	S3 FLANGE PUMP
713-9003-107-1	CAP & STAND BUSHINGS
713-9003-280	KIT, REPAIR #3 PUMP
716-10040-1603-10	MOTOR, PUMP
783-1-301	SCREW MACH SET UP
783-1-502	SCR.MCH.USE AND CONST.
783-1-505-2	CAM & TOOL DESIGN TABLES
783-1-506	CAM & TOOL DESIGN
820-2-202-1	HEATER SELECTION CHART
820-294-309-1	CAM LAYOUT SHEET,00 AUTO
820-324-309	CAM LAYOUT SHEET, #2 AUTO
840.142	MOTOR 220/380V-60HZ
840.648	LAMP 110V COMPLETE
842.174	V-BELT POLYFLEX
846.218	PULLEY-1
846.225	SERRATED BELT PULLEY
846.227	SERRATED BELT PULLEY CPL
846.291	WORM GEAR CPL
846.308	CHUCK LEVER CPL 10MM
846.309	CHUCK LEVER FOR A25 - 12MM
846.320	PIECE METER
846.334	CHUCK LEVER FOR TB
846.338	HINGE RIGHT CPL
846.339	HINGE LEFT CPL - A25
846.878	RUBBER SEALING
847.619	CAM DRUM CPL
849.767	PARTS BOOK, A15 - A25
849.769	PARTS BOOK, TB42/60-TBF42-TBH

PART #	DESCRIPTION
860.293	BRAKE MOTOR
860.456	MOTOR 380V/50HZ
860.550	MOTOR
860.608	SIGNAL LAMP
860.609	INCANDESCENT LAMP
862.562	FOAM RUBBER
862.834	CIRCLIP
864.066	SLIDE
866.531	PUSHER CPL
866.828	FLAG
867.205	FLANGE
867.249	V-BELT PULLEY
892.380	LAMP
893.837	CRANK CPL
893.879	CRANK CPL
893.906	FLAG
894.980	FRONT WORM GEAR CPL
897.048	BACK LEFT COVER
897.403	V-BELT
897.429	THREADED PIN
897.515	COOLANT POINT CPL
897.671	PUSHER CPL
897.797	V-BELT
897.900	FEED TUBE A25
898.555	ELECTRICAL CONTROL PANEL A25
913.114	INDEXING PIN ASSEMBLY
934-840	SEAL KIT,PTC FLO VLV-DBL A2
1366-5	NUT - INNER
2711-59193	VERTICAL TOOL HOLDER
413366-E	REPLACEMENT BRAKE DISCS
B-5	B-5 CRAWFORD, 1/2-5/8 RD
C20144-2062-A	MANCHESTER, WICKMAN2-1/4-6,6TH
C20600-10	MANCHESTER, WICKMAN HOLDER
C20600-12	MANCHESTER, WICKMAN
C-554	FORGING FOR 42-12397
D41-552	SHELL, TRUUE LOCK PIN
D41-1967	CHUCK NUT

PART #	DESCRIPTION
D41-2093	STOP SCREW
D91-100-75	SCREW MACHINE RELATED ITEM
D91-100-353	SCREW MACHINE RELATED ITEM
D91-204-559	SCREW MACHINE RELATED ITEM
D92-900-1238	SCREW MACHINE RELATED ITEM
D92-5070-844	SCREW MACHINE RELATED ITEM
D431-12	UK MFG PART
D431-51324	UK MFG PART
D432-1046	SCREW MACHINE RELATED ITEM
D437-1452	UK MFG PART
D461-106	UK MFG PART
D461-9021	UK MFG PART
D463-22	UK MFG PART
D463-874	UK MFG PART
D466-3163-4	UK MFG PART
DFB-1.000-M42	DAVENPORT FORM BLANK, 1" W
DSB-1.000-M42	DAVENPORT BLANK 1" WIDE
DSB-250-M42	DAVENPORT BLANK, 1/4" WIDE
DSB-250-REX	DAVENPORT BLANK, 1/4" WIDE
DSB-625-M42	DAVENPORT BLANK, 5/8" WIDE
DSB-875-REX	DAVENPORT BLANK, 7/8" WIDE
L-922	COLLET CHUCK
MISC 022	METERING UNIT
MISC 067	ADAPTOR
MISC 068	METER UNIT
MISC 075	METER UNITS
NF42-179	TURRET LOCKIN PIN
NF42-1372	CHANGE GEAR BUSHING
NF42-6573-2	CAM HOLDER
NF42-7221	WORM WHEEL
NF42-7853	BUSHING, USE 42-10223-99
NF42-8034-1	CLUTCH, CHUCK
NF42-8193	STOCK STOP
NF42-9222-3	STOCK STOP
NF42-9447	DRIVING SHAFT
NF42-10897	SPINDLE REAR BOX
NF42-11549	DOG, TRIP LEVER

PART #	DESCRIPTION
NF42-11894	SPROCKET, LT, NF
NF42-12509	WORM WHEEL SHAFT
NF42-12544-2	HOLDER ARM
NF42-13889	CLUTCH SLEEVE
NF42-15270	CHUCK ADJUSTING NUT
NF42-15572	SPROCKET BUSHING
NF42-16234-1	LEAD CAM HOLDER
NF42-16362-3	TURRET, 6-HOLE
NF42-16531-5	GEAR SHAFT
NF42-16824	COLLAR, SAFETY CLUTCH GEAR
NF42-16935-1	ROLL, OPERATING LEVER SHAFT
NF42-17020-1	IDLER SPROCKET, RIGHT
NF42-17058-4	TOOL HOLDER, FORWARD TURN
NF42-17375-1	SPINDLE NF 1 1/2"
NF42-17560-2	CAM LEVER
NF42-18507-2	PLATE
NF42-18512	BOLT
NF42-19501	ADJUSTMENT SCREW
NF42-20027-3	CLUTCH SLEEVE
NF42-58523	WORMWHEEL, CAMSHAFT
NF42-58722	TURRET SLIDE RACK
NF45-72	FEED ADJUSTING SCREW CAP
OR-15	SCREW MACHINE RELATED ITEM
P42-112	SPINDLE REAR BEARING SPACER
P42-122	PLUNGER, SPEED STOP LEVER SPR.
P42-123-1	REVERSING CLUTCH INSERT
P42-125	FEED TUBE WASHER
P42-126	CUSHION WASHER
P42-132	SPINDLE SPROCKET, LEFT
P42-133	CLUTCH SLEEVE RING
P42-135-B	CHUCK FORK SLEEVE
P42-141	NUT, CHUCK ADJUSTING
P42-142	FULCRUM, CHUCK LEVER
P42-143	SPINDLE
P42-144	SPINDLE FRONT BOX NUT, LEFT
P42-145	SPACER
P42-146	SPACER

PART #	DESCRIPTION
P42-149	SPINDLE FRONT BOX
P42-150	FRONT BOX NUT
P42-171	SPRING
P42-174	END PLUG
P42-177	SPRING, SILENT
P42-187	NUT
P42-188	STEM
P42-216	BUCKLE, HEX TURN
P42-223	TURN BUCKLE LINK NUT L.H.
P42-226	MOULDED RING
P42-248	SWITCH
P42-254	PIPE, GRIFLEX
P42-259	DOUBLE BODIED UNION
P42-260	NUT, FEMALE
P42-261	STEM, MALE
P42-262	FERRULE
P42-290	DOWEL, GROOVER SPRING
P42-301	PIPE, WASTE
P42-323	UNION FOR PUMP
P42-1554	TURRET SLIDE GIB
P42-7172-2	NUT,FEED LATCH PLUNGER
P42-7618	DR. GEAR OPER RACK
P42-9168-1	REVERSING CLUTCH
P42-9774-1	WORM SHAFT EXTENSION
P42-10419	CHUCK SLEEVE #22D
P42-10539	CHUCK SLEEVE
P42-11205-0-A	STOPPING LEVER COMP.
P42-11497	NUT,#00 CHUCK
P42-11625	OIL LABRYNTH SEAL
P42-12190-1	SPINDLE
P42-12507-1	LEAD CAMSHAFT
P42-13117	FEED LATCH
P42-15145-4	SHAFT, TURRET CHANGE
P42-15868	DRIVING GEAR
P42-16847	RET. SPRING FITTING WASHER
P42-17351-2	CHUCK ADJ NUT
P42-17392	REAR BOX, SPINDLE

PART #	DESCRIPTION
P42-17428-1	CHUCK ADJ NUT
P42-17433	CHUCK FORK SLEEVE INNER
P42-17518-1	FEED SLIDE
P42-19218	SLIDE WAY
P42-19239	GIB, FOURTH SLIDE
P42-19521	CAM, ADVANCING
P42-19522	CAM, TRANSFER
P42-19704	CARRIER, DOG
P42-19715	PLUNGER
P42-19736	LOCKING PIN LEVER STUD
P42-19766	OIL SEAL
P42-19768	DEFLECTOR GUIDE
P42-19781	SWITCH DOG 4/100
P42-19784	DOG, SWITCH EXTENSION
P42-19787	IDLER BRACKET
P42-19904	CLUTCH COIL BRACKET SMALL
P42-19944	GUARD
P42-19973-1	SPINDLE SPROCKET-GEARED 3/4
P42-19978	SPINDLE SPROCKET-LEFT 1.5/8
P42-19979	SPRING (BELVILLE TYPE)
P42-19980-1	CHUCK ADJ NUT
P42-19987-0-A	FEED TUBE COMP. 1-5/8" CAP
P42-19994	GUARD
P42-20009	CLUTCH INSERT
P42-20075	SPRING, TRIP LEVER
P42-20104	CROSS SLIDE RACK FRONT
P42-20199	PLATE
P42-20207-1	PLATE
P42-20208-1	PLATE
P42-20209-0-2	PLATE
P42-20209-1	PLATE
P42-20211	PLATE
P42-20212	PLATE
P42-20234-2	PLATE
P42-20266-1	SPINDLE
P42-20279-1	SPINDLE SPROCKET LEFT
P42-20366	NUT- LEFT

PART #	DESCRIPTION
P42-21077-1	WORMSHAFT
P42-21080-1	WORMWHEEL
P42-21089	CAM HOLDER
P91-90-721	PLUG
P92-970-612	KEY
P92-970-824	KEY
P92-970-1046	KEY
P92-980-832	KEY, WOODRUFF
P142-00-12-2	CIRCULAR TOOL POST, 00 FRONT
P465-140	TAP ASSY.
P498-20151-6513	SCREW MACHINE RELATED ITEM
P711-5-1522	ADAPTER
P-50-51027	SCREW MACHINE RELATED ITEM
PM42-19962-1	SCREW MACHINE RELATED ITEM
PRINTS 10	REPRINTS OF PARTS PRINTS
Q-140	TUBE CONECTION, BRASS
Q-335	NUT
Q-427	BUTTON HEAD SCREW
Q-455	TECALEMIT ADAPTER
Q-504	SCREW
Q-549	JAM NUT
Q-593	CLIP RING
Q-728	TOOL PART
Q-863	PIN
Q-1011	OIL TUBE & FILTER
Q-1062	BOX LINER
Q-1119	PIN
Q-1160	FITTING
Q-1192	NUT
Q-1203	BOLT
Q-1241	TUBE CONECTION, BRASS
Q-2036	GEAR
Q-2038	CHANGE GEAR
Q-2040	GEAR
Q-2042	GEAR
Q-2075	HOLDER
Q-3001	SCREW

PART #	DESCRIPTION
Q-3008	CAP HEAD SCREW
Q-5014	ARM
Q-5021	FITTING
Q-6003	GEAR
Q-9803	LOCK NUT
Q-9808	PLATE
Q-9811	SET SCREW
Q-9814	LINK
Q-9815	LINK
Q-10057	CAM HOLDER
Q-10109	PACKING
Q-10127	KEY
Q-10153	CHAIN
Q-10155	LINK
Q-10157	CHAIN LINK
Q-10523	BALL, CHUCK SLEEVE 9/32"
Q-10524	BALL, CHUCK SLEEVE 7/16"
Q-10527	CHROME STEEL BALL 5/16"
Q-10554	BALL, 7/16 OVERSIZE +2
SS-5087-1	SCREW MACHINE RELATED ITEM

Maintaining your equipment to its optimum performance is important to your business.

Turning Concepts has the knowledge and expertise to help you on your next project. Call one of our experts today and see the difference working with Turning Concepts can make for your business.

Turning Concepts
701 Matthews Mint-Hill Road
Matthews, NC 28104

Phone (704) 849-9209

